

alternator to battery wiring diagram

Alternator to Battery Wiring Diagram: A Comprehensive Guide

Author: Dr. Emily Carter, PhD, Automotive Engineering, SAE Member (Society of Automotive Engineers) – Dr. Carter has over 15 years of experience in automotive electrical systems design and diagnostics.

Publisher: AutoTech Publications – A leading publisher of automotive repair manuals and technical guides, known for its accuracy and comprehensive coverage.

Editor: Mark Olsen, ASE Certified Master Technician – Mark Olsen brings over 20 years of hands-on automotive repair experience to the editing process, ensuring the accuracy and clarity of the information presented.

Keywords: alternator to battery wiring diagram, alternator wiring, battery charging system, automotive electrical system, car alternator, alternator replacement, charging system diagram, automotive wiring diagrams, electrical troubleshooting, alternator repair.

Summary: This article provides a comprehensive understanding of the alternator to battery wiring diagram, its significance in a vehicle's electrical system, and the troubleshooting procedures for common problems. It details various alternator types, the components involved in the charging circuit, and step-by-step guidance on interpreting wiring diagrams. The article also covers safety precautions, common faults, and preventative maintenance to ensure optimal performance of the battery charging system.

1. Understanding the Significance of the Alternator to Battery Wiring Diagram

The alternator to battery wiring diagram is a crucial blueprint illustrating how the alternator, the battery, and other related components interact to charge the vehicle's battery and power its electrical systems. Without a functioning charging system, your vehicle will quickly deplete its battery, leading to a complete shutdown. Understanding this diagram is fundamental for anyone working on a vehicle's electrical system, from professional mechanics to DIY enthusiasts. This diagram shows the flow of electricity from the alternator, its regulation, and its delivery to the battery for charging. It's not just a simple connection; it involves fuses, voltage regulators, warning lights, and potentially other ancillary systems. Mastering this diagram is key to diagnosing and resolving issues related to the charging system.

2. Components of the Alternator to Battery Charging System

Before delving into the wiring diagram itself, let's understand the essential

components involved:

Alternator: This is the heart of the system, generating direct current (DC) electricity from the engine's mechanical energy. Different alternator types exist, including those with internal and external voltage regulators.

Battery: The battery stores electrical energy and provides power when the engine is off or the alternator isn't producing sufficient power. Common types include lead-acid, AGM (Absorbent Glass Mat), and lithium-ion.

Voltage Regulator: This critical component maintains the alternator's output voltage within the specified range, preventing overcharging or undercharging of the battery. It's either integrated within the alternator or a separate unit.

Wiring Harness: A network of wires connects the alternator, battery, voltage regulator, and other related components. The wiring harness is color-coded, and understanding the color codes is essential for interpreting the wiring diagram.

Fuses and Circuit Breakers: These safety devices protect the electrical system from overcurrent, preventing damage to components and reducing fire hazards.

Battery Charge Indicator Light (Warning Light): This light on the dashboard indicates the charging system's status. A lit light often signals a problem with the alternator or charging system.

3. Deciphering the Alternator to Battery Wiring Diagram

The alternator to battery wiring diagram can vary slightly depending on the vehicle's make, model, and year. However, the fundamental principles remain consistent. The diagram typically uses symbols to represent components and lines to illustrate the connections. Understanding these symbols is paramount. For example, a circle might represent a connector, a rectangle might represent a fuse, and different line thicknesses can indicate different wire gauges.

A typical diagram will show:

Positive (+) and Negative (-) Terminals: Clearly identifying the polarity of connections is crucial to prevent short circuits.

Alternator Output Wires: These wires carry the generated DC electricity from the alternator to the battery and other components.

Battery Connections: Showing the positive and negative terminals of the battery and their connections to the rest of the system.

Voltage Regulator Connections: Illustrating how the voltage regulator monitors and controls the alternator's output voltage.

Fuse or Circuit Breaker Locations: Identifying the protective devices in the circuit.

Grounding Points: Showing where the negative (-) side of the circuit is grounded to the vehicle's chassis.

By carefully tracing the lines and identifying the components, you can understand the complete flow of electricity through the charging system.

4. Common Problems and Troubleshooting using the Alternator to Battery Wiring Diagram

Using the alternator to battery wiring diagram, you can effectively

troubleshoot various charging system issues. Common problems include:

Battery not charging: This could be due to a faulty alternator, voltage regulator, wiring problems, or a bad battery itself. The wiring diagram helps pinpoint the location of the fault by tracing the circuit.

Overcharging: An overcharging battery can lead to damage. The wiring diagram helps trace the path to identify the issue with the voltage regulator or other components.

Alternator not generating power: This can be caused by a faulty alternator, broken belt, or problems within the internal circuitry. The wiring diagram aids in confirming if the issue is electrical or mechanical.

Warning light illuminated: A constantly lit battery warning light points to a charging system problem. Using the diagram helps isolate the source of the fault.

5. Safety Precautions When Working with the Alternator to Battery Wiring Diagram

Working with a vehicle's electrical system requires careful attention to safety:

Disconnect the battery negative terminal: This is the most important safety precaution to prevent short circuits and electrical shocks.

Use insulated tools: Always use insulated tools to avoid electrical shocks.

Consult the vehicle's repair manual: This manual provides specific information about your vehicle's electrical system and safety procedures.

Wear safety glasses: Protect your eyes from flying debris or sparks.

Work in a well-ventilated area: Exhaust fumes can be dangerous.

6. Preventative Maintenance for Optimal Performance

Regular maintenance can prolong the lifespan of your vehicle's charging system:

Inspect the alternator belt: Ensure the belt is properly tensioned and not showing signs of wear or damage.

Check battery terminals: Clean and tighten the battery terminals regularly to ensure a good connection.

Have the battery and charging system tested periodically: This can identify potential problems before they become major issues.

7. Different Types of Alternator to Battery Wiring Diagrams

While the basic principles remain the same, the complexity of the alternator to battery wiring diagram can vary. Simpler diagrams might be found in older vehicles with less sophisticated electrical systems. Modern vehicles, however, often incorporate more complex systems, including CAN bus communication, resulting in more intricate wiring diagrams. These diagrams may include multiple circuits and auxiliary components, requiring a more thorough understanding to troubleshoot effectively. Knowing the specific type of diagram you are working with is crucial for effective diagnosis and repair.

8. Utilizing Online Resources and Software

Numerous online resources and software applications are available to help interpret alternator to battery wiring diagrams. These tools offer visual representations, interactive diagrams, and troubleshooting guides. However, it's crucial to ensure the accuracy and reliability of the source before using the information. Always cross-reference information with your vehicle's specific repair manual.

9. Conclusion

Understanding the alternator to battery wiring diagram is essential for maintaining a vehicle's electrical system. This article has provided a comprehensive guide to interpreting these diagrams, troubleshooting common problems, and performing preventative maintenance. By following the safety precautions and utilizing available resources, individuals can confidently address charging system issues and ensure the reliable operation of their vehicles.

FAQs

1. What happens if my alternator fails? Your battery will drain, and eventually, your vehicle will fail to start.
2. How often should I have my alternator tested? As part of routine maintenance, it's a good idea to have your charging system tested at least annually or if you notice any charging system issues.
3. Can I replace the alternator myself? Depending on your mechanical skills and the vehicle, it's possible. However, it requires some mechanical knowledge and the right tools.
4. What does the battery light on my dashboard mean? It typically indicates a problem with the charging system, such as a faulty alternator or voltage regulator.
5. How do I interpret the color codes on the wiring harness? Your vehicle's repair manual will provide a legend explaining the color codes.
6. What is the difference between an internal and external voltage regulator? Internal regulators are integrated within the alternator, while external regulators are separate components.
7. Can I use a different type of battery in my vehicle? It's crucial to use a battery that meets the vehicle's specifications. Using an incompatible battery can damage the charging system.
8. How much does it cost to replace an alternator? The cost varies depending on the vehicle, the alternator's cost, and the labor charges.
9. What are the signs of a failing alternator? Dim headlights, slow cranking, battery warning light, electrical accessories not functioning correctly.

Related Articles

1. **Troubleshooting a Dead Battery: A Step-by-Step Guide:** This article focuses on diagnosing the root cause of a dead battery, which often involves the alternator and charging system.
2. **Understanding Automotive Electrical Systems:** A broader overview of automotive electrical systems, including the alternator and its role.
3. **How to Test an Alternator: A Comprehensive Guide:** Detailed instructions on testing an alternator using a multimeter.
4. **Automotive Fuses and Circuit Breakers: A Guide to Protection:** Explores the role of fuses and circuit breakers in protecting the electrical system.
5. **Common Automotive Wiring Problems and Solutions:** Discusses various wiring issues and how to diagnose and fix them.
6. **Reading Automotive Wiring Diagrams: A Beginner's Guide:** A basic tutorial on interpreting automotive wiring diagrams.
7. **Maintaining Your Car Battery for Optimal Performance:** Tips and advice on caring for your car battery to extend its lifespan.
8. **Understanding CAN Bus Communication in Modern Vehicles:** An explanation of the CAN bus system and its impact on automotive electrical systems.
9. **DIY Alternator Replacement: A Step-by-Step Guide (for specific vehicle model):** A detailed, model-specific guide on replacing an alternator. (Note: This article would need to be created for each specific vehicle model).

alternator to battery wiring diagram: ,

alternator to battery wiring diagram: Car PC Hacks Damien Stolarz, 2005-07-27 A car PC or carputer is a car tricked-out with electronics for playing radio, music and DVD movies, connecting to the Internet, navigating and tracking with satellite, taking photos, and any electronic gadget a person wants in a car. All these devices are managed and controlled through a single screen or interface. The only place car PC enthusiasts can go for advice, tips and tools is a handful of hard-to-find Web sites--until now. Car PC Hacks is your guide into the car PC revolution. Packing MP3 players, handheld devices, computers and video-on-demand systems gives you a pile too heavy to carry. But add a car and put them together, you've got a powerful and mobile multimedia center requiring no lifting. The next time you give kids a lift, you won't hear, Are we there yet? Instead, expect We're there already? as they won't want to leave the car while playing video games from multiple consoles. Car PC Hacks is the first book available to introduce and entrench you into this hot new market. You can count on the book because it hails from O'Reilly, a trusted resource for technical books. Expect innovation, useful tools, and fun experiments that you've come to expect from O'Reilly's Hacks Series. Maybe you've hacked computers and gadgets, and now you're ready to take it to your car. If hacking is new and you would like to mix cars and computers, this book gets you started with its introduction to the basics of car electrical systems. Even when you're unclear on the difference between amps and watts, expect a clear explanation along with real-life examples to

get on track. Whether you're venturing into car PC for the first time or an experienced hobbyist, hop in the book for a joy ride.

alternator to battery wiring diagram: Operator, Organizational, Direct Support, and General Support Maintenance Manual, Including Repair Parts List for Welding Machine, Model GCC-300W (3431-01-032-6289). , 1990

alternator to battery wiring diagram: Humvee HMMV M998 series Technical Manual Unit Maintenance For Brian Greul, 2021-01-17 The M998 HMMV (High Mobility Multipurpose Wheeled Vehicle) was introduced in 1983 to replace the ubiquitous M151 commonly called a Jeep. The HMMV will be replaced by the JLTV with the first fieldings beginning in 2019 for the US Military. This manual is a reprint of the official manual.

alternator to battery wiring diagram: Organizational Maintenance Manual , 1982

alternator to battery wiring diagram: Volkswagen Rabbit, Jetta (A1 Diesel Service Manual 1977, 1978, 1979, 1980, 1981, 1982, 1984, 1984: Including Pickup Truck and Turbo Diesel Bentley Publishers, 2012-03-01 The Volkswagen Rabbit, Jetta (A1) Diesel Service Manual: 1977-1984 covers 1977 through 1984 models with diesel engines, including those built on the A1 platform. This manual includes both the American-made and German-made Rabbits, VW Jettas, and VW Pickup Trucks with diesel engines built for sale in the United States and Canada. Engines covered: * 1.6L Diesel (engine code: CK, CR, JK) * 1.6L Turbo-Diesel (engine code: CY)

alternator to battery wiring diagram: Automotive Electrical Handbook Inkwell Co. Inc., 1987-01-01 When it's time to wire your car, whether it's a restoration project, race car, kit car, trailer, or street rod, don't be intimidated; wire it yourself. Jim Horner shares his years of experience and cuts through the technical jargon to show you how. Learn about basic electrical theory, how various electrical components work and drawing circuit diagrams. Includes tips on using electrical test equipment and troubleshooting electrical circuits. Choose the right components, build your own wiring harness, and install them by following the step-by-step instructions. Profusely illustrated with over 350 photos, drawings, and diagrams. Suppliers list included.

alternator to battery wiring diagram: Naval Ship Systems Command Technical News , 1958

alternator to battery wiring diagram: AC Maintenance & Repair Manual for Diesel Engines Jean Luc Pallas, 2013-08-22 The aim of this book with its detailed step-by-step colour photographs and diagrams, is to enable every owner to fix their diesel engine with ease. Troubleshooting tables help diagnose potential problems, and there is advice on regular maintenance and winterising and repair. Jean-Luc Pallas's enthusiasm for passing on his knowledge, as well as his clear explanations, precise advice and step-by-step instructions make this a unique book.

alternator to battery wiring diagram: Audels Engineers and Mechanics Guide , 1921

alternator to battery wiring diagram: Operator, Organizational, Direct Support, General Support, and Depot Maintenance Manual , 1990

alternator to battery wiring diagram: SAAB SONETTS Mark Staniforth, 2019-10-15 ANTI-SONNETS comprised the creation of one sonnet per day over a year, irrespective of personal circumstance. Each sonnet's subject matter, and perhaps also the perceived quality of its artistic execution, would reflect the tribulations of daily life. ANTI-SONNETS aimed to challenge assumptions associated with the sonnet form, and to champion the ascendancy of context over content. SAAB SONETTS is part of the extended fall-out.

alternator to battery wiring diagram: Bumper to Bumper Mike Byrnes & Associates, 2003 Textbook for tractor semitrailer operations: fourth edition includes current information on hours of service, hazardous materials, cargo securement, in-cab technology; trucking industry history; U.S. regulations; procedures; descriptions of systems, components, use/maintenance requirements; troubleshooting; safe driving; economy driving; regulated activities. Includes end-of-chapter tests, Observation Skills Tests, illustrations, index

alternator to battery wiring diagram: Operator and Organizational Maintenance Manual , 1991

alternator to battery wiring diagram: *Operator's, Organizational, and Direct Support Maintenance Manual (including Repair Parts and Special Tools List)* , 1992

alternator to battery wiring diagram: *Fundamentals of Automotive Technology* Kirk VanGelder, 2022-02-23 *Fundamentals of Automotive Technology: Principles and Practice, Third Edition* is a comprehensive resource that provides students with the necessary knowledge and skills to successfully master these tasks

alternator to battery wiring diagram: Operator's and Organizational Maintenance Manual , 1991

alternator to battery wiring diagram: Operator and Organizational Maintenance Manual for Crane, Shovel, Truck Mounted, 20 Ton, 3/4 Cu. Yd., G.E.D., 6 X 6, (Harnischfeger Model M320T), FSN 3810-861-8088 , 1980

alternator to battery wiring diagram: Fundamentals of Medium/Heavy Duty Commercial Vehicle Systems Gus Wright, Owen C. Duffy, 2019-07 Thoroughly updated and expanded, 'Fundamentals of Medium/Heavy Duty Commercial Vehicle Systems, Second Edition' offers comprehensive coverage of basic concepts building up to advanced instruction on the latest technology, including distributed electronic control systems, energy-saving technologies, and automated driver-assistance systems. Now organized by outcome-based objectives to improve instructional clarity and adaptability and presented in a more readable format, all content seamlessly aligns with the latest ASE Medium-Heavy Truck Program requirements for MTST. --Back cover.

alternator to battery wiring diagram: Volvo Penta MD5A Marine Diesel Engine N N, 2012-05 Reprint of the Workshop Manual of the well-known Volvo Penta MD5A Marine Diesel Engine.

alternator to battery wiring diagram: Fundamentals of Mobile Heavy Equipment Owen C. Duffy, Gus Wright, Scott A. Heard, 2017-09-27 *Fundamentals of Mobile Heavy Equipment* provides students with a thorough introduction to the diagnosis, repair, and maintenance of off-road mobile heavy equipment. With comprehensive, up-to-date coverage of the latest technology in the field, it addresses the equipment used in construction, agricultural, forestry, and mining industries.

alternator to battery wiring diagram: Petersen's Basic Ignition and Electrical Systems [edited by Spencer Murray and the Technical Editors of Specialty Publications Division]. Spence Murray, 1977

alternator to battery wiring diagram: Yanmar Marine Diesel Engines 3JH3 E , 4JH3 E, 4JH3CE1 Yanmar, 2013-06 Complete Service Handbook for the Yanmar Marine Diesel Engines (B)(C)E(A), 4JH3(B)(C)E and 4JH3CE1.

alternator to battery wiring diagram: Operator's, Organizational, Direct Support, and General Support Maintenance Manual (including Repair Parts Information and Supplemental Maintenance and Repair Parts Instructions) for Compactor, High Speed, Tamping Self-propelled (CCE) BOMAG Model K300 NSN 3895-01-024-4064 , 1982

alternator to battery wiring diagram: How To Diagnose and Repair Automotive Electrical Systems Tracy Martin, 2005

alternator to battery wiring diagram: Popular Science , 1970-03 Popular Science gives our readers the information and tools to improve their technology and their world. The core belief that Popular Science and our readers share: The future is going to be better, and science and technology are the driving forces that will help make it better.

alternator to battery wiring diagram: *Custom Auto Wiring & Electrical HP1545* Matt Strong, 2009-04-07 This indispensable guide to high performance and OEM automotive electrical systems covers electrical theory, wiring techniques and equipment, custom wiring harnesses for racing, hot rods and restorations, pre-made wiring harnesses, special electrical systems (navigational, audio, video), troubleshooting common electrical problems, dashboards and instrument, and trailer wiring.

alternator to battery wiring diagram: 52 Prepper Projects David Nash, 2013-11-06 A simple and easy-to-understand introduction to the fundamentals of...

alternator to battery wiring diagram: Polaris, Sportsman 400 and 500 4x4, 1996-2003 and

Xplorer 500 4x4, 1997-2003 Ed Scott, 2004

alternator to battery wiring diagram: How to Restore Your Farm Tractor Tharran E Gaines, 2020-06-09 The only all-marque antique tractor restoration guide is back in print, packed with the kind of detail you need to complete a first-class restoration. How to Restore Your Farm Tractor features hundreds of helpful full-color photographs, proven tips and techniques, and money-saving advice from restorers who know what works...and what doesn't. Tractor expert Tharran Gaines walks you step by step through the restoration techniques applicable to all of the most popular and collectible makes, covering: Shopping for a tractor and setting up shop Engine disassembly and rebuild Clutches and transmissions Final drives and brakes Steering Hydraulic, electrical, and fuel systems Tires and wheels Body repair, painting, and decals There's even information on antique tractor shows and demos, as well as a handy updated section on parts sources. John Deere, Ford, Farmall, Allis-Chalmers, Minneapolis-Moline, and more...no matter your passion, with Gaines' guidance you will be well on your way to transforming that old tractor into a shiny "new" classic!

alternator to battery wiring diagram: Technical Manual, Operator and Organizational Manual , 1980

alternator to battery wiring diagram: Operator's, Organizational, Direct Support, and General Support Maintenance Manual Including Repair Parts Information and Supplemental Operating, Maintenance, and Repair Parts Instructions for Forklift Truck, GED, SRT, 4,000 Lb. Cap, 144 Inch Lift Height, Model ACC 45 PS, MHE 239, NSN 3930-01-074-4937 , 1990

alternator to battery wiring diagram: The Essential Guide to Motorcycle Maintenance Mark Zimmerman, 2016-12-15 Popular motorcycle journalist and author Mark Zimmerman brings a comfortable, conversational tone to his easy-to-understand explanations of how motorcycles work and how to maintain them and fix them when they don't. This practical tutorial covers all brands and styles of bikes, making it a perfect companion to the owner's service manual whether you need to use the step-by-step instructions for basic maintenance techniques to wrench on your bike yourself or just want to learn enough to become an informed customer at your local motorcycle service department. This book includes more than 500 color photos and a thorough index to make it an especially user-friendly reference for home motorcycle mechanics of all skill levels.

alternator to battery wiring diagram: Aviation Maintenance Technician Handbook-Airframe Federal Aviation Administration (FAA)/Aviation Supplies & Academics (ASA), 2012 This new FAA AMT Handbook--Airframe Volume 1 is one of two volumes that replace and supersede Advisory Circular (AC) 65-15A. Completely revised and updated, this handbook reflects current operating procedures, regulations, and equipment. This book was developed as part of a series of handbooks for persons preparing for mechanic certification with airframe or powerplant ratings, or both -- those seeking an Aviation Maintenance Technician (AMT) Certificate, also called an A&P license. An effective text for both students and instructors, this handbook will also serve as an invaluable reference guide for current technicians who wish to improve their knowledge. Airframe Volume 1 contains: Aircraft Structures, Aerodynamics, Aircraft Assembly and Rigging, Aircraft Fabric Covering, Aircraft Metal Structural Repair, Aircraft Welding, Aircraft Wood and Structural Repair, Advanced Composite Materials, Aircraft Painting and Finishing, Aircraft Electrical System Includes colored charts, tables, full-color illustrations and photographs throughout, and an extensive glossary and index.

alternator to battery wiring diagram: Advanced Automotive Fault Diagnosis Tom Denton, 2016-07-07 Learn all the skills you need to pass Level 3 and 4 Vehicle Diagnostic courses from IMI, City and Guilds and BTEC, as well as higher levels, ASE, AUR and other qualifications. Advanced Automotive Fault Diagnosis explains the fundamentals of vehicle systems and components and examines diagnostic principles as well as the latest techniques employed in effective vehicle maintenance and repair. Diagnostics, or fault finding, is an essential part of an automotive technician's work, and as automotive systems become increasingly complex there is a greater need

for good diagnostics skills. For students new to the subject, this book will help to develop these skills, but it will also assist experienced technicians to further improve their performance and keep up with recent industry developments. Checked and endorsed by the Institute of to him to ensure that it is ideal for both independent and tutor-based study Diagnostics case studies to help you put the principles covered into real-life context Useful margin features throughout, including definitions, key facts and 'safety first' considerations

alternator to battery wiring diagram: Electrician's Wiring Manual Frank Ferdinand Sengstock, 1914

alternator to battery wiring diagram: Manuals Combined: 150+ U.S. Army Navy Air Force Marine Corps Generator Engine MEP APU Operator, Repair And Parts Manuals , Over 36,000 total pages Just a SAMPLE of the CONTENTS by File Number and TM Number:: 013511 TM 5-6115-323-24P 4 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 K SINGLE PHASE, AC, 120/240 V, 28 VDC (LESS ENGINE) DOD MODELS MEP-015A, 60 HZ (NSN 6115-00-889-1446) AND (DOD MODEL MEP-025A) 28 VDC (6115-00-017-8236) {TO 35C2-3-385-4; SL 4-07609A/07610A} 013519 TM 5-6115-329-25P 1 GENERATOR SET, GASOLINE ENGINE DR (LESS ENGINE) 0.5 KW, AC, 120/240 V, 60 HZ, 1 PHASE (DOD MODEL (FSN 6115-923-4469); 400 HZ (MODEL MEP-019A) (6115-940-7862) AN DC (MODEL MEP-024A) (6115-940-7867) {TO 35C2-3-440-14} 013537 TM 5-6115-457-12 7 GENERATOR SET, ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 4 WIRE, 120 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101), (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102), (MODEL MEP-116A) PRECISE CLASS, 400 KW (6115-00-133-9103) INCLUDING OPTIONAL KITS (MODEL MEP-007 AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082), (MEP-007AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9084), (MODEL MEP-007A DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP-007AWM) WHEEL 013538 TM 5-6115-457-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID 100 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODELS MEP0 UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101); (MODEL MEP106A) CLASS, 50/60 HZ (6115-00-133-9102) AND (MODEL MEP116A), PRECISE 400 HZ (6115-00-133-9103); INCLUDING OPTIONAL KITS (DOD MODELS MEP007AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082); MEP007AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-9084); (MOD MEP007ALM) DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP007A MOUNTING KIT (6 013540 TM 5-6115-458-24P 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD., 2 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, DOD MODELS MEP009A UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND MODEL MEP108A PRECISE CLASS, 50/60 HZ (6115-00-935-8729) INCLUDING OPTIONAL K DOD MODELS MEP009AWF, WINTERIZATION KIT, FUEL BURNING (6115-00-403-3761), MODEL MEP009AWE, WINTERIZATION KIT, ELECTRIC (6115-00-489-7285) 013545 TM 5-6115-465-12 19 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 30 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODEL MEP-005A), UTILITY CLASS, 50/6 (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE CLASS, 50/60 (6115-00-118-1247), (MODEL MEP-114A), PRECISE CLASS, 400 HZ (6115-00-118-1248) INCLUDING AUXILIARY EQUIPMENT (DOD MODEL MEP WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083), (MODEL MEP- WINTERIZATION KIT, ELECTRIC (6115-00-463-9085), (MODEL MEP-005A LOAD BANK KIT (6115-00-463-9088) AND (MODEL MEP-005AWM), WH 013547 TM 5-6115-465-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTIC SKID MTD, 30 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MO MEP-005A), UTILITY, 50/60 HZ (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE, 50/60 HZ (6115-00-118-1247), (MODEL MEP-114 PRECISE, 50/60 HZ (6115-00-118-1248) INCLUDING OPTIONAL KITS (MODEL MEP-005AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (MODEL MEP-005AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-908 (MODEL MEP-005ALM) LOAD BANK KIT (6115-00-463-9088) (MODEL MEP- WHEEL MOUNTING KIT (6115-00 013548 TM 5-6115-545-12 18 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 60 KW, 3 PHASE, 4 WIR 120/208

AND 240/416 VOLTS, DOD MODEL MEP-006A, UTILITY CLASS, 5 (NSN 6115-00-118-1243) DOD MODEL MEP-105A, PRECISE CLASS, 50/60 (6115-00-118-1252) DOD MODEL MEP-115A, PRECISE CLASS, 400 HZ (6115-00-118-1253) INCLUDING OPTIONAL KITS, DOD MODEL MEP006AWF WINTERIZATION KIT, FUEL BURNING (6115-00-407-8314) DOD MODEL MEP006AWE, WINTERIZATION KIT, ELECTRIC (6115-00-455-7693) DOD M MEP006ALM, LOAD BANK KIT (6115-00-407-8322) DOD MODEL MEP006 013550 TM 5-6115-545-34 12 INTERMEDIATE (FIELD) (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE MANUAL FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODELS MEP-006A, UTILITY CLASS, 50/60 HZ (FSN 6115-118-1243 MEP-105A, PRECISE CLASS, 50/60 HZ (6115-118-1252) AND MEP-115A, PRECISE CLASS, 400 HZ (6115-118-1253) {TO 35C2-3-444-2; NAVFAC P-8-626-34; TM 00038G-35} 015378 TM 5-6115-323-14 10 GENERATOR GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 KW, SI PHASE, AC, 120/240 V, 28 V, DC (LESS ENGINE) (DOD MODELS MEP-01 60 HZ (NSN 6115-00-889-1446) AND (MODEL MEP-025A) 28 V DC (6115-00-017-8236) {TO 35C2-3-385-1} 015380 TM 5-6115-332-24P 3 GENERATOR GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE; 120/208 V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) M DESIGN: 60 HZ (DOD MODEL MEP-017A) (NSN 6115-00-017-8240); 400 (DOD MODEL MEP-022A) (6115-00-017-8241) {TO 35C2-3-424-24} 020611 LO 5-6115-457-12 GENERATOR SET, DIESEL ENGINE DRIVEN; SKID MTD, 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/ (NSN 6115-00-133-9101); (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102) AND (MODEL MEP-116A), PRECISE CLASS, 400 HZ (6115-00-133-9103) 020612 LO 5-6115-458-12 GENERATOR SET, DIESEL ENGINE DRIVEN, SKID MTD, 200 KW, 3 PHASE, 4 WIRE, 120/208/416 VOLTS, DOD MODELS MEP-009A, UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-133-9104), MEP-108A, PRECISE CLASS, 50 HERTZ (6115-00-935-8729) {LO 07536A-12} 020614 LO 5-6115-465-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 30 3 PHASE, 4 WIRE, 120/206 AND 240/416 V (DOD MODEL MEP-055A), UT CLASS, 50/60 HZ (NSN 6115-00-118-1240); (MODEL MEP 104A), PRECI CLASS, 50/60 HZ (6115-00-118-1247) AND (MODEL 114A) PRECISE CLA 400 HZ (6115-00-118-1248) 025150 TM 5-6115-271-14 12 GENERATOR SET, GASOLINE ENGINE DRIVEN, S MTD, TUBULAR FRAME, 3 KW, 3 PHASE, AC, 120/208 AND 120/240 V, 2 DC (LESS ENGINE) DOD MODEL MEP-016A, 60 HZ (NSN 6115-00-017-823 MODEL MEP-016C 60 HZ (6115-00-143-3311) MODEL MEP-021A 400 HZ (6115-00-017-8238) MODEL MEP-021C 400 HZ (6115-01-175-7321) MODEL MEP-026A DC HZ (6115-00-017-8239) MODEL MEP-026C 28 V DC (6115-01-175-7320) {TO 35C2-3-386-1; TM 05926A-14; NAVFAC P-8-6 025151 TM 5-6115-271-24P 3 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULA FRAME, 3 KW, 3 PHASE, AC; 120/208 AND 120/240 VOLTS, 28 VDC (LE ENGINE) (DOD MODEL MEP-016A) 60 HERTZ (NSN 6115-00-017-8237) (MEP-021A) 400 HERTZ (6115-00-017-8238) (MEP-026A) 28 VDC HERTZ (6115-00-017-8239) (MEP-016C) 60 HERTZ (6115-01-143-3311) (MEP- 400 HERTZ (6115-01-175-7321) (MEP-026C) 28 VDC HERTZ (6115-01-175-7320) {TO 35C2-3-386-4; SL-4-05926A} 032507 TM 5-6115-275-14 10 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208V PHASE, AND 120/240V, SINGLE PHASE, LESS ENGINE: DOD MODELS MEP- HZ, (NSN 6115-00-889-1447) AND MEP-023A, 400 HZ (6115-00-926-08 {NAVFAC P-8-615-14; TO 35C2-3-452-1} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032508 TM 5-6115-275-24P 5 GENERATOR, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE AND 120/240 V, SINGLE PHASE (LESS ENGINE); D MEP-018A, UTILITY CLASS, 60 HZ (NSN 6115-00-889-1447) AND MEP-0 PRECISE CLASS, 400 HZ (6115-00-926-0843) {NAVFAC P8-615-24P; TO 35C2-3-452-4} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032551 TM 5-6115-584-12 11 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-12; TO 35C2-3-456-1; TM 05682C-12} 032640 TM

5-6115-585-12 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 10 KW, 1 PHASE, 2 WIRE 1 PHASE, 3 WIRE AND 3 PHASE, 4 WIRE; 120, 120/240 AND 120/208 V (DOD MODEL MEP-003A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1030 AND (MODEL MEP-112A), UTILITY CLASS, 400 HZ (6115-00-465-1027) {NAVFAC P-8-623-12; TO 35C2-3-455-1; TM-05684C/05685B-12} 032781 TM 5-6115-584-34 8 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 5 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A), UTILITY CLASS, (NSN 6115-00-465-1044) {NAVFAC P-8-622-34; TO 35C2-3-456-2; TM 0568C-34} 032936 TM 5-6115-329-14 4 GENERATOR SET GASOLINE ENGINE DRIVEN, 0.5 KW (LESS ENGINE) (DOD MODEL MEP-014 UTILITY CLASS, 60 HZ) (NSN 6115-00-923-4469), (DOD MODEL MEP-01 UTILITY CLASS, 400 HZ (6115-00-940-7862) AND (DOD MODEL MEP-024 UTILITY CLASS, 28 VDC (6115-00-940-7867) {TO 35C2-3-440-1} 033374 TM 5-6115-332-14 10 GENERATOR SET, TAC GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE, V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) (MILITARY DOD MODEL MEP-017A), UTILITY, 60 HZ (NSN 6115-00-017-8240) AND MODEL MEP-022A), UTILITY, 400 HZ (6115-00-017-8241) {NAVFAC P-8-614-14; TO 35C2-3-424-1} 033750 TM 5-6115-585-34 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 10 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP-003A), UT CLASS, 60 HZ (NSN 6115-00-465-1030) {NAVFAC P-8-623-12; TO 35C2-3-455-2; TM-05684C/05685B-34} 034072 TM 5-6115-585-24P 5 GENERATOR SET, DIESEL ENGINE DRIVEN, TA SKID MTD, 10 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 W 120, 120/240 AND 120/208 V (DOD MODELS 003A), UTILITY CLASS, 60 (NSN 6115-00-465-1030) AND (MODEL MEP-112A), UTILITY CLASS, 400 (6115-00-465-1027) {NAVFAC P-8-623-24P; TO 35C2-3-455-4; SL-4-05684C/06585B} 040180 TM 5-6115-584-12-HR HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 WIRE; 1 PH, 3 WIRE; 3 PH, 4 WIRE, 120, 120/240 AND 120/208 V (D MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) 040833 TM 5-6115-458-12-HR HAND RECEIPT MANUAL COVERING THE END ITEM/COMPONENTS OF END ITE BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AA GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 20 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODEL MEP-009A), UT CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND (DOD MODEL MEP-108A) PRECISE CLASS, 50/60 HZ (6115-00-935-8729) 040843 TM 5-6115-593-34 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD, 500 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL, MEP-029A, CLASS UTILITY, 50/60 HZ, (NSN 6115-01-030- DOD MODEL, MEP-029B, CLASS UTILITY, 50/60 HZ, (6115-01-318-6302 INCLUDING OPTIONAL KITS DOD MODEL, MEP-029AHK, HOUSING KIT, (6115-01-070-7550), DOD MODEL, MEP-029ACM, AUTOMATIC CONTROL MO (6115-01-275-7912) DOD MODEL, MEP-029ARC, REMOTE CONTROL MODULE (6110-01-070-7553) DOD MODEL, MEP-029ACC, REMOTE CONTROL CABLE, (6110-01-087-4127) {NAVFAC P-8 041070 TM 5-6115-593-12 GENERATOR SET, ENGINE DRIVEN, TACTICAL SKID MTD, 500 KW, 3 PHASE, 4 WIRE; 120/ 240/416 VOLTS DOD MODEL MEP-029A; CLASS UTILITY, HERTZ 50/60; (NSN 6115-01-030-6085); MEP-029B; UTILITY; 50/60; (6115-01-318- INCLUDING OPTIONAL KTS DOD MODELS MEP-029AHK; NOMENCLATURE HOUS (6115-01-070-7550) MEP-029ACM; AUTOMATIC CONTROL MODULE; (6115-01-275-7912); MEP-029ARC, REMOTE CONTROL MODULE, (6110-01-070-7553); MEP-029ACC, REMOTE CONTROL CABLE (6110-01-087-4127) {TO 35C2-3-463-1} 041338 LO 55-1730-229-12 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU), WHEEL MOUNTED, SELF-PROPELLED, TOWABLE DOD MODEL-MEP-360A, CLASS-PRECISE, HERTZ-400, (NSN 1730-01-144-1897 042791 TM 5-6115-457-12-HR HAND RECEIPT MANUAL COVERING THE BASIC ISSUE ITEMS (BII) FOR GE SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP007A), UTILITY CLASS, 50/6 (NSN 6115-00-133-9101), (MODEL MEP-106A), PRECISE CLASS, 50/60 (6115-00-133-9102) AND (MODEL

MEP116A) PRECISE CLASS, 400 HZ (6115-00-133-9103) 043437 TM 5-6115-593-24P 1
GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 500 KW, 3 PHA 4 WIRE;
120/208 AND 240/416 VOLTS DOD MODEL MEP-029A UTILITY CL 50/60 HZ (NSN
6115-01-030-6085) MEP-029B UTILITY CLASS, 50/60 (6115-01-318-6302) INCLUDING OPTIONAL
KITS DOD MODEL MEP-029AHK HOUSING KIT (6115-01-070-7550) MEP-029ACM AUTOMATIC
CONTROL MOD (6115-01-275-7912) MEP-029ARC REMOTE CONTROL MODULE
(6110-01-070-7553) MEP-029ACC REMOTE CONTROL CABLE (6110-01-087 {NAVFAC P-8-631-24P;
TO 35C2-3-463-4} 044703 TM 5-6115-545-12-HR HAND RECEIPT MANUAL COVERING
COMPONENTS OF END ITEM (COEI), BAS ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST
(AAL) FOR GENERA DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 60 KW, 3 PHASE, 4 WIRE
120/208 AND 240/416 V (DOD MODELS MEP-006A) UTILITY CLASS, 50/6 (NSN 6115-00-118-1243),
(MODEL MEP-105A) PRECISE CLASS, 50/60 H (6115-00-118-1252) AND (MODEL MEP-115A)
PRECISE CLASS, 400 HZ (6115-00-118-1253) 050998 TM 5-6115-600-12 8 GENERATOR DIESEL
ENGINE DRIVEN, TACTICAL SKID MTD, 100 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 V (DOD
MODEL MEP-007B) CLASS UTILITY, 50/60 (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS,
DOD MODEL MEP00 WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION
KIT ELECTRIC 051007 TM 5-6115-600-24P 4 GENERATOR SET, DIESEL ENGINE DRIVEN, 100 KW,
3 PHASE, 4 WIRE, 120/208 AND VOLTS (DOD MODEL MEP-007B), UTILITY CLASS, 50/60 HZ (NSN
6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP007BWF, WINTERIZATION
KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT, ELECTRIC {TO 35C2-3-442-14;
NAVFAC P-8-628-24P; SL-4-07464B} 057268 LO 5-6115-600-12 GENERATOR SET, DIESEL ENGINE
DRIVEN; TACTICAL, SKID MTD, 100 KW PHASE, 4 WIRE; 120/208 AND 240/416 V (DOD MODEL
MEP007B), CLASS UTILITY, 50/60 HZ (NSN 6115-01-036-6374) 057513 LO 5-6115-604-12
GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE; SKID MT 750 KW, 3 PHASE,
4 WIRE; 2400/4160 AND 2200/3800 VOLTS (DOD MOD MEP208A) CLASS PRIME UTILITY, HZ
50/60 (NSN 6115-00-450-5881) {LI 6115-12/9} 060183 TM 5-6115-612-24P 6 GENERATOR SET,
AVIATION, GAS TURBINE ENGINE DRIVEN, INTEGRA TRAILER MOUNTED, 10KW, 28 VOLTS
MODEL MEP-362A, PRECISE, DC (NSN 6115-01-161-3992) {TM 6115-24P/1; AG-320B0-IPE-000; TO
35C2-3-471-4} 060188 TM 5-6115-612-34 4 GENERATOR SET, AVIATION, GAS TURBINE ENG
DRIVEN, INTEGRAL TRAILER MOUNTED 10KW 28 VOLTS DOD MODEL MEP 36 PRECISE, DC,
(NSN 6115-01-161-3992) {AG-320BO-MME-000; TM 6115- TO 35C2-3-471-2} 060645 LO
5-6115-612-12 AVIATION GENERATOR SET, GAS TURBINE, ENGINE DRIVEN, INTEGRAL TR
MOUNTED, 10KW, 28 VOLTS DC DOD MODEL MEP 362A CLASS PRECISE (NSN
6115-01-161-3992) 060921 TM 55-1730-229-34 5 POWER UNIT, AVIATION, MULTI-OUTPUT GTED,
ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWA
AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28VDC 700 AMPS, PNEUMATIC, 60 LBS/MIN. AT 40
PSIG, HYDRAULIC, 15 GPM AT 3300 PS DOD MODEL MEP-360A, CLASS PRECISE, 400 HERTZ,
(NSN 1730-01-144- {AG 320A0-MME-000; TO 35C2-3-473-2; TM 1730-34/1} 060922 TM
55-1730-229-12 8 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC,
PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWABLE, AC 400HZ, 3PH, 0.8 PF,
115/200V, 30 KW, DC 28 VDC 700 AMPS, PNEUMATIC 60 LBS/M AT 40 PSIG, HYDRAULIC 15 GPM
AT 3300 PSIG, DOD MODEL MEP-360A, CLASS PRECISE, HERTZ 400, (NSN 1730-01-144-1897)
{AG 320A0-OMM-000; TO 35C2-3-473-1; TM 1730-12/1} 061758 LO 5-6115-614-12 GENERATOR
SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD. 200 KW, 3 PHASE, 4 WIRE, 120/208 AND
240/416 VOLTS MODEL MEP009B, UTILI 50/60 HERTZ, (NSN 6115-01-021-4096) 061772 LO
5-6115-622-12 GENERATOR SET, DIESEL ENGINE-DRIVEN, WHEEL MOUNTED 750-KW, 3-PH
4-WIRE, 2200/3800 AND 2400/4160 VOLTS CUMMINS ENGINE COMPANY IN MODEL
KTA-2300G-2 DOD MODEL MEP-012A; CLASS UTILITY; HERTZ 062762 LO 5-6115-615-12
GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 3 K MODEL 016B;
CLASS UTILITY MODE 50/60 HZ (NSN 6115-01-150-4140); DOD MODEL MEP-021B; CLASS
UTILITY; MODE 400 HZ (6115-01-151-812 DOD MODEL MEP-026B; CLASS UTILITY; MODE 28

VDC (6115-01-150-036 {LI 05926B/06509B-12/5; P-8-646-LO} 064310 TM 5-6115-626-14&P 2 POWER UNIT PU-406B/M (NSN 6115-00-394-9576) MEP-005A 30 KW 60 HZ GENERATOR SET M200A1 2-WHEEL4-TIRE, MODIFIED TRAILER 064390 TM 5-6115-632-14&P 5 POWER UNIT PU-753/M (NSN 6115-00-033-1 MEP-003A 10 KW 60 HZ GENERATOR SET M116A2 2-WHEEL, 2-TIRE, MODI TRAILER 064392 TM 5-6115-629-14&P 3 POWER PLANT AN/AMJQ-12A (NSN 6115-00-257-1602) (2) MEP-006A 60HZ, GENERATOR SETS (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAIL 064443 TM 5-6115-625-14&P 2 POWER UNIT PU-405A/M (NSN 6115-00-394-9577) MEP-004A 15 KW 60 HZ GENERATOR SET M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER (THIS ITEM IS INCLUDED ON EM 0086 & EM 0087) 064445 TM 5-6115-633-14&P 4 POWER PLANT AN/MJQ-18 (NSN 6115-00-033-1398) (2) MEP-003A 1 60 HZ GENERATOR SETS M103A3 2-WHEEL 1 1/2 TON MODIFIED TRAILER 064446 TM 5-6115-628-14&P 4 POWER PLANT AN/MJQ-15 (NSN 6115-00-400-7591) (2) MEP-113A 1 400 HZ GENERATOR SETS, (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRA (THIS ITEM IS INCLUDED ON EM 0086) 064542 TM 5-6115-631-14&P 4 POWER PLANT AN/MJQ-16 (NSN 61 15-00-033-1395) (2) MEP-002A 5 KW 60 HZ GENERATOR SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAI 065071 TM 55-1730-229-24P 6 POWER AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDAULIC, PNEUMATIC (AG WHEEL MOUNTED, SELF-PROPELLED, TOWABLE AC 400 HZ, 3 PH, 0.8 PF, 115/200V, 30 KW DC 28 VDC 700 AMPS PNEUMATIC 60 LBS/MIN. AT 40 HYDRAULIC 15 GPM AT 3300 PSIG DOD MODEL MEP-360A, CLASS PRECISE 400 HERTZ (NSN 1730-01-144-1897) {TO 35C2-3-473-4; TM 1730-24P/ AG 320A0-IPB-000} 065603 TB 5-6115-593-24 WARRANTY PROGRAM FOR GENERATOR SET DOD MODEL MEP-029A HOUSING K DOD MODEL MEP-029AHK 066727 TM 5-6115-640-14&P 2 POWER AN/MJQ-32 (NSN 6115-01-280-2300) AN/MJQ-33 (6115-01-280-2301) (MEP-701A 3KW 60 HZ ACOUSTIC SUPPRESSION KIT GENERATOR SETS M116 2-WHEEL, 2-TIRE, 3/4-TON MODIFIED TRAILERS 066808 TM 5-6115-627-14&P 2 POWER PLANT AN/MJQ-10A (NSN 6115-00-394-9582); (2) MEP-005A 30 KW 60 HZ GEN SETS; (2) M200A1 2-WHEEL, 4 TIRE MODIFIED TRAILERS 066809 TM 5-6115-630-14&P 4 POWER UNIT, PU-751/M (NSN 6115-00-033-1373) MEP-002A, 5 KW, 60 HZ GENERATOR SET M116A1 2-WHEEL, 2-TIRE, MODIFIED TRAILER 066824 TM 5-6115-465-10-HR 1 HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS, (BII) AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 30K 4 WIRE, 120/208 AND 240/416 VOLTS - MEP-005A, UTILITY, 50/60 HE (NSN 6115-00-118-1240); MEP-104A, PRECISE, 50/60 HERTZ, (6115-00-118-1247): MEP-114A, PRECISE, 400 HERTZ, (6115-00-118- INCLUDING AUXILIARY EQUIPMENT MEP-005AWF WINTERIZATION KIT, FUE BURNING (6115-00-463-9083); MEP-005AWE, WINTERIZATION KIT, ELEC (6115-00 067310 TM 9-6115-650-14&P 1 POWER PLAN AN/MJQ-25 (NSN 6115-01-153-7742) (2) MEP-112A 10 KW 400 HZ GENE SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAILER 067311 TM 9-6115-653-14&P 2 POWER UNIT PU-732/M (NSN 6115-00-260-3082) MEP-113A 15 KW 400 HZ GENERATOR SET M200 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067544 TM 9-6115-652-14&P 1 POWER UNIT PU-760/M (NSN 6115-00-394-9581) MEP-114A 30 KW 400 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067632 TM 9-6115-648-14&P POWER UNIT PU-650B/G (NSN 6115-00-258-1622) MEP-006A 60 KW 60 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067744 TM 9-6115-646-14&P 1 POWER UNIT PU-495A/G, (NSN 6115-00-394-9575) AND PU-495B/G, (6115-01-134-0 MEP-007A 100 KW, 60 HZ OR MEP-007B, 100 KW, 60 HZ GENERATOR SET M353-2-WHEEL, 2-TIRE MODIFIED TRAILER 067746 TM 9-6115-651-14&P POWER UNIT 707A/M (NSN 6115-00-394-9573) MEP-115A, 60 KW, 400 HZ GENERATOR M200A1, 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067879 TM 9-6115-647-14&P 1 POWER UNIT PU-789/M (NSN 6115-01-208-9827) MEP-114A, 30 KW 400 HZ GENERATOR SET M353 2-WHEEL, 2-TIRE, MODIFIED TRAILER 069601 TM 9-6115-464-10-HR HAND RECEIPT MANUAL COVERING THE END ITEMS/COMPONENTS OF END IT (COEI), BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION L (AAL) FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MO 15 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD

MODEL MEP UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP PRECISE CLASS, 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113 PRECISE CLASS, 400 HERTZ (6115-00-118-1244) 069602 LO 9-6115-464-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD, 15KW, 4 WIRE, 120/208 AND 240/416 VOLTS (DOD MODEL MEP 004A) (NSN 6115-00-118-1241); (DOD MODEL MEP 104A) (6115-00-118-1245) (DOD MODEL MEP-113A) (6115-00-118-1244) 069954 TM 9-6115-465-24P 2 GENERATOR SET, DIESEL ENGINE DRIVE TACTICAL SKID MTD. 30KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V MODELS; MEP-005A, UTILITY, 50/60 HZ, (NSN 6115-00-118-1240), MEP-104A PRECISE, 50/60 HZ, (6115-00-118-1247), MEP-114A, PRECISE, 400 H (6115-00-118-1248), INCLUDING OPTIONAL KITS, DOD MODELS; MEP-00 WINTERIZATION KIT, FUEL BURNING, (6115-00-463-9083), MEP-005-AW WINTERIZATION KIT, ELECTRIC, (6115-00-463-9085), MEP-002-ALM, L BANK KIT, (6115-00-463-9088), MEP-005-AWM, WHEEL MOUNTING KIT, (6115-00-463-9094) {TO-35C2-3-070096 TM 9-6115-464-24P 1 GENERATOR S DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS (DOD MODEL MEP-004A) UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) (DOD MODEL MEP-103A) PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) (DOD MODEL MEP-113A) PRECI CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS (DOD MODEL MEP-005-AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (DOD MODEL MEP-005-AWE) WINTERIZATION KIT, ELECTRIC (6615-00-46 (DOD MODEL MEP-004-ALM) LOAD BANK KIT (6115-00-191-9201 071025 TM 9-6115-641-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-11} 071026 TM 9-6115-642-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIE 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-11; TM 09247A/09248A-10/1} 071028 TM 9-6115-643-10 3 GENERATOR SET, SKID MOUNTED, TACTICAL QUI 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-73 MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-21} 071029 TM 9-6115-644-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ), (NSN 6115-01-274-7389) MEP-815A (400 HZ), (6115-01-274-7394) {TO 35C2-3-446-11; TM 09249A/09246A-10/1} 071030 TM 9-6115-645-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ), (NSN 6115-01-274-7390) MEP-816A (400 HZ), (6115-01-274-7395) {TO 35C2-3-444-11; TM 09244A/09245A-10/1} 071031 LO 9-6115-641-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A TACTICAL QUIET 60 HZ (NSN 6115-01-274-7387) MEP-812A TACTICAL QUIET 400 HZ (6115-01-274-7391) 071032 LO 9-6115-642-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 H MEP-803A TACTICAL QUIET 60 HZ (NSN 6115-01-275-5061) MEP-813A TACTICAL QUIET 400 HZ (6115-01-274-7392) 071033 LO 9-6115-643-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60/400 HZ MEP-804A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7388) MEP-814 TACTICAL QUIET 400 HZ (6115-01-274-7393) 071034 LO 9-6115-644-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 40 MEP-805A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7389) MEP-815 TACTICAL QUIET 400 HZ (6115-01-274-7394) {LI 09249A/09246A-12} 071035 LO 9-6115-645-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 40 MEP-806A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7390) MEP-816 TACTICAL QUIET 400 HZ (6115-01-274-7395) {LI 09244A/09245A-12} 071036 TB 9-6115-641-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A AND MEP-812A 071037 TB 9-6115-642-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A AND MEP-813A {SI 09247A/09248A-24} 071038 TB 9-6115-643-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A AND MEP-814A 071039 TB 9-6115-644-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A AND MEP-815A {SI 09249A/09246A-24} 071040 TB 9-6115-645-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A AND

MEP-816A {SI 09244A/09245A-24} 071541 TM 9-6115-464-12 2 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 15 KW, 3 PHASE, 4 WIRE, 120/2 AND 240/416 VOLTS DOD MODEL MED-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP-103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005-AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005-AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004-ALM LOAD BANK KIT (6115-00-291 071604 TM 9-6115-645-24P GENERATOR SET, TACTICAL QUIET 60KW, 50/60/400 HZ (NSN 6115-01-274-7390) (MEP-806A) (6115-01-274-7395) (MEP-816A) {TO 35C2-3-444-14; TM 09244A/09245A-24P/3} 071605 TM 9-6115-642-24P GENERATOR SET, TACTICAL QUIET 10 KW, 60/400 HZ (NSN 6115-01-275-5061) (MEP-803A) (6115-01-274-7392) (MEP-813A) {TO 35C2-3-455-14; TM 09247A/09248A-24P/3} 071610 TM 9-6115-643-24P GENERATOR SET, TACTICAL QUIET 15KW, 50/60 - 400 HZ (NSN 6115-01-274-7388) (MEP-804A) (6115-01-274-7393) (MEP-814A) {TO 35C2-3-445-24} 071611 TM 9-6115-644-24P GENERATOR SET, TACTICAL QUIET 30KW, 50/60-400 HZ (NSN 6115-01-274-7389) (MEP-805A) (6115-01-274-7394) (MEP-815A) {TO 35C2-3-446-14; TM 09249A/09246A-24P/3} 071613 TM 9-6115-641-24P GENERATOR SET, TACTICAL QUIET 5 KW, 60/400 HZ (NSN 6115-01-274-7387) (MEP-802A) (6115-01-274-7391) (MEP-812A) {TO 35C2-3-456-14} 071713 TM 9-6115-645-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ) (NSN 6115-01-274-7390) MEP-816A (400 HZ) (6115-01-274-7395) {TO 35C2-3-444-12; TM 09244A/09245A-24/2} 071748 TM 9-6115-644-24 1 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ) (NSN 6115-01-274-7389) MEP-815A (400 HZ) (6115-01-274-7394) {TO 35C2-3-446-12; TM 09249A/09246A-24/2} 071749 TM 9-6115-643-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-7388) MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-22} 071750 TM 9-6115-642-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-12; TM 09247A/09248A-24/2} 071751 TM 9-6115-641-24 3 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-12} 072239 TM 9-6115-464-34 1 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS DOD MODEL MEP-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP 103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005AWE WINTERIZAT KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004ALM LOAD BANK KIT (6115-00-291-920 073744 TM 9-6115-604-24P 1 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MOUNTED, 750KW, 3 PHASE, 4 WIRE, 2400/4160, AND 2200/3800 VOLTS DOD MODEL MEP208A PRIME UTILITY CLASS 50/60 HERTS (NSN 6115-00-450-5881) DOD MODEL 80-1466 REMOTE CONTROL MODULE CLASS (6115-01-150-5284 DOD MODEL 80-7320 SITE REQUIREMENTS MODULE CLASS (6115-01-150-5 {NAVFAC P-8-633-24P} 074040 TM 9-6115-545-24P GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, D MODELS MEP-006A, UTILITY CLASS, 50/60 H/Z, (NSN 6115-00-118-124 MEP-105A, PRECISE CLASS, 50/60 H/Z, (6115-00-118-1252), MEP-115 PRECISE CLASS, 400 H/Z (6115-00-118-1253); INCLUDING OPTIONAL K DOD MODELS MEP-006AWF, WINTERIZATION FUEL BURNING, (6115-00-407 MEP-006AWE, WINTERIZATION KIT, ELECTRIC, (6115-00-455-7693), ME LOAD BANK KIT, (6115-00-407-8322), AND MEP-006AWM, WHEEL MOUNTI (6115-00-463-9092) {TO 074212 TM 9-6115-604-12 GENERATOR SET, DIESEL DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 24 AND 2200/3800 V (DOD MODEL MEP 208A) CLASS PRIME UTILITY, HZ 50 (NSN 6115-00-450-5881) {NAVFAC P-8-633-12} 074896 TM 9-6115-604-34 GENERATOR SET,

DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 2400/4160 AND 2200/3800 VOLTS DOD MODEL MEP 208A PRIME UTILITY CLASS 50/60 HERTZ (NSN 6115-00-450-5881) {NAVFAC P-8-633-34} 075027 TM 9-6115-584-24P 1 GENERATOR SET, DIESEL E DRIVEN, TACTICAL SKID MTD 5 KW, 1 PHASE -2 WIRE, 1 PHASE -3 WIR 3 PHASE -4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP- UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-24P TO 35C2-3-456-4} 077581 TM 9-6115-673-13&P 2KW MILITARY TACTICAL GENERATOR SET 120 VAC, 60 HZ (NSN 6115-01-435-1565) (MEP-531A) (EIC: LKA) (NSN 6115-21-912-0393) (MECHRON) 28 VDC (NSN 6115-01-435-1567) (MEP-501A) (EIC: LKD) (NSN 6115-21-912-0392) (MECHRON) 078167 TM 9-6115-672-14 GENERATOR SET SKID MOUNTED TACTICAL QUIET 60KW, 50/60 AND 400 HZ, MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) EIC: GGW, MEP-816B (400 HZ) (NSN 6115-01-462-0292) EIC: GGX 078443 TM 9-6115-639-13 1 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 078490 TM 9-6115-671-14 OPERATOR, UNIT, GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ, MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (6115-01-462-0290) (EIC: GGV) 078503 TM 9-6115-671-24P GENERATOR SET SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (NSN 6115-01-462-0290) (EIC: GGV) 078504 TM 9-6115-672-24P GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) (EIC: GGW) MEP-816B (400 HZ) (NSN 6115-01-462-0292) (EIC: GGX) 078505 TB 9-6115-671-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-805B AND MEP-815B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078506 TB 9-6115-672-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-806B AND MEP-816B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078523 TM 9-6115-664-13&P 5KW, 28VDC, AUXILIARY POWER UNIT (APU) MEP 952B NSN 6115-01-452-6513 (EIC: N/A) 078878 TM 9-6115-639-23P 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 079379 TB 9-6115-641-13 WINTERIZATION KIT (NSN 6115-01-476-8973) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 5KW, 60 AND 400 HZ MEP-802A (600HZ) (6115-01-274-7387) MEP-812A (400HZ) (6115-01-274-7391) 079460 TB 9-6115-642-13 WINTERIZATION KIT (NSN 6115-01-477-0564) (EIC: N/A) INSTALLED ON GENERATOR KIT, SKID MOUNTED, TACTICAL QUIET, 10KW, 60 AND 400 HZ MEP-803A (60HZ) (6115-01-275-0561) MEP-813A (400HZ) (6115-01-274-7392) 079461 TB 9-6115-643-13 WINTERIZATION KIT (NSN 6115-477-0566) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 15KW, 50/60 AND 400 HZ, MEP-804A (50/60HZ) (6115-01-274-7388) MEP-814A (400HZ) (6115-01-274-7393) 079462 TB 9-6115-644-13 WINTERIZATION KIT (NSN 6115-01-474-8354) (EIC:N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, 30KW, 50/60 AND 400 HZ MEP-805A (50/60HZ) (NSN 6115-01-274-7389) MEP-815A (400HZ) (NSN 611501-274-7394) 079463 TB 9-6115-645-13 WINTERIZATION KIT (NSN 6115-01-474-8344) (EIC: N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 60KW, 50/60 AND 400 HZ, MEP-806A (50/60HZ) (6115-01-274-7390) MEP-816A (400HZ) (6115-01-274-7395) 080214 TM 9-6115-670-14&P AUXILIARY POWER UNIT, 20KW, 120/240 VAC, 60 HZ, MODEL NO. MEP-903A(SICPS) NSN 6115-01-431-3062 MODEL NUMBER MEP-903B (JTACS) NSN 6115-01-431-3063 MODEL NO MEP-903C9WIN-T) NSN 6115-01-458-5329 (EIC: N/A)

alternator to battery wiring diagram: Master EFI Tuner - GM EFI Dan Maslic, 2009-12
Master EFI Tuner - GM EFI is a comprehensive instructional book that provides the reader with a working knowledge of late-model General Motors LS-series V8 engines as well as a tuning process so that the reader can tune the EFI system on race cars powered by GM LS V8 engines. A complete tuning process is outlined and real world case studies are provided to allow the reader to understand the real-world application of the tuning process.

alternator to battery wiring diagram: The Hack Mechanic Guide to European

Automotive Electrical Systems Rob Siegel, 2016-06-27 Electrical issues in European cars can be intimidating. The Hack Mechanic Guide to European Automotive Electrical Systems shows you how to think about electricity in your car and then take on real-world electrical problems. The principles discussed can be applied to most conventional internal-combustion-engined vehicles, with a focus on European cars spanning the past six decades. Drawing on The Hack Mechanic's wisdom and experience, the 38 chapters cover key electrical topics such as battery, starter, alternator, ignition, circuits, and relays. Through a practical and informal approach featuring hundreds of full-color illustrations, author Rob Siegel takes the fear-factor out of projects like making wire repairs, measuring voltage drops, or figuring out if you have a bad fuel pump relay. Essential tools such as multimeters (DVOM), oscilloscopes, and scan tools are discussed, with special attention given to the automotive multimeter needed to troubleshoot many modern sensors. You'll get step-by-step troubleshooting procedures ranging from safely jump starting a battery to diagnosing parasitic current drain and vehicle energy diagnosis. And you'll find detailed testing procedures for most problematic electrical components on your European car such as oxygen sensors, crankshaft and camshaft sensors, wheel speed sensors, fuel pumps, solenoids, and actuators. Reading wiring diagrams and decoding the German DIN standard are also covered. Whether you are a DIY mechanic or a professional technician, The Hack Mechanic Guide to European Automotive Electrical Systems will increase your confidence in tackling automotive electrical problem-solving. This book applies to gasoline and diesel powered internal combustion engine vehicles. Not intended for hybrid or electric vehicles.

alternator to battery wiring diagram: Operator's, organizational, direct support and general support maintenance manual (including repair parts information and supplemental maintenance and repair parts instructions) , 1984

Additional Resources

[What Alternator Fits My Car? - Alternators Near Me - AutoZone](#)

Find an alternator that fits your car and delivers the same performance as original equipment, or better. We carry long lasting replacements, like Duralast Gold alternators that come with a ...

[Alternator - Wikipedia](#)

An alternator (or synchronous generator) is an electrical generator that converts mechanical energy to electrical energy in the form of alternating current. [2] For reasons of cost and simplicity, most ...

The Signs of a Bad Alternator | O'Reilly Auto Parts

The alternator on your vehicle is a generator that produces direct current (DC) voltage which is used to keep your battery charged and your electrical system working properly. But when your ...

[Alternator, how it works, symptoms, testing, problems, replacement](#)

May 9, 2022 · What is an alternator in a car, alternator problems, symptoms, testing. Replacement vs. rebuilding, tips to prevent alternator problems

What Is a Car Alternator and How Does It Work?

Mar 4, 2025 · Your car's alternator generates electricity by converting mechanical energy from the engine into electrical energy. When the engine runs, it spins a belt connected to the alternator, ...

[Car Alternators & Starters for Sale | NAPA - NAPA Auto Parts](#)

Alternators for cars, which are essentially small generators, are a crucial piece of the electrical system. They maintain the charge on your vehicle's

battery by feeding it a regulated current of ...

Alternator: What is it? (And The Types of Alternators) - Electrical4U

Feb 24, 2012 · An alternator is defined as a machine which converts mechanical energy to electrical energy in the form of alternating current (at a specific voltage and frequency). Alternators are ...

Alternator - O'Reilly Auto Parts

Shop for the best Alternator for your vehicle, and you can place your order online and pick up for free at your local O'Reilly Auto Parts.

Car Alternator Cost - Cheap Price OEM, Rebuilt Alternators

If your battery goes dead the first thing you need to do is check your alternator to ensure the charging system hasn't failed. Get your OEM quality replacement alternator at Parts Geek from ...

How Much Does an Alternator Replacement Cost? - AutoZone

Some car repairs are minor, costing under \$50 while major repairs can be thousands of dollars. An alternator is on the lower end of the scale and, depending on several factors, the cost to replace ...

Troubleshooting Leece-Neville Alternators - Fore Forums

Step 1. Check the Battery Condition A. Before beginning the battery test, make sure that the batteries are 95% - 100% charged. Use a battery charger, if necessary. B. Shut off all electrical ...

ALTERNATOR INSTALLATION AND OPERATION MANUAL

Battery cable size must meet the increased output capacity of your new alternator. The easiest method for determining the best cable size for your system is to compare your new alternator's ...

Supplement to Yanmar Kit Installation Instructions SAFETY

See engine wiring harness diagram and schematics shown on page 3 and 4 of this document. YANMAR CO., LTD. ... W27 RED 8 AWG 30.0 N/A HDL-8-14 N/A N/A HDL-6-38 N/A ...

im iin e0301en-GB11 - Scania

Battery capacity at +20 °C Battery capacity at -18°C 100% 50% 70% 35% 40% 25% Connection of batteries Connect the battery cables correctly, i.e. negative (-) to the engine ground point and ...

HILUX Electrical Wiring Diagram - Tuning Concepts

[E] : Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows (). Outside numerals are pin numbers. Female Male () The first ...

OWNER'S MANUAL FOR MINN KOTA ONBOARD DC ...

ONBOARD DC ALTERNATOR BATTERY CHARGERS Models: MK-1-DC, MK-2-DC, MK-3-DC Service Information: Please call our service department ... See diagram to the right. If the purple ignition ...

Ford Transit Battery Wiring Instructions - Tommy Gate

Figure 2: Generic battery wiring diagram. Refer to vehicle specific mounting instructions for detailed diagram. Pump and Motor Common Ground ... For 2015-2019, see Ford Bulletin Q-226R2 and do ...

OVERALL ELECTRICAL WIRING DIAGRAM - Toyota Nation ...

OVERALL ELECTRICAL WIRING DIAGRAM 1 2 34 1 4RUNNER ELECTRICAL WIRING DIAGRAM 3 ACC IG1AM1 1 ST1 IG2 6 7 8AM2 1 2 5 3 22 2 IGNITION SW 22 2 2 2 22 5 6 ...

BATTERY To Engine ...

12-Volt Alternator Installation & Operation Manual - Balmar

Feb 12, 2016 · Disconnect the wiring from the existing alternator. 2. Loosen the mounting & tensioning bolts and remove the existing alternator. 3. Once the alternator is disconnected from ...

OVERALL WIRING DIAGRAM 1-3 FLOOR AND ROOF ...

OVERALL WIRING DIAGRAM M3010000100233 NOTE: . 1. This illustration shows only major wiring harnesses. 2. *: also equipped at the right side. AC211751AB Battery wiring harness Front wiring ...

3G Ford Alternator Installation - PA Performance

Disconnect the Battery (-) wire from the battery. 2. Locate the existing alternator. Loosen the top and bottom mounting bolts. 3. Remove the belt. 4. Locate any wires on the rear of the unit and ...

MASSEY FERGUSON 35/135 TRACTOR WIRING DIAGRAM

motor failure is battery leads which are too light. Use 50mm braided cable. Fix earth cable lug to 7/16 bolt on bell housing. 2 Accessories Lights Horn Pilot light 1 Power 4 Starter Solenoid 3 Glow ...

Delco-Remy CS-130 Type Alternator Service Manual - Diesel ...

E. Measure voltage across battery. If above 16.0, replace or repair alternator. NOTICE: The alternator may be O.K. on vehicles using "S" terminal if "S" terminal wiring has excessive ...

OEM OR 1-WIRE CS130 ALTERNATOR INSTALLATION ...

wiring harness and simplifies installation by using only one wire for charging. WIRING THE ALTERNATOR When using with OEM wiring, reconnect the factory wiring to the alternator. If ...

1967 Cougar Charging System - Mercury Cougar Owners

Title: 1967 Cougar Charging System Author: coachJack Subject: Covering both Indicator light and Ammeter systems Created Date: 4/22/2021 8:13:19 AM

9600 Series Battery Disconnect Switch Installation Instructions

Alternator Field Disconnect Terminals F1 & F2 See Diagram #2 DIAGRAM #1 Battery Engine Ground DIAGRAM #2 ALTERNATOR FIELD DISCONNECT you to lead). For more information go to A. Use ...

WIRING DIAGRAM INDEX, 12V - Mack Trucks

key sw. , start & charging wiring diagram: ac - o f7b-0.8 battery + g01 battery s036b switch, push button start a b spf7d aa:0 a frcl_p1 key sw crank starter ign rh oper a17 control unit, vecu ...

Diesel 6.7L Power Stroke - Ford Powerstroke Diesel Forum

Inspect wiring, terminals and connectors. 3. Inspect the FEAD system. REFER to 303-05. 4. Check the battery condition and state of charge. REFER to: Battery (414-01 Battery, Mounting and ...

WIRING INSTRUCTIONS - Powermaster Motorsports

Disconnect Battery Negative (-) READ ALL INSTRUCTIONS IN BOX! Charge Wires: 170 Amp Alt. use 4 gauge up to 6 ft. 200 Amp Alt. use 4 gauge up to 6 ft. Alternator Ground: Many mounting ...

Multi-Battery Isolator InstallationGuide

1. If circuit breaker is going to be used, it should be installed near the

Aux. Battery and on the Aux. Load. NO circuit breaker isto be installed from alternator to isolator orfrom isolator to main ...

WIRING INSTRUCTIONS Ford 2G Alternator - Powermaster ...

Never disconnectthe battery with enginerunning! ... WIRING INSTRUCTIONS Ford 2G Alternator (OE Hookup Only) Tech Dept. (630) 957-4019
Tech@powermasterperformance.com DO NOT ...

33SI, 34SI, 35SI & 36SI ALTERNATOR INSTALLATION ...

battery (+) terminal on the alternator to lower the output voltage for 34SI, 35SI & 36SI alternators. If necessary, use an 18 AWG ... TYPICAL WIRING
DIAGRAM LOWER OUTPUT VOLTAGE: VOLTAGE ...

Wiring a Split Charge Relay - Midsummer Energy

both battery banks and the alternator share a common negative connection. If not, run substantial cables to connect the negatives. Existing wiring not shown for clarity. + - + - To fit a split charge ...

Application & Installation Guide Starting and Charging Systems

Ambient temperatures drastically affect battery performance and charging efficiencies. Maintain 21°C (70°F) temperature to assure rated output. Battery temperature should not exceed 52°C ...

Wiring Diagrams & Harnesses for Ford Tractors

Wiring Diagram . POINTS COIL 12V DASH PANEL AMMETER TERMINAL BLOCK 4- KEY SWITCH STARTER BUTTON CHAS'S GRD STRAP SINGLE WIRE ALTERNATOR \ 1952 . Title: Wiring ...

RV-7 Electrical System

Sep 23, 2007 · the bus voltage and pull in the aux battery charging relay only when the engine is not being cranked (to avoid taxing the aux battery) and when bus voltage is greater than 13V ...

NEGATIVE EARTH DYNALITE - powerlite-units.com

diagram). A wiring diagram for the vehicle will aid identifying the wires. 3. Disconnect the earth from the control box. 4. Remove field lead (F) and warning light from regulator (Small wire at D ...

24 -Volt Alternator Installation & Operation Manual ...

(tach) wire if needed and other necessary wiring. Connect alternator to Balmar regulator wiring harness as indicated in wiring diagram included on Page 12. The alternator's positive and ground ...

12-Volt Positive Ground Installation Instructions - Speedway ...

1. Attach the Ignitor black wire to the negative terminal of the battery.
5. Attach the red lead from the voltmeter to the battery positive terminal.
6. The voltmeter should read battery voltage once ...

C.E. Niehoff & Co. N1225 / N1237 / N1505 Alternators - Gear ...

Figure 2 - N1505-1/N1237-1/N1225-1 Alternators with N3135 Regulator Wiring Diagram Figure 1 - N1505-1/N1237-1/N1225-1 Alternators and N3135 Regulator Terminals ... Shut off engine. With ...

Dual Battery Isolator Wiring Diagram - RV Super Centre

1. Easy 3 wire connection at the battery. No need to bypass existing alternator wiring . 4. Ignition protected . 5. Manual Remote Model . Summary . The battery isolator allows two batteries to be ...

24 -Volt Alternator Installation & Operation Manual ...

Feb 24, 2016 · (tach) wire if needed and other necessary wiring. Connect alternator to Balmar regulator wiring harness as indicated in wiring diagram included on Page 12. The alternator's ...

Wires Used for Lithium Systems - Nations Starter & Alternator

Connect to alternator side of fuse assembly with #6 (recommend inline fuse 3-5 amps) Wires #12 & #13 (P u r p l e + & G r e y -) Connect to battery shunt - this is crucial to take advantage of the ...

WIRING DIAGRAMS Article Text - Miata Forumz

May 10, 2003 · WIRING DIAGRAMS Article Text 1990 Mazda Miata For Yorba Linda Miata Copyright © 1998 Mitchell Repair Information Company, LLC Saturday, May 10, 2003 11:19AM

12-Volt Alternator Installation & Operation Manual

Disconnect the wiring from the existing alternator. 2. Loosen the mounting & tensioning bolts and remove the existing alternator. 3. Once the alternator is disconnected from the engine, compare ...

im iin e0301en-GB07 - Scania

conditions. The battery master switch must not be switched off before then. Status for post-running is sent out in CAN message DLN7. More information is available in the CAN interface installation ...

Service Manual - Genie

combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach. Be sure that all tools and working areas ... Trailer Lighting Wiring ...

Alternator Identification - Small Engine Suppliers

5 To Battery (battery terminal on solenoid) 6 To Alternator (DC Output) 1. OFF *1 + 3 + 6 2. RUN 2 + 5 + 6 3. START 2 + 4 + 5 5 4 2 3 1-+ ... Typical 16 amp Regulated Alternator Wiring Diagram 5 ...

Bosch Alternator Wiring Volvo Penta (PDF)

Battery Cable: A thick, heavy-duty cable connecting the battery to the starter and alternator. Alternator Wiring: The cables connecting the alternator to the battery and other electrical ...

Electrical Wiring Diagram Date : 21-12-2018 PowerKit Engine

Battery charging alternator D+ Electrical Wiring Diagram Date : 21-12-2018 PowerKit Engine - 4M11 Mechanical Governor Page : 1/5 Technoparc du Brégadan - 13260 Cassis / France - Tel. +33 488 ...

12ALTV - Alternator Kit for Willys Jeep

Installation of ALT12V Alternator Kit (Wiring) 1. Vehicle must be negative ground only to utilize this alternator. *Wiring and ammeter must be replaced with 0-100 AMP scale. (Use of original 30 or ...

WIRING DIAGRAMS Article Text - Miata Forumz

May 10, 2003 · WIRING DIAGRAMS Article Text (p. 2) 1993 Mazda Miata ... GROUND A: (NEAR BATTERY) 1 (A 2) GROUND B: (LEFT SIDE OF ENGINE ... Fig. 1: Headlights, Battery, ...

FLEETWOOD - BATTERY CONTROL CENTER - Intellitec

Switched Coach Battery, Coach Battery, Disconnect-Switched Chassis Battery, and Ignition Switched Chassis Battery. The 20 fuses and their size are as listed: Connector LP / CO Det. F1 10 ...

Smart Alternator Setup for the DC2DC-v2-2 - Enerdrive

for smart alternator vehicles 12/24v Start Battery Ignition Link 1.5mm² 16mm² 16mm² 12v House Battery Smart alternator battery sense module (Optional) Battery monitor Shunt Warning!! Fuse ...

13.090 - 1980 CORVETTE WIRING DIAGRAM IN FULL COLOR

With special thanks to the Mitchell 2001 Wiring diagram. 2018-09-19 Peter Ziegler (zzip) corvettev8power@gmail.com . Title: URL : Author: PETER Created Date:

Dual Battery Kit Fitting Instructions - 4WD Supacentre

battery (be careful to keep the wiring away from any moving parts). Cut the cable to length. STEP 7: Repeat the above process to the positive terminal of the auxiliary battery. STEP 8: Strip the un ...

24SI & 28SI ALTERNATOR INSTALLATION INSTRUCTIONS ...

♦ If installing this alternator with Remote Sense™ terminal in a vehicle that does not have a sense line, connect a fused (5 Amp) insulated wire from the Alternator Voltage Sense terminal to the ...

WIRING DIAGRAM INDEX - Mack Trucks

power distribution frc 1/2 wiring diagram: aa spf44a spx03ea3 fb2a1-0.8 ag:0 b a17.b:2 ai:4 c frc_j3:c5 aq:1 b mcsc:a9 f61a1-0.8 hb:2 d a131b.a:4 f15a1-5.0 bi:3 c x210a.a:d f87 15a cust. a b ...

1-Wire Alternator Instructions - Speedway Motors

alternator 'Battery' terminal to the positive terminal on the battery or to the starter solenoid main lug (connects to the ... One wire alternators eliminate the unsightly factory wiring harness and ...

ARGOFET Battery Isolator with alternator energize input

1. Always disconnect the battery minus cables before making alterations to the electrical system. 2. Connect the positive output of the supplying source (alternator) to the input of the battery ...

Alternator To Battery Wiring Diagram

Alternator To Battery Wiring Diagram

Related Articles

- [alternative history of the united states](#)
- [alternatives to estrogen therapy](#)
- [month mcat study plan](#)

[Back to Home](#)