

# 3 wire fuel sending unit wiring diagram

## Decoding the 3-Wire Fuel Sending Unit Wiring Diagram: A Comprehensive Guide

Author: Michael Anderson, Certified Automotive Technician with 20 years of experience in automotive diagnostics and repair.

Publisher: AutoRepairCentral.com – A leading online resource for automotive repair information and DIY guides, trusted by mechanics and hobbyists alike.

Editor: Sarah Chen, Automotive Engineering graduate with 5 years experience in technical writing and editing within the automotive industry.

Keyword: 3-wire fuel sending unit wiring diagram

### Introduction:

Understanding your vehicle's fuel system is crucial for safe and efficient operation. A key component of this system is the fuel sending unit, responsible for accurately reporting the fuel level to your dashboard gauge. While simpler systems use two wires, many modern vehicles employ a 3-wire fuel sending unit wiring diagram, offering enhanced functionality and accuracy. This comprehensive guide will delve into the intricacies of the 3-wire fuel sending unit wiring diagram, explaining its workings, common issues, troubleshooting techniques, and wiring configurations across different vehicle makes and models.

### Understanding the Components of a 3-Wire Fuel Sending Unit

A typical 3-wire fuel sending unit wiring diagram involves three distinct wires:

1. Power Wire: This wire provides the voltage necessary for the sending unit's operation. It's usually connected to a switched power source, meaning it only receives power when the ignition is turned on.

1. Ground Wire: This wire provides a return path for the current,

completing the electrical circuit. It's usually connected to the vehicle's chassis ground.

1. **Signal Wire:** This is the crucial wire that transmits the fuel level information to the instrument cluster. The resistance of this wire changes based on the float's position within the fuel tank, reflecting the amount of fuel present. The gauge interprets this resistance change as a fuel level reading.

### Decoding the 3-Wire Fuel Sending Unit Wiring Diagram: Different Configurations

The exact configuration of a 3-wire fuel sending unit wiring diagram can vary depending on the vehicle manufacturer and the specific fuel gauge system used. However, there are some common patterns:

**Variable Resistance System:** This is the most common type. As the float moves up or down with the fuel level, the resistance in the signal wire changes proportionally. A higher resistance indicates a lower fuel level, and a lower resistance indicates a higher fuel level. The gauge interprets this resistance variation to display the accurate fuel level. Understanding this relationship is key to interpreting any 3-wire fuel sending unit wiring diagram.

**Variable Voltage System:** Some systems utilize a variable voltage approach. The fuel level is represented by a voltage change on the signal wire, not a resistance change. While less common, this system still relies on the basic principles shown in the 3-wire fuel sending unit wiring diagram.

**Ground Switching System:** In this less common setup, the signal wire might be connected to ground through a variable resistor, altering the ground path and consequently the signal reading. Again, a clear 3-wire fuel sending unit wiring diagram is crucial for understanding the specific system.

### Troubleshooting a Malfunctioning Fuel Gauge: Utilizing the 3-Wire Fuel Sending Unit Wiring Diagram

If your fuel gauge is inaccurate or non-functional, troubleshooting can begin by examining the 3-wire fuel sending unit wiring diagram. Common issues include:

**Faulty Sending Unit:** This is the most frequent cause. The float might be stuck, the potentiometer (variable resistor) might be damaged, or there might be corrosion or damage to the internal components.

**Wiring Issues:** Broken, corroded, or loose wires are also common problems. Carefully inspect all three wires for any damage, paying close attention to the connections at the sending unit and the instrument cluster. A visual inspection based on the 3-wire fuel sending unit wiring diagram is the first step.

**Gauge Problems:** In some cases, the fuel gauge itself might be faulty. Testing the gauge using a multimeter can confirm whether it's the source of the problem.

**Ground Issues:** A poor ground connection can disrupt the circuit, resulting in an inaccurate or non-functional gauge. Check the ground wire connection for any corrosion or looseness.

### Testing Procedures based on the 3-Wire Fuel Sending Unit Wiring Diagram

To accurately diagnose problems, use a multimeter to test:

1. **Power Wire:** Check for voltage when the ignition is on.
2. **Ground Wire:** Verify a good ground connection to the vehicle chassis.
3. **Signal Wire:** Measure the resistance at various fuel levels. Compare the readings to the specifications outlined in your vehicle's repair manual or the relevant 3-wire fuel sending unit wiring diagram. This step provides critical information for determining whether the sending unit is the culprit.

### Interpreting the 3-Wire Fuel Sending Unit Wiring Diagram: A Step-by-Step Approach

1. **Locate the Diagram:** Consult your vehicle's repair manual or a reliable online database for the specific 3-wire fuel sending unit wiring diagram for your car's make and model.
1. **Identify the Wires:** Clearly identify the power, ground, and signal wires on the diagram and locate their corresponding connectors.
1. **Trace the Wires:** Follow the wires from the sending unit to the instrument cluster, noting any connectors or splice points along the

way.

1. Check for Continuity: Use a multimeter to test continuity on each wire, ensuring there are no breaks in the circuit.

1. Test Resistance (Signal Wire): Measure the resistance of the signal wire at different fuel levels. Compare your readings to the specifications provided in the repair manual or the 3-wire fuel sending unit wiring diagram.

### Replacement and Installation Using the 3-Wire Fuel Sending Unit Wiring Diagram

Replacing a faulty sending unit requires careful attention to the wiring. Remember to:

1. Disconnect the Battery: Always disconnect the negative battery terminal before starting any electrical work.

1. Carefully Remove the Old Sending Unit: Follow the instructions in your vehicle's repair manual.

1. Install the New Sending Unit: Ensure the new unit is correctly installed and seated.

1. Reconnect the Wires: Using the 3-wire fuel sending unit wiring diagram, carefully reconnect the power, ground, and signal wires. Double-check the connections to avoid errors.

1. Reconnect the Battery: Reconnect the negative battery terminal.

1. Test the Fuel Gauge: Turn the ignition on and check if the fuel gauge is working correctly.

#### Conclusion:

Understanding and interpreting the 3-wire fuel sending unit wiring diagram is essential for effectively troubleshooting and repairing fuel gauge problems. By systematically testing the components and connections based on the diagram, you can pinpoint the issue and restore the accuracy of your fuel gauge. Remember to always consult your vehicle's repair manual for specific instructions and diagrams relevant to your car's model.

#### FAQs:

1. Can I use a 2-wire sending unit to replace a 3-wire one? Generally, no. The 3-wire system offers additional functionality, and a direct replacement would likely not work correctly.
1. What happens if I connect the wires incorrectly? Incorrect wiring could damage the sending unit, the fuel gauge, or even other vehicle components. It's crucial to follow the wiring diagram precisely.
1. How often should I replace my fuel sending unit? There's no set lifespan; failure is usually due to wear and tear, corrosion, or mechanical issues. Replacement is needed only when the unit malfunctions.
1. Can I test the sending unit without removing it from the tank? In some cases, access might allow testing through the filler neck, but removing it is usually necessary for thorough testing.
1. What tools do I need to replace a fuel sending unit? You'll likely need basic tools like screwdrivers, sockets, and a multimeter. Consult your vehicle's repair manual for specific tools needed.

1. My fuel gauge is erratic; is it always the sending unit? No, it could be wiring issues, a faulty gauge, or even a ground problem. Systematic troubleshooting is necessary.
1. Where can I find a replacement fuel sending unit? Auto parts stores, online retailers, and dealerships all sell replacement sending units. Be sure to specify your vehicle's make, model, and year.
1. Can I repair a damaged fuel sending unit? Sometimes minor repairs are possible, but often replacement is more practical and cost-effective.
1. Is it difficult to replace a fuel sending unit myself? The difficulty varies by vehicle. Some are easier than others. Consult a repair manual before attempting the repair.

#### Related Articles:

1. Troubleshooting Common Fuel Gauge Problems: A guide to diagnosing various fuel gauge issues beyond the sending unit.
2. Understanding Automotive Electrical Systems: A general overview of automotive electrical principles, relevant to understanding fuel gauge circuits.
3. How to Test an Automotive Fuel Gauge: Step-by-step instructions on how to test your vehicle's fuel gauge independently.
4. Fuel Tank Removal and Installation Guide: Detailed instructions on removing and reinstalling a fuel tank, often necessary for sending unit replacement.
5. Working with Automotive Wiring Diagrams: A comprehensive guide to interpreting and understanding automotive wiring diagrams.
6. Common Causes of Inaccurate Fuel Readings: An overview of common reasons why your fuel gauge might give inaccurate readings.

7. Choosing the Right Replacement Fuel Sending Unit: Guidance on selecting the correct replacement unit for your vehicle.
8. Safety Precautions When Working on Fuel Systems: Important safety considerations when performing fuel system repairs.
9. Advanced Fuel Injection System Diagnostics: A deeper dive into more complex fuel system diagnostics for those with more advanced knowledge.

**3 wire fuel sending unit wiring diagram: ,**

**3 wire fuel sending unit wiring diagram: Operator, Unit, Direct Support and General Support Maintenance Manual for Generator, Skid Mounted, Tactical Quiet, 30 KW, 50/60 and 400 HZ MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC:GGU), MEP-815B (400 HZ) (NSN 6115-01-462-0290) (EIC:GGV). ,**

**3 wire fuel sending unit wiring diagram: Operator's, Organizational, Direct Support and General Support Maintenance Manual , 1987**

**3 wire fuel sending unit wiring diagram: Advanced Automotive Electricity and Electronics** Michael Klyde, Kirk VanGelder, 2017-06-09 Advanced Automotive Electricity and Electronics, published as part of the CDX Master Automotive Technician Series, gives students with a basic understanding of automotive electrical the additional knowledge and experience they need to diagnose and fix complex electrical systems and circuits. Focused on a "strategy-based diagnostics" approach, this book helps students master technical trouble-shooting in order to address the problem correctly on the first attempt.

**3 wire fuel sending unit wiring diagram: Operator, Organizational, Direct Support, General Support, and Depot Maintenance Manual , 1973**

**3 wire fuel sending unit wiring diagram: Operator, Organizational, Direct Support and General Support Maintenance Manual, Including Repair Parts Information and Supplementary Operating, Maintenance and Repair Parts Instruction for Roller, Vibratory, Self-propelled, (CCE) Model SP-848, NSN 3895-01-075-2823 , 1981**

**3 wire fuel sending unit wiring diagram: Advanced Automotive Electricity and Electronics** Klyde, Kirk Vangelder, 2017-06-12 Advanced Automotive Electricity and Electronics, published as part of the CDX Master Automotive Technician Series, gives students with a basic understanding of automotive electrical the additional knowledge and experience they need to diagnose and fix complex electrical systems and circuits. Focused on a "strategy-based diagnostics" approach, this book helps students master technical trouble-shooting in order to address the problem correctly on the first attempt.

**3 wire fuel sending unit wiring diagram: How to Restore Your Collector Car Tom Brownell, 2009**

**3 wire fuel sending unit wiring diagram: 70+ EH-1 UH-1 Huey Helicopter Technical Manuals, Technical Bulletins, Modification Work Orders & Depot Maintenance Work Requirements Manuals** U.S. Army , Over 15,000 total pages ... Just a SAMPLE of the included manuals dated mid 1970s to the early 2000s: 55 SERIES TECHNICAL MANUALS TM 55-1520-210-10 TM 55-1520-210-CL TM 55-1520-210-PM TM 55-1520-210-PMD TM 55-1520-210-23-1 TM 55-1520-210- 23-2 TM 55- 1520-210-23-3 TM 55-1520-210-23P-1 TM 55-1520-210-23P-2 TM 55-1520-210-23P-3 TM 55-1520-242-MTF UH-1 EH ENGINE RELATED TM 55-2840-229- 23-1 TM 1-2840-260- 23P TM 1-2840-260- 23P 11 SERIES and MISC. TM 11-1520-210-20P TM 11-1520-210-20P-1 TM 11-1520-210-34P TM 11-1520-210-34P-1 TM 11-1520-210-23

TM-1-1500-204-23-1 General Maintenance Practices TM-1-1500-204-23-2 Pneudraulics  
 TM-1-1500-204-23-3 Fuel & Oil Systems TM-1-1500-204-23-4 Electrical & Instruments  
 TM-1-1500-204-23-5 Prop, Rotor and Powertrain TM-1-1500-204-23-6 Hardware and Consumables  
 TM-1-1500-204-23-7 NDT TM-1-1500-204-23-8 Machine & Welding Shops TM-1-1500-204-23-9 Tools  
 and Ground Support TM-1-1500-204-23-10 Sheetmetal TM 38-301-3 Acceptable Oil Analysis Limits  
 TM-55-1615-226-40 Scissors & Sleeve UH-1 Maintenance Test Flight Manual DA PM 738\_751  
 MODIFICATION WORK ORDERS MWO 30-8-5V Lighting MWO 30-45 GS-MB MWO 30-48 Radar Alt  
 AIRCRAFT RELATED TECHNICAL BULLETINS TB 20-17 TB 20-25 TB 20-26 TB 20-32 TB 20-33 TB  
 20-34 TB 20-35 TB 20-36 TB 20-38 TB 20-46 TB 20-47 TB 23-1 TB 30-01 TB TR ENGINE RELATED  
 TECHNICAL BULLETINS TB 20-9 TB 20-10 TB 20-12 TB 20-15 TB 20-16 TB 20-18 TB 20-24 TB  
 20-26 TB 20-27 TB 20-28 TB 229-20-2 + Numerous DEPOT MAINTENANCE WORK REQUIREMENT  
 (DMWR) Manuals

**3 wire fuel sending unit wiring diagram: Technical Manual** United States. War  
 Department, 1944

**3 wire fuel sending unit wiring diagram: Manuals Combined: UH-1 HUEY Army Helicopter  
 Maintenance, Parts & Repair Manuals** , Contains the following current U.S. Army Technical Manuals  
 related to repair and maintenance of the UH-1 Huey series helicopter: (23P-1 Level) AVIATION  
 UNIT AND INTERMEDIATE MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST  
 (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR HELICOPTER,  
 UTILITY - TACTICAL TRANSPORT UH-1B, UH-1C, UH-1H, UH-1M, EH-1H (BELL), UH-1V, 31  
 October 2001, 921 pages - (23P-2 Level) AVIATION UNIT AND INTERMEDIATE MAINTENANCE  
 REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS  
 AND SPECIAL TOOLS) FOR HELICOPTER, UTILITY - TACTICAL TRANSPORT UH-1B, UH-1C,  
 UH-1H, UH-1M, EH-1H (BELL), UH-1V, 23 November 2001, 970 pages - (23P-3 Level) AVIATION UNIT  
 AND INTERMEDIATE MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST (INCLUDING  
 DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS) FOR HELICOPTER, UTILITY -  
 TACTICAL TRANSPORT UH-1B, UH-1C, UH-1H, UH-1M, EH-1H (BELL), UH-1V, 23 November 2001,  
 715 pages - (23-1 Level) AVIATION UNIT AND INTERMEDIATE MAINTENANCE INSTRUCTIONS  
 ARMY MODEL UH-1H/V/EH-1H/X HELICOPTERS, 15 October 2001, 1,176 pages - (23-2 Level)  
 AVIATION UNIT AND INTERMEDIATE MAINTENANCE INSTRUCTIONS ARMY MODEL  
 UH-1H/V/EH-1H/X HELICOPTERS, 1 November 2001, 836 pages - (23-3 Level) AVIATION UNIT  
 AND INTERMEDIATE MAINTENANCE INSTRUCTIONS ARMY MODEL UH-1H/V/EH-1H/X, 14 June  
 1996, 754 pages. UH--1H/V and EH--1H/X Aircraft Preventive Maintenance Daily Inspection  
 Checklist, 27 April 2001, 52 pages - UH-1H/V and EH--1H/X AIRCRAFT PHASED MAINTENANCE  
 CHECKLIST, 2 October 2000, 112 pages.

**3 wire fuel sending unit wiring diagram: Organizational, DS, GS, and Depot Maintenance  
 Manual** , 1989

**3 wire fuel sending unit wiring diagram: Manuals Combined: 50 + Army T-62 T-53 T-55  
 T-700 AVIATION GAS TURBINE ENGINE Manuals** , Over 70 (350+ Mbs) U.S. Army Repair,  
 Maintenance and Part Technical Manuals (TMs) related to U.S. Army helicopter and fixed-wing  
 turbine aircraft engines, as well as turbine power plants / generators! Just a SAMPLE of the  
 CONTENTS: ENGINE, AIRCRAFT, TURBOSHAFT MODELS T700-GE-700, T700-GE-701,  
 T700-GE-701C, 1,485 pages - TURBOPROP AIRCRAFT ENGINE, 526 pages - ENGINE, GAS  
 TURBINE MODEL T55-L-712, 997 pages - ENGINE ASSEMBLY GAS TURBINE (GTCP36-150 (BH),  
 GTCP36-150 (BH), 324 pages - ENGINE, AIRCRAFT, GAS TURBINE (T63-A-5A) (T63-A-700), 144  
 pages - ENGINE, AIRCRAFT, GAS TURBINE MODEL T63-A-720, 208 pages - ENGINE, AIRCRAFT,  
 TURBOSHAFT (T703-AD-700), (T703-AD-700A), (T703-AD-700B), 580 pages ENGINE ASSEMBLY,  
 T700-GE-701, 247 pages - ENGINE ASSEMBLY GAS TURBINE (GTCP3645(H), 214 pages - ENGINE,  
 AIRCRAFT, GAS TURBINE MODEL T63-A-720, 208 pages - GAS TURBINE ENGINE (AUXILIARY  
 POWER UNIT - APU ) MODEL T - 62 T - 40 - 1, 344 pages - ENGINE ASSEMBLY, T700-GE-700, 243  
 pages - SANDY ENVIRONMENT AND/OR COMBAT OPERATIONS FOR T53-L-13B, T53-L-13BA AND

T53-L-703 ENGINES, 112 pages - DUAL PURPOSE MOBILE CHECK AND ADJUSTMENT/GENERATOR STAND FOR T62T-2A AND T62T-2A1 AUXILIARY POWER UNITS; T62T-40-1 AND T62T-2B AUXILIARY POWER UNITS, 193 pages - Others included: POWER PLANT, UTILITY; GAS TURBINE ENGINE DRI (LIBBY WELDING CO., MODEL LPU-71) (FSN 6115-937-0929) (NON-WINT AND (6115-134-0825) (WINTERIZED) POWER PLANT, UTILITY (MUST), GAS TURBINE ENGINE DRIVEN (AIRESEARCH CO MODEL NO. PPU85-5); (LIBBY WELDING CO., MODEL NO. LPU-71); (AME CORP., MODEL APP-1) AND (HOLLINGSWORTH CO., MODEL NO. JHTWX10/9 (NSN 6115-00-937-0929) (NON-WINTERIZED) AND (6115-00-134-0825) (WINTERIZED) POWER PLANT, UTILITY (MUST), GAS TURBINE ENGINE DRIVEN (AIRESEA MODEL PPU85-5), (LIBBY WELDING CO., MODEL LPU-71), (AMERTECH CO MODEL APP-1) AND (HOLLINGSWORTH CO., MODEL JHTWX10/96) (NSN 6115-00-937-0929, NON-WINTERIZED AND 6115-00-134-0825, WINTERIZED) GENERATOR SET, GAS TURBINE ENGINE DRIVEN, TACTICAL, SKID MTD, 1 400 HZ, ALTERNATING CURRENT GENERATOR SET, GAS TURBINE ENGINE: 45 KW, AC, 120/208 AND 240/4 3 PHASE, 4 WIRE; SKID MTD, WINTERIZED (AIRESEARCH MODEL GTGE 70 (FSN 6115-075-1639) POWER PLAN UTILITY, (MUST), GAS TURBINE ENGINE DRIVEN (AIRESEARCH CO., MOD PPU85-5) (LIBBY WELDING CO., MODEL LPU-71), (AMERTECH CORP., MODEL APP-1) AND (HOLLINGSWORTH CO., MODEL JHTWX 10/96) (NSN 6115-00-937-0929) (NONWINTERIZED) AND (6115-00-134-0825) (WINTERIZED) POWER PLANT, UTILITY, GAS TURBINE ENGINE DRIVEN (AMERTECH CORP MODEL APP-1) POWER PLANT UTILITY, GAS TURBINE ENGINE DRIVEN (LIBBY WELDING CO. MODEL LPU-71) POWER UNIT UTILITY PACK: GAS TURBINE ENGINE DRIVEN (AIRESEARCH MODEL PPU85-5 TYPE A) AVIATION UNIT AND INTERMEDIATE MAINTENANCE FOR GAS TURBINE ENGI (AUXILIARY POWER UNIT - APU) MODEL T-62T-2B, PART NO. 161050-10 (NSN 2835-01-092-2037) AVIATION UNIT AND INTERMEDIATE MAINTENANCE REPAIR PARTS AND SPE TOOLS LIST (INCLUDING DEPOT MAINTENANCE REPAIR PARTS AND SPECIA FOR GAS TURBINE ENGINE (AUXILIARY POWER UNIT - APU), MODEL T-62 PART NO. 160150-100 (NSN 2835-01-092-2037)

**3 wire fuel sending unit wiring diagram: Organizational, Direct Support, and General Support Maintenance Manual (including Repair Parts and Special Tools Lists) for Heaters, Vehicular Compartment , 1992**

**3 wire fuel sending unit wiring diagram: Ford Fuel Injection & Electronic Engine Control** Charles O. Probst, 1993 The authoritative, hands-on book for Ford Engine Control Systems. Author Charles Probst worked directly with Ford engineers, trainers and technicians to bring you expert advice and inside information on the operation of Ford systems. His comprehensive troubleshooting, service procedures and tips will help you master your Ford's engine control system.

**3 wire fuel sending unit wiring diagram: Operator's, Unit, Direct Support, and General Support Maintenance for Compressor, Air, Rotary Screw, 750 Cfm, 100 Psi, Wheel-mounted, DED, Sullair Model 750 DP (NSN 4310-01-053-3891). , 1993**

**3 wire fuel sending unit wiring diagram: Advanced Automotive Engine Performance** Michael Klyde, CDX Automotive,, 2020-04-17 Advanced Automotive Engine Performance is designed to prepare novice technicians for the challenge of diagnosing today's highly technical electronic engine controls. Using this curriculum, learners will gain familiarity with the operation and variations of emissions systems and associated onboard monitors. The curriculum especially focuses on applying diagnostic strategy to and performing service procedures for emissions systems faults. Learners will also develop an understanding of IM testing and an ability to interpret IM test reports to aid in diagnosis. This objective-based curriculum will prepare learners for the challenges of servicing engine management systems in the shop today. This is a complete curriculum solution for Advanced Automotive Engine Performance. Online courseware is available and is rich in video and animation to support understanding of complex systems. This solution is available in print-plus-digital, or digital-only offerings, providing eBook and online course pairing with mobile-friendly adaptability. Complete tests, tasksheets, and instructor resources make this curriculum easy to adopt and integrate into any automotive program.

**3 wire fuel sending unit wiring diagram:** \1985\nineteen Eighty-five\ Domestic Light Trucks & Vans Tune-up, Mechanical Service & Repair Mitchell Information Services, 1985

**3 wire fuel sending unit wiring diagram:** Motorcycle Electrical Systems Tracy Martin, 2007

**3 wire fuel sending unit wiring diagram:** **Operator, Organizational, Field, and Depot Maintenance Manual** , 1973

**3 wire fuel sending unit wiring diagram:** **Automobile Electrical and Electronic Systems** Tom Denton, 2017-09-12 This textbook will help you learn all the skills you need to pass all Vehicle Electrical and Electronic Systems courses and qualifications. As electrical and electronic systems become increasingly more complex and fundamental to the workings of modern vehicles, understanding these systems is essential for automotive technicians. For students new to the subject, this book will help to develop this knowledge, but will also assist experienced technicians in keeping up with recent technological advances. This new edition includes information on developments in pass-through technology, multiplexing, and engine control systems. In full colour and covering the latest course specifications, this is the guide that no student enrolled on an automotive maintenance and repair course should be without. Designed to make learning easier, this book contains: Photographs, flow charts, quick reference tables, overview descriptions and step-by-step instructions. Case studies to help you put the principles covered into a real-life context. Useful margin features throughout, including definitions, key facts and 'safety first' considerations.

**3 wire fuel sending unit wiring diagram:** **Operator, Organizational, Direct Support, & General Support Maintenance Manual Including Repair Parts List for Cleaner, Steam Pressure, Jet, Skid Mounted, Model RI 2400 (NSN 4940-00-186-0027).** , 1990

**3 wire fuel sending unit wiring diagram:** *How to Troubleshoot, Repair, and Modify Motorcycle Electrical Systems* Tracy Martin, 2014-07-15 DIVIn How to Troubleshoot, Repair, and Modify Motorcycle Electrical Systems, motorcycle expert Tracy Martin provides crystal-clear, fully illustrated, step-by-step instructions for every electrical repair imaginable on a bike. /div

**3 wire fuel sending unit wiring diagram:** **Fundamentals of Medium/Heavy Duty Commercial Vehicle Systems** Gus Wright, Owen C. Duffy, 2019-07-15 Fundamentals of Medium/Heavy Duty Commercial Vehicle Systems, Second Edition offers comprehensive coverage of basic concepts and fundamentals, building up to advanced instruction on the latest technology coming to market for medium- and heavy-duty trucks and buses. This industry-leading Second Edition includes six new chapters that reflect state-of-the-art technological innovations, such as distributed electronic control systems, energy-saving technologies, and automated driver-assistance systems.

**3 wire fuel sending unit wiring diagram:** **Locomotive Cyclopedia of American Practice** , 1956

**3 wire fuel sending unit wiring diagram:** *Manuals Combined: 150+ U.S. Army Navy Air Force Marine Corps Generator Engine MEP APU Operator, Repair And Parts Manuals* , Over 36,000 total pages .... Just a SAMPLE of the CONTENTS by File Number and TM Number:: 013511 TM 5-6115-323-24P 4 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 K SINGLE PHASE, AC, 120/240 V, 28 VDC (LESS ENGINE) DOD MODELS MEP-015A, 60 HZ (NSN 6115-00-889-1446) AND (DOD MODEL MEP-025A) 28 VDC (6115-00-017-8236) {TO 35C2-3-385-4; SL 4-07609A/07610A} 013519 TM 5-6115-329-25P 1 GENERATOR SET, GASOLINE ENGINE DR (LESS ENGINE) 0.5 KW, AC, 120/240 V, 60 HZ, 1 PHASE (DOD MODEL (FSN 6115-923-4469); 400 HZ (MODEL MEP-019A) (6115-940-7862) AN DC (MODEL MEP-024A) (6115-940-7867) {TO 35C2-3-440-14} 013537 TM 5-6115-457-12 7 GENERATOR SET, ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 4 WIRE, 120 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101), (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102), (MODEL MEP-116A) PRECISE CLASS, 400 KW (6115-00-133-9103) INCLUDING OPTIONAL KITS (MODEL MEP-007 AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082), (MEP-007AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9084), (MODEL MEP-007A DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL

MEP-007AWM) WHEEL 013538 TM 5-6115-457-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID 100 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODELS MEP0 UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101); (MODEL MEP106A) CLASS, 50/60 HZ (6115-00-133-9102) AND (MODEL MEP116A), PRECISE 400 HZ (6115-00-133-9103); INCLUDING OPTIONAL KITS (DOD MODELS MEP007AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082); MEP007AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-9084); (MOD MEP007ALM) DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP007A MOUNTING KIT (6 013540 TM 5-6115-458-24P 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD., 2 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, DOD MODELS MEP009A UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND MODEL MEP108A PRECISE CLASS, 50/60 HZ (6115-00-935-8729) INCLUDING OPTIONAL K DOD MODELS MEP009AWF, WINTERIZATION KIT, FUEL BURNING (6115-00-403-3761), MODEL MEP009AWE, WINTERIZATION KIT, ELECTRIC (6115-00-489-7285) 013545 TM 5-6115-465-12 19 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 30 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODEL MEP-005A), UTILITY CLASS, 50/6 (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE CLASS, 50/60 (6115-00-118-1247), (MODEL MEP-114A), PRECISE CLASS, 400 HZ (6115-00-118-1248) INCLUDING AUXILIARY EQUIPMENT (DOD MODEL MEP WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083), (MODEL MEP- WINTERIZATION KIT, ELECTRIC (6115-00-463-9085), (MODEL MEP-005A LOAD BANK KIT (6115-00-463-9088) AND (MODEL MEP-005AWM), WH 013547 TM 5-6115-465-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTIC SKID MTD, 30 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MO MEP-005A), UTILITY, 50/60 HZ (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE, 50/60 HZ (6115-00-118-1247), (MODEL MEP-114 PRECISE, 50/60 HZ (6115-00-118-1248) INCLUDING OPTIONAL KITS (MODEL MEP-005AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (MODEL MEP-005AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-908 (MODEL MEP-005ALM) LOAD BANK KIT (6115-00-463-9088) (MODEL MEP- WHEEL MOUNTING KIT (6115-00 013548 TM 5-6115-545-12 18 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 60 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 VOLTS, DOD MODEL MEP-006A, UTILITY CLASS, 5 (NSN 6115-00-118-1243) DOD MODEL MEP-105A, PRECISE CLASS, 50/60 (6115-00-118-1252) DOD MODEL MEP-115A, PRECISE CLASS, 400 HZ (6115-00-118-1253) INCLUDING OPTIONAL KITS, DOD MODEL MEP006AWF WINTERIZATION KIT, FUEL BURNING (6115-00-407-8314) DOD MODEL MEP006AWE, WINTERIZATION KIT, ELECTRIC (6115-00-455-7693) DOD M MEP006ALM, LOAD BANK KIT (6115-00-407-8322) DOD MODEL MEP006 013550 TM 5-6115-545-34 12 INTERMEDIATE (FIELD) (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE MANUAL FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODELS MEP-006A, UTILITY CLASS, 50/60 HZ (FSN 6115-118-1243 MEP-105A, PRECISE CLASS, 50/60 HZ (6115-118-1252) AND MEP-115A, PRECISE CLASS, 400 HZ (6115-118-1253) {TO 35C2-3-444-2; NAVFAC P-8-626-34; TM 00038G-35} 015378 TM 5-6115-323-14 10 GENERATOR GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 KW, SI PHASE, AC, 120/240 V, 28 V, DC (LESS ENGINE) (DOD MODELS MEP-01 60 HZ (NSN 6115-00-889-1446) AND (MODEL MEP-025A) 28 V DC (6115-00-017-8236) {TO 35C2-3-385-1} 015380 TM 5-6115-332-24P 3 GENERATOR GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE; 120/208 V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) M DESIGN: 60 HZ (DOD MODEL MEP-017A) (NSN 6115-00-017-8240); 400 (DOD MODEL MEP-022A) (6115-00-017-8241) {TO 35C2-3-424-24} 020611 LO 5-6115-457-12 GENERATOR SET, DIESEL ENGINE DRIVEN; SKID MTD, 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/ (NSN 6115-00-133-9101); (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102) AND (MODEL MEP-116A), PRECISE CLASS, 400 HZ (6115-00-133-9103) 020612 LO 5-6115-458-12 GENERATOR SET, DIESEL ENGINE DRIVEN, SKID MTD, 200 KW, 3 PHASE, 4 WIRE, 120/208/416 VOLTS, DOD MODELS MEP-009A, UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-133-9104), MEP-108A, PRECISE CLASS, 50 HERTZ

(6115-00-935-8729) {LO 07536A-12} 020614 LO 5-6115-465-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 30 3 PHASE, 4 WIRE, 120/206 AND 240/416 V (DOD MODEL MEP-055A), UT CLASS, 50/60 HZ (NSN 6115-00-118-1240); (MODEL MEP 104A), PRECI CLASS, 50/60 HZ (6115-00-118-1247) AND (MODEL 114A) PRECISE CLA 400 HZ (6115-00-118-1248) 025150 TM 5-6115-271-14 12 GENERATOR SET, GASOLINE ENGINE DRIVEN, S MTD, TUBULAR FRAME, 3 KW, 3 PHASE, AC, 120/208 AND 120/240 V, 2 DC (LESS ENGINE) DOD MODEL MEP-016A, 60 HZ (NSN 6115-00-017-823 MODEL MEP-016C 60 HZ (6115-00-143-3311) MODEL MEP-021A 400 HZ (6115-00-017-8238) MODEL MEP-021C 400 HZ (6115-01-175-7321) MODEL MEP-026A DC HZ (6115-00-017-8239) MODEL MEP-026C 28 V DC (6115-01-175-7320) {TO 35C2-3-386-1; TM 05926A-14; NAVFAC P-8-6 025151 TM 5-6115-271-24P 3 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULA FRAME, 3 KW, 3 PHASE, AC; 120/208 AND 120/240 VOLTS, 28 VDC (LE ENGINE) (DOD MODEL MEP-016A) 60 HERTZ (NSN 6115-00-017-8237) (MEP-021A) 400 HERTZ (6115-00-017-8238) (MEP-026A) 28 VDC HERTZ (6115-00-017-8239) (MEP-016C) 60 HERTZ (6115-01-143-3311) (MEP- 400 HERTZ (6115-01-175-7321) (MEP-026C) 28 VDC HERTZ (6115-01-175-7320) {TO 35C2-3-386-4; SL-4-05926A} 032507 TM 5-6115-275-14 10 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208V PHASE, AND 120/240V, SINGLE PHASE, LESS ENGINE: DOD MODELS MEP- HZ, (NSN 6115-00-889-1447) AND MEP-023A, 400 HZ (6115-00-926-08 {NAVFAC P-8-615-14; TO 35C2-3-452-1} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032508 TM 5-6115-275-24P 5 GENERATOR, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE AND 120/240 V, SINGLE PHASE (LESS ENGINE); D MEP-018A, UTILITY CLASS, 60 HZ (NSN 6115-00-889-1447) AND MEP-0 PRECISE CLASS, 400 HZ (6115-00-926-0843) {NAVFAC P8-615-24P; TO 35C2-3-452-4} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032551 TM 5-6115-584-12 11 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-12; TO 35C2-3-456-1; TM 05682C-12} 032640 TM 5-6115-585-12 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 10 KW, 1 PHASE, 2 WIRE 1 PHASE, 3 WIRE AND 3 PHASE, 4 WIRE; 120, 120/240 AND 120/208 V (DOD MODEL MEP-003A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1030 AND (MODEL MEP-112A), UTILITY CLASS, 400 HZ (6115-00-465-1027) {NAVFAC P-8-623-12; TO 35C2-3-455-1; TM-05684C/05685B-12} 032781 TM 5-6115-584-34 8 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 5 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A), UTILITY CLASS, (NSN 6115-00-465-1044) {NAVFAC P-8-622-34; TO 35C2-3-456-2; TM 0568C-34} 032936 TM 5-6115-329-14 4 GENERATOR SET GASOLINE ENGINE DRIVEN, 0.5 KW (LESS ENGINE) (DOD MODEL MEP-014 UTILITY CLASS, 60 HZ) (NSN 6115-00-923-4469), (DOD MODEL MEP-01 UTILITY CLASS, 400 HZ (6115-00-940-7862) AND (DOD MODEL MEP-024 UTILITY CLASS, 28 VDC (6115-00-940-7867) {TO 35C2-3-440-1} 033374 TM 5-6115-332-14 10 GENERATOR SET, TAC GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE, V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) (MILITARY DOD MODEL MEP-017A), UTILITY, 60 HZ (NSN 6115-00-017-8240) AND MODEL MEP-022A), UTILITY, 400 HZ (6115-00-017-8241) {NAVFAC P-8-614-14; TO 35C2-3-424-1} 033750 TM 5-6115-585-34 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 10 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP-003A), UT CLASS, 60 HZ (NSN 6115-00-465-1030) {NAVFAC P-8-623-12; TO 35C2-3-455-2; TM-05684C/05685B-34} 034072 TM 5-6115-585-24P 5 GENERATOR SET, DIESEL ENGINE DRIVEN, TA SKID MTD, 10 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 W 120, 120/240 AND 120/208 V (DOD MODELS 003A), UTILITY CLASS, 60 (NSN 6115-00-465-1030) AND (MODEL MEP-112A), UTILITY CLASS, 400 (6115-00-465-1027) {NAVFAC P-8-623-24P; TO 35C2-3-455-4; SL-4-05684C/06585B} 040180 TM 5-6115-584-12-HR HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS (BII), AND

ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 WIRE; 1 PH, 3 WIRE; 3 PH, 4 WIRE, 120, 120/240 AND 120/208 V (D MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) 040833 TM 5-6115-458-12-HR HAND RECEIPT MANUAL COVERING THE END ITEM/COMPONENTS OF END ITE BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AA GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 20 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODEL MEP-009A), UT CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND (DOD MODEL MEP-108A) PRECISE CLASS, 50/60 HZ (6115-00-935-8729) 040843 TM 5-6115-593-34 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD, 500 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL, MEP-029A, CLASS UTILITY, 50/60 HZ, (NSN 6115-01-030- DOD MODEL, MEP-029B, CLASS UTILITY, 50/60 HZ, (6115-01-318-6302 INCLUDING OPTIONAL KITS DOD MODEL, MEP-029AHK, HOUSING KIT, (6115-01-070-7550), DOD MODEL, MEP-029ACM, AUTOMATIC CONTROL MO (6115-01-275-7912) DOD MODEL, MEP-029ARC, REMOTE CONTROL MODULE (6110-01-070-7553) DOD MODEL, MEP-029ACC, REMOTE CONTROL CABLE, (6110-01-087-4127) {NAVFAC P-8 041070 TM 5-6115-593-12 GENERATOR SET, ENGINE DRIVEN, TACTICAL SKID MTD, 500 KW, 3 PHASE, 4 WIRE; 120/ 240/416 VOLTS DOD MODEL MEP-029A; CLASS UTILITY, HERTZ 50/60; (NSN 6115-01-030-6085); MEP-029B; UTILITY; 50/60; (6115-01-318- INCLUDING OPTIONAL KTS DOD MODELS MEP-029AHK; NOMENCLATURE HOUS (6115-01-070-7550) MEP-029ACM; AUTOMATIC CONTROL MODULE; (6115-01-275-7912); MEP-029ARC, REMOTE CONTROL MODULE, (6110-01-070-7553); MEP-029ACC, REMOTE CONTROL CABLE (6110-01-087-4127) {TO 35C2-3-463-1} 041338 LO 55-1730-229-12 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU), WHEEL MOUNTED, SELF-PROPELLED, TOWABLE DOD MODEL-MEP-360A, CLASS-PRECISE, HERTZ-400, (NSN 1730-01-144-1897 042791 TM 5-6115-457-12-HR HAND RECEIPT MANUAL COVERING THE BASIC ISSUE ITEMS (BII) FOR GE SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP007A), UTILITY CLASS, 50/6 (NSN 6115-00-133-9101), (MODEL MEP-106A), PRECISE CLASS, 50/60 (6115-00-133-9102) AND (MODEL MEP116A) PRECISE CLASS, 400 HZ (6115-00-133-9103) 043437 TM 5-6115-593-24P 1 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 500 KW, 3 PHA 4 WIRE; 120/208 AND 240/416 VOLTS DOD MODEL MEP-029A UTILITY CL 50/60 HZ (NSN 6115-01-030-6085) MEP-029B UTILITY CLASS, 50/60 (6115-01-318-6302) INCLUDING OPTIONAL KITS DOD MODEL MEP-029AHK HOUSING KIT (6115-01-070-7550) MEP-029ACM AUTOMATIC CONTROL MOD (6115-01-275-7912) MEP-029ARC REMOTE CONTROL MODULE (6110-01-070-7553) MEP-029ACC REMOTE CONTROL CABLE (6110-01-087 {NAVFAC P-8-631-24P; TO 35C2-3-463-4} 044703 TM 5-6115-545-12-HR HAND RECEIPT MANUAL COVERING COMPONENTS OF END ITEM (COEI), BAS ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL) FOR GENERA DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 60 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODELS MEP-006A) UTILITY CLASS, 50/6 (NSN 6115-00-118-1243), (MODEL MEP-105A) PRECISE CLASS, 50/60 H (6115-00-118-1252) AND (MODEL MEP-115A) PRECISE CLASS, 400 HZ (6115-00-118-1253) 050998 TM 5-6115-600-12 8 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 100 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 V (DOD MODEL MEP-007B) CLASS UTILITY, 50/60 (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP00 WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT ELECTRIC 051007 TM 5-6115-600-24P 4 GENERATOR SET, DIESEL ENGINE DRIVEN, 100 KW, 3 PHASE, 4 WIRE, 120/208 AND VOLTS (DOD MODEL MEP-007B), UTILITY CLASS, 50/60 HZ (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP007BWF, WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT, ELECTRIC {TO 35C2-3-442-14; NAVFAC P-8-628-24P; SL-4-07464B} 057268 LO 5-6115-600-12 GENERATOR SET, DIESEL ENGINE DRIVEN; TACTICAL, SKID MTD, 100 KW PHASE, 4 WIRE; 120/208 AND 240/416 V (DOD MODEL MEP007B), CLASS UTILITY, 50/60 HZ (NSN 6115-01-036-6374) 057513 LO 5-6115-604-12 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE; SKID MT 750 KW, 3 PHASE,

4 WIRE; 2400/4160 AND 2200/3800 VOLTS (DOD MOD MEP208A) CLASS PRIME UTILITY, HZ 50/60 (NSN 6115-00-450-5881) {LI 6115-12/9} 060183 TM 5-6115-612-24P 6 GENERATOR SET, AVIATION, GAS TURBINE ENGINE DRIVEN, INTEGRA TRAILER MOUNTED, 10KW, 28 VOLTS MODEL MEP-362A, PRECISE, DC (NSN 6115-01-161-3992) {TM 6115-24P/1; AG-320B0-IPE-000; TO 35C2-3-471-4} 060188 TM 5-6115-612-34 4 GENERATOR SET, AVIATION, GAS TURBINE ENG DRIVEN, INTEGRAL TRAILER MOUNTED 10KW 28 VOLTS DOD MODEL MEP 36 PRECISE, DC, (NSN 6115-01-161-3992) {AG-320B0-MME-000; TM 6115- TO 35C2-3-471-2} 060645 LO 5-6115-612-12 AVIATION GENERATOR SET, GAS TURBINE, ENGINE DRIVEN, INTEGRAL TR MOUNTED, 10KW, 28 VOLTS DC DOD MODEL MEP 362A CLASS PRECISE (NSN 6115-01-161-3992) 060921 TM 55-1730-229-34 5 POWER UNIT, AVIATION, MULTI-OUTPUT GTED, ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWA AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28VDC 700 AMPS, PNEUMATIC, 60 LBS/MIN. AT 40 PSIG, HYDRAULIC, 15 GPM AT 3300 PS DOD MODEL MEP-360A, CLASS PRECISE, 400 HERTZ, (NSN 1730-01-144- {AG 320A0-MME-000; TO 35C2-3-473-2; TM 1730-34/1} 060922 TM 55-1730-229-12 8 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWABLE, AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28 VDC 700 AMPS, PNEUMATIC 60 LBS/M AT 40 PSIG, HYDRAULIC 15 GPM AT 3300 PSIG, DOD MODEL MEP-360A, CLASS PRECISE, HERTZ 400, (NSN 1730-01-144-1897) {AG 320A0-OMM-000; TO 35C2-3-473-1; TM 1730-12/1} 061758 LO 5-6115-614-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD. 200 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS MODEL MEP009B, UTILI 50/60 HERTZ, (NSN 6115-01-021-4096) 061772 LO 5-6115-622-12 GENERATOR SET, DIESEL ENGINE-DRIVEN, WHEEL MOUNTED 750-KW, 3-PH 4-WIRE, 2200/3800 AND 2400/4160 VOLTS CUMMINS ENGINE COMPANY IN MODEL KTA-2300G-2 DOD MODEL MEP-012A; CLASS UTILITY; HERTZ 062762 LO 5-6115-615-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 3 K MODEL 016B; CLASS UTILITY MODE 50/60 HZ (NSN 6115-01-150-4140); DOD MODEL MEP-021B; CLASS UTILITY; MODE 400 HZ (6115-01-151-812 DOD MODEL MEP-026B; CLASS UTILITY; MODE 28 VDC (6115-01-150-036 {LI 05926B/06509B-12/5; P-8-646-LO} 064310 TM 5-6115-626-14&P 2 POWER UNIT PU-406B/M (NSN 6115-00-394-9576) MEP-005A 30 KW 60 HZ GENERATOR SET M200A1 2-WHEEL4-TIRE, MODIFIED TRAILER 064390 TM 5-6115-632-14&P 5 POWER UNIT PU-753/M (NSN 6115-00-033-1 MEP-003A 10 KW 60 HZ GENERATOR SET M116A2 2-WHEEL, 2-TIRE, MODI TRAILER 064392 TM 5-6115-629-14&P 3 POWER PLANT AN/AMJQ-12A (NSN 6115-00-257-1602) (2) MEP-006A 60HZ, GENERATOR SETS (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAIL 064443 TM 5-6115-625-14&P 2 POWER UNIT PU-405A/M (NSN 6115-00-394-9577) MEP-004A 15 KW 60 HZ GENERATOR SET M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER (THIS ITEM IS INCLUDED ON EM 0086 & EM 0087) 064445 TM 5-6115-633-14&P 4 POWER PLANT AN/MJQ-18 (NSN 6115-00-033-1398) (2) MEP-003A 1 60 HZ GENERATOR SETS M103A3 2-WHEEL 1 1/2 TON MODIFIED TRAILER 064446 TM 5-6115-628-14&P 4 POWER PLANT AN/MJQ-15 (NSN 6115-00-400-7591) (2) MEP-113A 1 400 HZ GENERATOR SETS, (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRA (THIS ITEM IS INCLUDED ON EM 0086) 064542 TM 5-6115-631-14&P 4 POWER PLANT AN/MJQ-16 (NSN 61 15-00-033-1395) (2) MEP-002A 5 KW 60 HZ GENERATOR SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAI 065071 TM 55-1730-229-24P 6 POWER AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDAULIC, PNEUMATIC (AG WHEEL MOUNTED, SELF-PROPELLED, TOWABLE AC 400 HZ, 3 PH, 0.8 PF, 115/200V, 30 KW DC 28 VDC 700 AMPS PNEUMATIC 60 LBS/MIN. AT 40 HYDRAULIC 15 GPM AT 3300 PSIG DOD MODEL MEP-360A, CLASS PRECISE 400 HERTZ (NSN 1730-01-144-1897) {TO 35C2-3-473-4; TM 1730-24P/ AG 320A0-IPB-000} 065603 TB 5-6115-593-24 WARRANTY PROGRAM FOR GENERATOR SET DOD MODEL MEP-029A HOUSING K DOD MODEL MEP-029AHK 066727 TM 5-6115-640-14&P 2 POWER AN/MJQ-32 (NSN 6115-01-280-2300) AN/MJQ-33 (6115-01-280-2301) ( MEP-701A 3KW 60 HZ ACOUSTIC SUPPRESSION KIT GENERATOR SETS M116 2-WHEEL, 2-TIRE, 3/4-TON MODIFIED TRAILERS 066808 TM 5-6115-627-14&P 2 POWER

PLANT AN/MJQ-10A (NSN 6115-00-394-9582); (2) MEP-005A 30 KW 60 HZ GEN SETS; (2) M200A1 2-WHEEL, 4 TIRE MODIFIED TRAILERS 066809 TM 5-6115-630-14&P 4 POWER UNIT, PU-751/M (NSN 6115-00-033-1373) MEP-002A, 5 KW, 60 HZ GENERATOR SET M116A1 2-WHEEL, 2-TIRE, MODIFIED TRAILER 066824 TM 5-6115-465-10-HR 1 HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS, (BII) AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 30K 4 WIRE, 120/208 AND 240/416 VOLTS - MEP-005A, UTILITY, 50/60 HE (NSN 6115-00-118-1240); MEP-104A, PRECISE, 50/60 HERTZ, (6115-00-118-1247); MEP-114A, PRECISE, 400 HERTZ, (6115-00-118- INCLUDING AUXILIARY EQUIPMENT MEP-005AWF WINTERIZATION KIT, FUE BURNING (6115-00-463-9083); MEP-005AWE, WINTERIZATION KIT, ELEC (6115-00 067310 TM 9-6115-650-14&P 1 POWER PLAN AN/MJQ-25 (NSN 6115-01-153-7742) (2) MEP-112A 10 KW 400 HZ GENE SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAILER 067311 TM 9-6115-653-14&P 2 POWER UNIT PU-732/M (NSN 6115-00-260-3082) MEP-113A 15 KW 400 HZ GENERATOR SET M200 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067544 TM 9-6115-652-14&P 1 POWER UNIT PU-760/M (NSN 6115-00-394-9581) MEP-114A 30 KW 400 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067632 TM 9-6115-648-14&P POWER UNIT PU-650B/G (NSN 6115-00-258-1622) MEP-006A 60 KW 60 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067744 TM 9-6115-646-14&P 1 POWER UNIT PU-495A/G, (NSN 6115-00-394-9575) AND PU-495B/G, (6115-01-134-0 MEP-007A 100 KW, 60 HZ OR MEP-007B, 100 KW, 60 HZ GENERATOR SET M353-2-WHEEL, 2-TIRE MODIFIED TRAILER 067746 TM 9-6115-651-14&P POWER UNIT 707A/M (NSN 6115-00-394-9573) MEP-115A, 60 KW, 400 HZ GENERATOR M200A1, 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067879 TM 9-6115-647-14&P 1 POWER UNIT PU-789/M (NSN 6115-01-208-9827) MEP-114A, 30 KW 400 HZ GENERATOR SET M353 2-WHEEL, 2-TIRE, MODIFIED TRAILER 069601 TM 9-6115-464-10-HR HAND RECEIPT MANUAL COVERING THE END ITEMS/COMPONENTS OF END IT (COEI), BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION L (AAL) FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MO 15 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL MEP UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP PRECISE CLASS, 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113 PRECISE CLASS, 400 HERTZ (6115-00-118-1244) 069602 LO 9-6115-464-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD, 15KW, 4 WIRE, 120/208 AND 240/416 VOLTS (DOD MODEL MEP 004A) (NSN 6115-00-118-1241); (DOD MODEL MEP 104A) (6115-00-118-1245) (DOD MODEL MEP-113A) (6115-00-118-1244) 069954 TM 9-6115-465-24P 2 GENERATOR SET, DIESEL ENGINE DRIVE TACTICAL SKID MTD. 30KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V MODELS; MEP-005A, UTILITY, 50/60 HZ, (NSN 6115-00-118-1240), MEP-104A PRECISE, 50/60 HZ, (6115-00-118-1247), MEP-114A, PRECISE, 400 H (6115-00-118-1248), INCLUDING OPTIONAL KITS, DOD MODELS; MEP-00 WINTERIZATION KIT, FUEL BURNING, (6115-00-463-9083), MEP-005-AW WINTERIZATION KIT, ELECTRIC, (6115-00-463-9085), MEP-002-ALM, L BANK KIT, (6115-00-463-9088), MEP-005-AWM, WHEEL MOUNTING KIT, (6115-00-463-9094) {TO-35C2-3-070096 TM 9-6115-464-24P 1 GENERATOR S DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS (DOD MODEL MEP-004A) UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) (DOD MODEL MEP-103A) PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) (DOD MODEL MEP-113A) PRECI CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS (DOD MODEL MEP-005-AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (DOD MODEL MEP-005-AWE) WINTERIZATION KIT, ELECTRIC (6615-00-46 (DOD MODEL MEP-004-ALM) LOAD BANK KIT (6115-00-191-9201 071025 TM 9-6115-641-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-11} 071026 TM 9-6115-642-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIE 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-11; TM 09247A/09248A-10/1} 071028 TM 9-6115-643-10 3 GENERATOR SET, SKID

MOUNTED, TACTICAL QUI 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-73 MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-21} 071029 TM 9-6115-644-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ), (NSN 6115-01-274-7389) MEP-815A (400 HZ), (6115-01-274-7394) {TO 35C2-3-446-11; TM 09249A/09246A-10/1} 071030 TM 9-6115-645-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ), (NSN 6115-01-274-7390) MEP-816A (400 HZ), (6115-01-274-7395) {TO 35C2-3-444-11; TM 09244A/09245A-10/1} 071031 LO 9-6115-641-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A TACTICAL QUIET 60 HZ (NSN 6115-01-274-7387) MEP-812A TACTICAL QUIET 400 HZ (6115-01-274-7391) 071032 LO 9-6115-642-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A TACTICAL QUIET 60 HZ (NSN 6115-01-275-5061) MEP-813A TACTICAL QUIET 400 HZ (6115-01-274-7392) 071033 LO 9-6115-643-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60/400 HZ MEP-804A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7388) MEP-814 TACTICAL QUIET 400 HZ (6115-01-274-7393) 071034 LO 9-6115-644-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7389) MEP-815 TACTICAL QUIET 400 HZ (6115-01-274-7394) {LI 09249A/09246A-12} 071035 LO 9-6115-645-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7390) MEP-816 TACTICAL QUIET 400 HZ (6115-01-274-7395) {LI 09244A/09245A-12} 071036 TB 9-6115-641-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A AND MEP-812A 071037 TB 9-6115-642-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A AND MEP-813A {SI 09247A/09248A-24} 071038 TB 9-6115-643-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A AND MEP-814A 071039 TB 9-6115-644-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A AND MEP-815A {SI 09249A/09246A-24} 071040 TB 9-6115-645-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A AND MEP-816A {SI 09244A/09245A-24} 071541 TM 9-6115-464-12 2 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 15 KW, 3 PHASE, 4 WIRE, 120/2 AND 240/416 VOLTS DOD MODEL MED-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP-103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005-AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005-AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004-ALM LOAD BANK KIT (6115-00-291 071604 TM 9-6115-645-24P GENERATOR SET, TACTICAL QUIET 60KW, 50/60/400 HZ (NSN 6115-01-274-7390) (MEP-806A) (6115-01-274-7395) (MEP-816A) {TO 35C2-3-444-14; TM 09244A/09245A-24P/3} 071605 TM 9-6115-642-24P GENERATOR SET, TACTICAL QUIET 10 KW, 60/400 HZ (NSN 6115-01-275-5061) (MEP-803A) (6115-01-274-7392) (MEP-813A) {TO 35C2-3-455-14; TM 09247A/09248A-24P/3} 071610 TM 9-6115-643-24P GENERATOR SET, TACTICAL QUIET 15KW, 50/60 - 400 HZ (NSN 6115-01-274-7388) (MEP-804A) (6115-01-274-7393) (MEP-814A) {TO 35C2-3-445-24} 071611 TM 9-6115-644-24P GENERATOR SET, TACTICAL QUIET 30KW, 50/60-400 HZ (NSN 6115-01-274-7389) (MEP-805A) (6115-01-274-7394) (MEP-815A) {TO 35C2-3-446-14; TM 09249A/09246A-24P/3} 071613 TM 9-6115-641-24P GENERATOR SET, TACTICAL QUIET 5 KW, 60/400 HZ (NSN 6115-01-274-7387) (MEP-802A) (6115-01-274-7391) (MEP-812A) {TO 35C2-3-456-14} 071713 TM 9-6115-645-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ) (NSN 6115-01-274-7390) MEP-816A (400 HZ) (6115-01-274-7395) {TO 35C2-3-444-12; TM 09244A/09245A-24/2} 071748 TM 9-6115-644-24 1 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ) (NSN 6115-01-274-7389) MEP-815A (400 HZ) (6115-01-274-7394) {TO 35C2-3-446-12; TM 09249A/09246A-24/2} 071749 TM 9-6115-643-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN

6115-01-274-7388) MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-22} 071750 TM  
 9-6115-642-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 HZ  
 MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO  
 35C2-3-455-12; TM 09247A/09248A-24/2} 071751 TM 9-6115-641-24 3 GENERATOR SET, SKID  
 MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387)  
 MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-12} 072239 TM 9-6115-464-34 1  
 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15 KW, 3 PHASE, 4 WIRE  
 120/208 AND 240/416 VOLTS DOD MODEL MEP-004A UTILITY CLASS 50/60 HERTZ (NSN  
 6115-00-118-1241) DOD MODEL MEP 103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245)  
 DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL  
 KITS DOD MODEL MEP-005AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD  
 MODEL MEP-005AWE WINTERIZAT KIT, ELECTRIC (6115-00-463-9085) DOD MODEL  
 MEP-004ALM LOAD BANK KIT (6115-00-291-920 073744 TM 9-6115-604-24P 1 GENERATOR SET,  
 DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MOUNTED, 750KW, 3 PHASE, 4 WIRE,  
 2400/4160, AND 2200/3800 VOLTS DOD MODEL MEP208A PRIME UTILITY CLASS 50/60 HERTS  
 (NSN 6115-00-450-5881) DOD MODEL 80-1466 REMOTE CONTROL MODULE CLASS  
 (6115-01-150-5284 DOD MODEL 80-7320 SITE REQUIREMENTS MODULE CLASS (6115-01-150-5  
 {NAVFAC P-8-633-24P} 074040 TM 9-6115-545-24P GENERATOR SET, DIESEL ENGINE DRIVEN,  
 TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, D MODELS MEP-006A,  
 UTILITY CLASS, 50/60 H/Z, (NSN 6115-00-118-124 MEP-105A, PRECISE CLASS, 50/60 H/Z,  
 (6115-00-118-1252), MEP-115 PRECISE CLASS, 400 H/Z (6115-00-118-1253); INCLUDING  
 OPTIONAL K DOD MODELS MEP-006AWF, WINTERIZATION FUEL BURNING, (6115-00-407  
 MEP-006AWE, WINTERIZATION KIT, ELECTRIC, (6115-00-455-7693), ME LOAD BANK KIT,  
 (6115-00-407-8322), AND MEP-006AWM, WHEEL MOUNTI (6115-00-463-9092) {TO 074212 TM  
 9-6115-604-12 GENERATOR SET, DIESEL DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3  
 PHASE, 4 WIRE, 24 AND 2200/3800 V (DOD MODEL MEP 208A) CLASS PRIME UTILITY, HZ 50  
 (NSN 6115-00-450-5881) {NAVFAC P-8-633-12} 074896 TM 9-6115-604-34 GENERATOR SET,  
 DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE,  
 2400/4160 AND 2200/3800 VOLTS DOD MODEL MEP 208A PRIME UTILITY CLASS 50/60 HERTZ  
 (NSN 6115-00-450-5881) {NAVFAC P-8-633-34} 075027 TM 9-6115-584-24P 1 GENERATOR SET,  
 DIESEL E DRIVEN, TACTICAL SKID MTD 5 KW, 1 PHASE -2 WIRE, 1 PHASE -3 WIR 3 PHASE -4  
 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP- UTILITY CLASS, 60 HZ (NSN  
 6115-00-465-1044) {NAVFAC P-8-622-24P TO 35C2-3-456-4} 077581 TM 9-6115-673-13&P 2KW  
 MILITARY TACTICAL GENERATOR SET 120 VAC, 60 HZ (NSN 6115-01-435-1565) (MEP-531A)  
 (EIC: LKA) (NSN 6115-21-912-0393) (MECHRON) 28 VDC (NSN 6115-01-435-1567) (MEP-501A)  
 (EIC: LKD) (NSN 6115-21-912-0392) (MECHRON) 078167 TM 9-6115-672-14 GENERATOR SET  
 SKID MOUNTED TACTICAL QUIET 60KW, 50/60 AND 400 HZ, MEP-806B (50/60 HZ) (NSN  
 6115-01-462-0291) EIC: GGW, MEP-816B (400 HZ) (NSN 6115-01-462-0292) EIC: GGX 078443 TM  
 9-6115-639-13 1 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN  
 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 078490 TM  
 9-6115-671-14 OPERATOR, UNIT, GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW,  
 50/60 AND 400 HZ, MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ)  
 (6115-01-462-0290) (EIC: GGV) 078503 TM 9-6115-671-24P GENERATOR SET SKID MOUNTED,  
 TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC:  
 GGU) MEP-815B (400 HZ) (NSN 6115-01-462-0290) (EIC: GGV) 078504 TM 9-6115-672-24P  
 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806B  
 (50/60 HZ) (NSN 6115-01-462-0291) (EIC: GGW) MEP-816B (400 HZ) (NSN 6115-01-462-0292 (EIC:  
 GGX) 078505 TB 9-6115-671-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET  
 30KW, 50/60 AND 400 HZ MEP-805B AND MEP-815B PROCURED UNDER CONTRACT  
 DAAK01-96-D-00620WITH MCII INC 078506 TB 9-6115-672-24 WARRANTY PROGRAM FOR  
 GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-806B AND MEP-816B

PROCURED UNDER CONTRACT DAAK01-96-D-00620 WITH MCII INC 078523 TM 9-6115-664-13&P 5KW, 28VDC, AUXILIARY POWER UNIT (APU) MEP 952B NSN 6115-01-452-6513 (EIC: N/A) 078878 TM 9-6115-639-23P 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 079379 TB 9-6115-641-13 WINTERIZATION KIT (NSN 6115-01-476-8973) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 5KW, 60 AND 400 HZ MEP-802A (600HZ) (6115-01-274-7387) MEP-812A (400HZ) (6115-01-274-7391) 079460 TB 9-6115-642-13 WINTERIZATION KIT (NSN 6115-01-477-0564) (EIC: N/A) INSTALLED ON GENERATOR KIT, SKID MOUNTED, TACTICAL QUIET, 10KW, 60 AND 400 HZ MEP-803A (60HZ) (6115-01-275-0561) MEP-813A (400HZ) (6115-01-274-7392) 079461 TB 9-6115-643-13 WINTERIZATION KIT (NSN 6115-477-0566) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 15KW, 50/60 AND 400 HZ, MEP-804A (50/60HZ) (6115-01-274-7388) MEP-814A (400HZ) (6115-01-274-7393) 079462 TB 9-6115-644-13 WINTERIZATION KIT (NSN 6115-01-474-8354) (EIC:N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, 30KW, 50/60 AND 400 HZ MEP-805A (50/60HZ) (NSN 6115-01-274-7389) MEP-815A (400HZ) (NSN 611501-274-7394) 079463 TB 9-6115-645-13 WINTERIZATION KIT (NSN 6115-01-474-8344) (EIC: N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 60KW, 50/60 AND 400 HZ, MEP-806A (50/60HZ) (6115-01-274-7390) MEP-816A (400HZ) (6115-01-274-7395) 080214 TM 9-6115-670-14&P AUXILIARY POWER UNIT, 20KW, 120/240 VAC, 60 HZ, MODEL NO. MEP-903A(SICPS) NSN 6115-01-431-3062 MODEL NUMBER MEP-903B (JTACS) NSN 6115-01-431-3063 MODEL NO MEP-903C9WIN-T) NSN 6115-01-458-5329 (EIC: N/A)

**3 wire fuel sending unit wiring diagram:** *Organizational Maintenance Manual* , 1978

**3 wire fuel sending unit wiring diagram:** *South African Automotive Heavy Vehicle Level 1* CDX Automotive, 2012-12-28

**3 wire fuel sending unit wiring diagram:** **1993 Mitchell Domestic Light Trucks & Vans Service & Repair** Mitchell International, 1993

**3 wire fuel sending unit wiring diagram:** **How To Diagnose and Repair Automotive Electrical Systems** Tracy Martin, 2005

**3 wire fuel sending unit wiring diagram:** **Popular Science** , 1982-07 Popular Science gives our readers the information and tools to improve their technology and their world. The core belief that Popular Science and our readers share: The future is going to be better, and science and technology are the driving forces that will help make it better.

**3 wire fuel sending unit wiring diagram:** **Fundamentals of Medium/Heavy Duty Diesel Engines** Gus Wright, 2015-12-16 Based on the 2014 National Automotive Technicians Education Foundation (NATEF) Medium/Heavy Truck Tasks Lists and ASE Certification Test Series for truck and bus specialists, Fundamentals of Medium/Heavy Duty Diesel Engines is designed to address these and other international training standards. The text offers comprehensive coverage of every NATEF task with clarity and precision in a concise format that ensures student comprehension and encourages critical thinking. Fundamentals of Medium-Heavy Duty Diesel Engines describes safe and effective diagnostic, repair, and maintenance procedures for today's medium and heavy vehicle diesel engines.

**3 wire fuel sending unit wiring diagram:** **Organizational maintenance for recovery vehicle, full tracked, medium, M88A1, (NSN 2350-00-122-6826).** , 1984

**3 wire fuel sending unit wiring diagram:** **Imported Cars & Trucks** Mitchell Manuals, inc, 1984

**3 wire fuel sending unit wiring diagram:** *Power* , 1911

**3 wire fuel sending unit wiring diagram:** *How to Tune and Modify Engine Management Systems* Jeff Hartman, 2004-02-13 Drawing on a wealth of knowledge and experience and a background of more than 1,000 magazine articles on the subject, engine control expert Jeff Hartman explains everything from the basics of engine management to the building of complicated project cars. Hartman has substantially updated the material from his 1993 MBI book Fuel Injection

(0-879387-43-2) to address the incredible developments in automotive fuel injection technology from the past decade, including the multitude of import cars that are the subject of so much hot rodding today. Hartman's text is extremely detailed and logically arranged to help readers better understand this complex topic.

**3 wire fuel sending unit wiring diagram:** *Operator, Organizational, Direct Support and General Support Maintenance Manual* , 1973

**3 wire fuel sending unit wiring diagram:** *Direct Support, General Support, and Depot Maintenance for Truck, Chassis, 5-ton, 6 X 6, M39, M39A2, M40, M40A1 ... Truck, Cargo ... Truck, Dump ... Truck, Tractor ... Truck, Tractor, Wrecker ... Truck, Van, Expansible ... Truck, Wrecker, Medium ... Truck, Bridging ... Truck, Logging, M748A1, M748A2* , 1978

**3 wire fuel sending unit wiring diagram: Operator's, Organizational, Direct Support, and General Support Maintenance Manual Including Repair Parts List for Cleaner, Steam Pressure Model 200-AO (NSN 4940-00-186-0027), American Kleaner Mfg. Co., Inc** , 1990

**3 wire fuel sending unit wiring diagram: Technical Manual** United States Department of the Army, 1954

## Additional Resources

*A place to share knowledge and better understand the world*  
Quora is a place to gain and share knowledge. It's a platform to ask questions and connect with people who contribute unique insights and quality answers.

3DMGAME Forum - Powered ...  
3DMGAME Forum

3DMGAME  
Explore gaming discussions, news, and updates on 3DM Forum, a hub for gamers to share insights and stay informed about the latest in gaming.

130 - ...  
3—4“ ”“”5  
“22” ...

www.baidu.com\_ ...  
Aug 11, 2024 · www.baidu.comwww.baidu.com  
...

- ...  
ai

- ...  
1÷ |×100%31003  
300

3DMGAME  
"Explore discussions, tips, and updates about the game ""Kingdom Come: Deliverance 2"" on this forum."

\_



3 Wire Fuel Sending Unit Wiring Diagram

## Related Articles

- [3 am study session](#)
- [3 month libor rate history 2022](#)
- [3 sisters planting diagram](#)

[Back to Home](#)