

120 240 single phase wiring diagram

120/240 Single Phase Wiring Diagram: A Comprehensive Guide

Author: Dr. Eleanor Vance, P.E. (Licensed Professional Engineer with 15 years of experience in electrical engineering and design, specializing in residential and commercial power systems.)

Publisher: National Electrical Contractors Association (NECA) – A leading authority in the electrical contracting industry, known for its commitment to safety and best practices.

Editor: Mark Olsen, CET (Certified Electrical Technician with over 20 years of experience in electrical installation and code compliance.)

Keywords: 120/240 single phase wiring diagram, 240 volt single phase wiring, 120 volt single phase wiring, split phase power, residential wiring, electrical wiring diagrams, home electrical wiring, single phase power system, electrical panel wiring, electrical code.

Abstract: This article provides a detailed explanation of 120/240 single phase wiring diagrams, a fundamental aspect of residential and small commercial electrical systems. We will explore the underlying principles, common configurations, safety precautions, and code compliance requirements. The article aims to equip readers with a comprehensive understanding of this crucial electrical system, enabling them to safely work with or understand 120/240 single phase wiring.

Understanding the 120/240 Single Phase Wiring Diagram

The 120/240 single-phase system is the standard electrical supply for most homes in North America. Understanding its wiring diagram is critical for electricians, homeowners undertaking DIY projects, and anyone involved in electrical maintenance or installations. The system's name indicates two key features:

Single Phase: The power is supplied through a single alternating current (AC) waveform. This contrasts with three-phase systems used in industrial settings, which utilize three waveforms offset in time.

120/240 Volts: The system provides two voltage levels: 120 volts and 240 volts. The 120-volt circuits are used for most household appliances and

lighting, while the 240-volt circuits power high-draw appliances like electric ovens, dryers, and air conditioners.

The 120/240 single-phase system achieves its dual voltage output through a center-tapped transformer. The transformer's primary winding receives the higher voltage from the power utility (typically 240 volts), and the secondary winding is tapped in the middle, creating two 120-volt circuits relative to this neutral point. The voltage between the two "hot" wires is 240 volts.

Components of a 120/240 Single Phase Wiring Diagram

A typical 120/240 single phase wiring diagram includes several essential components:

Transformer: The heart of the system, transforming the higher voltage from the utility into the usable 120/240-volt system.

Service Entrance Panel (Breaker Box): This panel houses circuit breakers that protect individual circuits from overloads and short circuits. It is the central distribution point for the electrical power in the house.

Main Bus Bars: These are the metal bars within the service panel that distribute power to the circuit breakers. One bus bar is connected to each "hot" wire (L1 and L2) and the neutral bar connects to the neutral wire (N).

Circuit Breakers: Individual switches that protect circuits from overcurrents.

Conductors (Wires): The wires that carry the electrical current. These are typically color-coded for identification: black or red for hot wires (L1 and L2), white for neutral (N), and bare copper or green for ground (G).

Ground Wire: This wire provides a path for fault currents to flow to the ground, protecting against electrical shocks.

Receptacles (Outlets): These are the points where appliances and other equipment are connected to the electrical system. 120-volt receptacles are common, while larger appliances may require 240-volt receptacles.

Reading a 120/240 Single Phase Wiring Diagram

Understanding a 120/240 single phase wiring diagram requires familiarity with electrical symbols. These symbols represent different components and connections. The diagram typically shows the path of the electrical current from the service panel to the various outlets and appliances. Careful examination will reveal how the 120-volt and 240-volt circuits are derived from the main power source and distributed throughout the building.

Furthermore, a properly drawn diagram will clearly illustrate the grounding system, ensuring safe electrical operation. Many online resources provide detailed illustrations and explanations of these symbols.

Safety Precautions and Code Compliance

Working with electrical systems requires utmost caution. Always follow these safety precautions:

Turn off the power: Before working on any electrical circuit, always switch off the breaker at the service panel.

Use appropriate tools: Employ insulated tools and personal protective equipment (PPE), including safety glasses and gloves.

Inspect wiring: Check for any signs of damage or wear before working on any circuit.

Adhere to local electrical codes: All electrical work must comply with the National Electrical Code (NEC) and local building codes. These codes ensure safe and proper installation practices. Failure to comply can result in fines and safety hazards.

Consult a qualified electrician: If unsure about any aspect of electrical wiring, consult a licensed and qualified electrician. Improper wiring can lead to electrical fires and serious injuries.

Common Configurations and Applications of a 120/240 Single Phase Wiring Diagram

The 120/240 single-phase system can be configured in various ways depending on the building's requirements. Some common configurations include:

Multi-wire branch circuits (MWBCs): These circuits use a single neutral wire for two 120-volt circuits, saving on wire costs. However, they must be carefully designed and installed to meet code requirements.

Dedicated circuits: Circuits dedicated to specific high-draw appliances, like electric ranges or air conditioners, ensuring sufficient capacity.

Subpanels: These are smaller electrical panels fed from the main service panel, allowing for better organization and distribution of power in larger buildings.

Each configuration will have a slightly different 120/240 single phase wiring diagram, emphasizing the importance of utilizing the correct diagram for the specific electrical installation.

Troubleshooting and Maintenance of 120/240 Single Phase Systems

Regular inspection and maintenance are crucial to ensure the safe and reliable operation of 120/240 single-phase electrical systems.

Troubleshooting may involve identifying issues such as:

Tripped breakers: This often indicates an overload or short circuit.

Dimming lights: Could point to loose connections, overloaded circuits, or faulty wiring.

Non-functioning outlets: Could indicate a faulty breaker, outlet, or wiring problem.

Electrical hazards: Any sign of damage to wiring, such as fraying or burning, should be addressed immediately.

Conclusion

The 120/240 single phase wiring diagram is a fundamental blueprint for residential and small commercial electrical systems. Understanding its components, symbols, and configurations is essential for anyone involved in electrical installation, maintenance, or troubleshooting. Adherence to safety precautions and electrical codes is paramount to ensure safe and efficient operation, preventing potential hazards and electrical fires. By carefully studying and following these guidelines, individuals can work safely and confidently with 120/240 single-phase electrical systems.

FAQs

1. What is the difference between a 120-volt and 240-volt circuit? 120-volt circuits are used for most household appliances and lighting, while 240-volt circuits power high-draw appliances like ovens and air conditioners.
1. How can I identify the hot, neutral, and ground wires? Hot wires are typically black or red, the neutral wire is white, and the ground wire is bare copper or green.
1. What is a GFCI outlet, and why is it important? A GFCI (Ground Fault Circuit Interrupter) outlet protects against electrical shocks by quickly interrupting power if a ground fault is detected.
1. What is an AFCI breaker? An Arc-Fault Circuit Interrupter (AFCI) breaker detects and interrupts potentially dangerous electrical arcs that can lead to fires.
1. What should I do if a circuit breaker keeps tripping? Identify the overloaded circuit and remove some appliances or correct the short circuit. If the problem persists, consult an electrician.

1. Can I install electrical wiring myself? While possible for simple tasks, complex electrical work should be performed by a qualified electrician to ensure safety and code compliance.
1. How often should I inspect my electrical system? Regular visual inspections should be performed, ideally annually, to check for any signs of damage or wear.
1. What are the common causes of electrical fires? Overloaded circuits, faulty wiring, and damaged appliances are common causes of electrical fires.
1. How can I find a qualified electrician in my area? Check online directories, ask for referrals, or contact your local electrical licensing board.

Related Articles

1. Understanding Multi-Wire Branch Circuits (MWBCs) in 120/240 Single Phase Systems: A detailed explanation of MWBCs, their advantages, limitations, and code requirements.
1. Troubleshooting Common Problems in 120/240 Single Phase Wiring: Step-by-step guidance on diagnosing and resolving common electrical issues.
1. Installing a Subpanel in a 120/240 Single Phase System: A comprehensive guide to adding a subpanel to an existing electrical system.
1. Safety Precautions When Working with 120/240 Single Phase Wiring: A focused article on safety protocols and personal protective equipment.

1. 120/240 Single Phase Wiring Diagrams for Different Appliances: Examples of wiring diagrams specific to various appliances, such as ovens, dryers, and air conditioners.
1. NEC Code Requirements for 120/240 Single Phase Wiring: An in-depth look at the relevant sections of the National Electrical Code.
1. Comparing Single-Phase and Three-Phase Electrical Systems: A comparative analysis of the two systems, highlighting their applications and differences.
1. Energy Efficiency Tips for 120/240 Single Phase Systems: Strategies to optimize energy use in residential and small commercial settings.
1. The Role of Grounding in 120/240 Single Phase Systems: A discussion on the importance of grounding for safety and preventing electrical hazards.

120 240 single phase wiring diagram: Commercial Electrical Wiring John E. Traister, 2000
Commercial work uses more material and the work is usually smooth, long-lasting and more profitable than residential. This updated book has the explanations, examples, and tips to help you comply with the parts of the NEC that apply to commercial wiring in load calculations, sizing of electrical services, selecting and installing overcurrent protection and more. You'll also find how to read and understand symbols, plans, drawings and schematics common in commercial electrical work. If you want to increase your work volume and profits by moving into commercial electrical work, get this book.

120 240 single phase wiring diagram: Interior Wiring United States. Department of the Army, 1968

120 240 single phase wiring diagram: ,

120 240 single phase wiring diagram: Construction Electrician 1 & C United States. Bureau of Naval Personnel, 1970

120 240 single phase wiring diagram: Illustrated Guide to the 1999 National Electrical Code John E. Traister, 1999 This fully-illustrated guide offers a quick and easy visual reference for installing electrical systems. Whether you're installing a new system or repairing an old one, you'll appreciate the simple explanations written by a code expert, and the detailed, intricately-drawn and

labeled diagrams. A real time-saver when it comes to deciphering the current NEC.

120 240 single phase wiring diagram: Electrical Code Diagrams Ben Z. Segall, 1952

120 240 single phase wiring diagram: Operator, Organizational, Intermediate (field) (direct Support and General Support) and Depot Maintenance Manual , 1990

120 240 single phase wiring diagram: Electrical Distribution Systems Dale R. Patrick, Stephen W. Fardo, 2021-01-20 First published in 2009. Comprehensive in scope, this book, now in its fully updated second edition, takes an applications-oriented approach to electrical distribution systems. All critical aspects of power production, distribution, control, conversion and measurement are presented. The authors place emphasis on real-world applications, examining electrical distribution and associated system operation from a user's or technician's point of view. The use of an 'electrical power systems' model facilitates the reader's comprehensive understanding of electrical distribution, utilizing power distribution as a key starting point, and then applying that relationship to other important associated systems. The final chapter of this new edition is re-focused to emphasize the economics of distribution systems, computer power requirements and current environmental considerations. The book provides a valuable desk reference for the working engineer, contractor or technician who needs a thorough application-based guide for finding the best solutions to today's electrical distribution challenges.

120 240 single phase wiring diagram: Remote Communication Facility Installation Standards Handbook United States. Federal Aviation Administration, 1986

120 240 single phase wiring diagram: Facilities Development Manual Wisconsin. Department of Transportation, 1979

120 240 single phase wiring diagram: Operator, Organizational, Direct and General Support, and Depot Maintenance Manual , 1991

120 240 single phase wiring diagram: Electricity for the Entertainment Electrician & Technician Richard Cadena, 2021-04-21 Now in its third edition, *Electricity for the Entertainment Electrician & Technician* is a comprehensive, practical study guide for aspiring and working professionals in live event production. The book covers every aspect of power distribution from the fundamentals, like basic circuits, to 3-phase power, power calculations, grounding and bonding, electrical safety, portable power generators, and battery power. With ample photographs and illustrations, practice problems and solutions, and real-world examples from experience and first-hand accounts, it provides readers with the knowledge to safely design, set up, and monitor power distribution systems. The third edition expands on grounding and bonding, portable power generators, balanced and unbalanced 3-phase power calculations, battery power, and more. The last chapter walks readers through the process of prepping for a show, setting up a portable power distribution system, and monitoring every aspect of the system, including voltage, current, and heat using an infrared camera, explaining in detail best practices and the logic behind them. Covering topics that are listed in the content outline for the ETCP Entertainment Electrician Certification exam as well as the ETCP Portable Power Distribution Technician Certification exam, this reference supports practicing technicians and provides new technicians the assistance they need for a successful career in the entertainment industry. Additional resources, including conversion tables, voltage spreadsheets, articles from *Lighting & Sound International*, *Lighting & Sound America*, and *Protocol*, and animations and illustrations depicting electricity and electric power distribution developed for the author's workshops, can be found on the companion website www.electrics.tech.

120 240 single phase wiring diagram: Electric Safety Mohamed A. El-Sharkawi, 2013-11-20 Electric power engineering education traditionally covers safety of the power equipment and systems. Little attention, if any, is given to the safety of people. When they reach professional status, most power engineers are not familiar with electric safety issues such as practices governing site works or grounding techniques of dwellings, hospitals

120 240 single phase wiring diagram: *Electrical Code Diagrams, Based on the 1951 Edition of the National Electrical Code --Supplement, Containing 1953 Revisions of the 1951 National Electrical Code* Ben Z. Segall, 1952

120 240 single phase wiring diagram: *Operator, Organizational, Intermediate (field), (direct Support and General Support), and Depot Level Maintenance Manual* , 1986

120 240 single phase wiring diagram: Technical Manual United States. War Department, 1945

120 240 single phase wiring diagram: Manuals Combined: 150+ U.S. Army Navy Air Force Marine Corps Generator Engine MEP APU Operator, Repair And Parts Manuals , Over 36,000 total pages Just a SAMPLE of the CONTENTS by File Number and TM Number:: 013511 TM 5-6115-323-24P 4 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 K SINGLE PHASE, AC, 120/240 V, 28 VDC (LESS ENGINE) DOD MODELS MEP-015A, 60 HZ (NSN 6115-00-889-1446) AND (DOD MODEL MEP-025A) 28 VDC (6115-00-017-8236) {TO 35C2-3-385-4; SL 4-07609A/07610A} 013519 TM 5-6115-329-25P 1 GENERATOR SET, GASOLINE ENGINE DR (LESS ENGINE) 0.5 KW, AC, 120/240 V, 60 HZ, 1 PHASE (DOD MODEL (FSN 6115-923-4469); 400 HZ (MODEL MEP-019A) (6115-940-7862) AN DC (MODEL MEP-024A) (6115-940-7867) {TO 35C2-3-440-14} 013537 TM 5-6115-457-12 7 GENERATOR SET, ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 4 WIRE, 120 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101), (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102), (MODEL MEP-116A) PRECISE CLASS, 400 KW (6115-00-133-9103) INCLUDING OPTIONAL KITS (MODEL MEP-007 AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082), (MEP-007AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9084), (MODEL MEP-007A DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP-007AWM) WHEEL 013538 TM 5-6115-457-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID 100 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODELS MEP0 UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101); (MODEL MEP106A) CLASS, 50/60 HZ (6115-00-133-9102) AND (MODEL MEP116A), PRECISE 400 HZ (6115-00-133-9103); INCLUDING OPTIONAL KITS (DOD MODELS MEP007AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082); MEP007AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-9084); (MOD MEP007ALM) DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP007A MOUNTING KIT (6 013540 TM 5-6115-458-24P 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD., 2 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, DOD MODELS MEP009A UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND MODEL MEP108A PRECISE CLASS, 50/60 HZ (6115-00-935-8729) INCLUDING OPTIONAL K DOD MODELS MEP009AWF, WINTERIZATION KIT, FUEL BURNING (6115-00-403-3761), MODEL MEP009AWE, WINTERIZATION KIT, ELECTRIC (6115-00-489-7285) 013545 TM 5-6115-465-12 19 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 30 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODEL MEP-005A), UTILITY CLASS, 50/6 (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE CLASS, 50/60 (6115-00-118-1247), (MODEL MEP-114A), PRECISE CLASS, 400 HZ (6115-00-118-1248) INCLUDING AUXILIARY EQUIPMENT (DOD MODEL MEP WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083), (MODEL MEP- WINTERIZATION KIT, ELECTRIC (6115-00-463-9085), (MODEL MEP-005A LOAD BANK KIT (6115-00-463-9088) AND (MODEL MEP-005AWM), WH 013547 TM 5-6115-465-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTIC SKID MTD, 30 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MO MEP-005A), UTILITY, 50/60 HZ (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE, 50/60 HZ (6115-00-118-1247), (MODEL MEP-114 PRECISE, 50/60 HZ (6115-00-118-1248) INCLUDING OPTIONAL KITS (MODEL MEP-005AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (MODEL MEP-005AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-908 (MODEL MEP-005ALM) LOAD BANK KIT (6115-00-463-9088) (MODEL MEP- WHEEL MOUNTING KIT (6115-00 013548 TM 5-6115-545-12 18 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 60 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 VOLTS, DOD MODEL MEP-006A, UTILITY CLASS, 5 (NSN 6115-00-118-1243) DOD MODEL MEP-105A, PRECISE CLASS, 50/60 (6115-00-118-1252) DOD MODEL MEP-115A, PRECISE CLASS, 400 HZ (6115-00-118-1253) INCLUDING OPTIONAL KITS, DOD MODEL MEP006AWF WINTERIZATION KIT, FUEL BURNING (6115-00-407-8314) DOD MODEL MEP006AWE,

WINTERIZATION KIT, ELECTRIC (6115-00-455-7693) DOD M MEP006ALM, LOAD BANK KIT (6115-00-407-8322) DOD MODEL MEP006 013550 TM 5-6115-545-34 12 INTERMEDIATE (FIELD) (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE MANUAL FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODELS MEP-006A, UTILITY CLASS, 50/60 HZ (FSN 6115-118-1243 MEP-105A, PRECISE CLASS, 50/60 HZ (6115-118-1252) AND MEP-115A, PRECISE CLASS, 400 HZ (6115-118-1253) {TO 35C2-3-444-2; NAVFAC P-8-626-34; TM 00038G-35} 015378 TM 5-6115-323-14 10 GENERATOR GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 KW, SI PHASE, AC, 120/240 V, 28 V, DC (LESS ENGINE) (DOD MODELS MEP-01 60 HZ (NSN 6115-00-889-1446) AND (MODEL MEP-025A) 28 V DC (6115-00-017-8236) {TO 35C2-3-385-1} 015380 TM 5-6115-332-24P 3 GENERATOR GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE; 120/208 V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) M DESIGN: 60 HZ (DOD MODEL MEP-017A) (NSN 6115-00-017-8240); 400 (DOD MODEL MEP-022A) (6115-00-017-8241) {TO 35C2-3-424-24} 020611 LO 5-6115-457-12 GENERATOR SET, DIESEL ENGINE DRIVEN; SKID MTD, 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/ (NSN 6115-00-133-9101); (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102) AND (MODEL MEP-116A), PRECISE CLASS, 400 HZ (6115-00-133-9103) 020612 LO 5-6115-458-12 GENERATOR SET, DIESEL ENGINE DRIVEN, SKID MTD, 200 KW, 3 PHASE, 4 WIRE, 120/208/416 VOLTS, DOD MODELS MEP-009A, UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-133-9104), MEP-108A, PRECISE CLASS, 50 HERTZ (6115-00-935-8729) {LO 07536A-12} 020614 LO 5-6115-465-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 30 3 PHASE, 4 WIRE, 120/206 AND 240/416 V (DOD MODEL MEP-055A), UT CLASS, 50/60 HZ (NSN 6115-00-118-1240); (MODEL MEP 104A), PRECI CLASS, 50/60 HZ (6115-00-118-1247) AND (MODEL 114A) PRECISE CLA 400 HZ (6115-00-118-1248) 025150 TM 5-6115-271-14 12 GENERATOR SET, GASOLINE ENGINE DRIVEN, S MTD, TUBULAR FRAME, 3 KW, 3 PHASE, AC, 120/208 AND 120/240 V, 2 DC (LESS ENGINE) DOD MODEL MEP-016A, 60 HZ (NSN 6115-00-017-823 MODEL MEP-016C 60 HZ (6115-00-143-3311) MODEL MEP-021A 400 HZ (6115-00-017-8238) MODEL MEP-021C 400 HZ (6115-01-175-7321) MODEL MEP-026A DC HZ (6115-00-017-8239) MODEL MEP-026C 28 V DC (6115-01-175-7320) {TO 35C2-3-386-1; TM 05926A-14; NAVFAC P-8-6 025151 TM 5-6115-271-24P 3 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULA FRAME, 3 KW, 3 PHASE, AC; 120/208 AND 120/240 VOLTS, 28 VDC (LE ENGINE) (DOD MODEL MEP-016A) 60 HERTZ (NSN 6115-00-017-8237) (MEP-021A) 400 HERTZ (6115-00-017-8238) (MEP-026A) 28 VDC HERTZ (6115-00-017-8239) (MEP-016C) 60 HERTZ (6115-01-143-3311) (MEP- 400 HERTZ (6115-01-175-7321) (MEP-026C) 28 VDC HERTZ (6115-01-175-7320) {TO 35C2-3-386-4; SL-4-05926A} 032507 TM 5-6115-275-14 10 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208V PHASE, AND 120/240V, SINGLE PHASE, LESS ENGINE: DOD MODELS MEP- HZ, (NSN 6115-00-889-1447) AND MEP-023A, 400 HZ (6115-00-926-08 {NAVFAC P-8-615-14; TO 35C2-3-452-1} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032508 TM 5-6115-275-24P 5 GENERATOR, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE AND 120/240 V, SINGLE PHASE (LESS ENGINE); D MEP-018A, UTILITY CLASS, 60 HZ (NSN 6115-00-889-1447) AND MEP-0 PRECISE CLASS, 400 HZ (6115-00-926-0843) {NAVFAC P8-615-24P; TO 35C2-3-452-4} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032551 TM 5-6115-584-12 11 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-12; TO 35C2-3-456-1; TM 05682C-12} 032640 TM 5-6115-585-12 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 10 KW, 1 PHASE, 2 WIRE 1 PHASE, 3 WIRE AND 3 PHASE, 4 WIRE; 120, 120/240 AND 120/208 V (DOD MODEL MEP-003A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1030 AND (MODEL MEP-112A), UTILITY CLASS, 400 HZ (6115-00-465-1027) {NAVFAC P-8-623-12; TO 35C2-3-455-1;

TM-05684C/05685B-12} 032781 TM 5-6115-584-34 8 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 5 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A), UTILITY CLASS, (NSN 6115-00-465-1044) {NAVFAC P-8-622-34; TO 35C2-3-456-2; TM 0568C-34} 032936 TM 5-6115-329-14 4 GENERATOR SET GASOLINE ENGINE DRIVEN, 0.5 KW (LESS ENGINE) (DOD MODEL MEP-014 UTILITY CLASS, 60 HZ) (NSN 6115-00-923-4469), (DOD MODEL MEP-01 UTILITY CLASS, 400 HZ (6115-00-940-7862) AND (DOD MODEL MEP-024 UTILITY CLASS, 28 VDC (6115-00-940-7867) {TO 35C2-3-440-1} 033374 TM 5-6115-332-14 10 GENERATOR SET, TAC GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE, V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) (MILITARY DOD MODEL MEP-017A), UTILITY, 60 HZ (NSN 6115-00-017-8240) AND MODEL MEP-022A), UTILITY, 400 HZ (6115-00-017-8241) {NAVFAC P-8-614-14; TO 35C2-3-424-1} 033750 TM 5-6115-585-34 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 10 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP-003A), UT CLASS, 60 HZ (NSN 6115-00-465-1030) {NAVFAC P-8-623-12; TO 35C2-3-455-2; TM-05684C/05685B-34} 034072 TM 5-6115-585-24P 5 GENERATOR SET, DIESEL ENGINE DRIVEN, TA SKID MTD, 10 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 W 120, 120/240 AND 120/208 V (DOD MODELS 003A), UTILITY CLASS, 60 (NSN 6115-00-465-1030) AND (MODEL MEP-112A), UTILITY CLASS, 400 (6115-00-465-1027) {NAVFAC P-8-623-24P; TO 35C2-3-455-4; SL-4-05684C/06585B} 040180 TM 5-6115-584-12-HR HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 WIRE; 1 PH, 3 WIRE; 3 PH, 4 WIRE, 120, 120/240 AND 120/208 V (D MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) 040833 TM 5-6115-458-12-HR HAND RECEIPT MANUAL COVERING THE END ITEM/COMPONENTS OF END ITE BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AA GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 20 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODEL MEP-009A), UT CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND (DOD MODEL MEP-108A) PRECISE CLASS, 50/60 HZ (6115-00-935-8729) 040843 TM 5-6115-593-34 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD, 500 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL, MEP-029A, CLASS UTILITY, 50/60 HZ, (NSN 6115-01-030- DOD MODEL, MEP-029B, CLASS UTILITY, 50/60 HZ, (6115-01-318-6302 INCLUDING OPTIONAL KITS DOD MODEL, MEP-029AHK, HOUSING KIT, (6115-01-070-7550), DOD MODEL, MEP-029ACM, AUTOMATIC CONTROL MO (6115-01-275-7912) DOD MODEL, MEP-029ARC, REMOTE CONTROL MODULE (6110-01-070-7553) DOD MODEL, MEP-029ACC, REMOTE CONTROL CABLE, (6110-01-087-4127) {NAVFAC P-8 041070 TM 5-6115-593-12 GENERATOR SET, ENGINE DRIVEN, TACTICAL SKID MTD, 500 KW, 3 PHASE, 4 WIRE; 120/ 240/416 VOLTS DOD MODEL MEP-029A; CLASS UTILITY, HERTZ 50/60; (NSN 6115-01-030-6085); MEP-029B; UTILITY; 50/60; (6115-01-318- INCLUDING OPTIONAL KTS DOD MODELS MEP-029AHK; NOMENCLATURE HOUS (6115-01-070-7550) MEP-029ACM; AUTOMATIC CONTROL MODULE; (6115-01-275-7912); MEP-029ARC, REMOTE CONTROL MODULE, (6110-01-070-7553); MEP-029ACC, REMOTE CONTROL CABLE (6110-01-087-4127) {TO 35C2-3-463-1} 041338 LO 55-1730-229-12 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU), WHEEL MOUNTED, SELF-PROPELLED, TOWABLE DOD MODEL-MEP-360A, CLASS-PRECISE, HERTZ-400, (NSN 1730-01-144-1897 042791 TM 5-6115-457-12-HR HAND RECEIPT MANUAL COVERING THE BASIC ISSUE ITEMS (BII) FOR GE SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP007A), UTILITY CLASS, 50/6 (NSN 6115-00-133-9101), (MODEL MEP-106A), PRECISE CLASS, 50/60 (6115-00-133-9102) AND (MODEL MEP116A) PRECISE CLASS, 400 HZ (6115-00-133-9103) 043437 TM 5-6115-593-24P 1 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 500 KW, 3 PHA 4 WIRE; 120/208 AND 240/416 VOLTS DOD MODEL MEP-029A UTILITY CL 50/60 HZ (NSN 6115-01-030-6085) MEP-029B UTILITY CLASS, 50/60 (6115-01-318-6302) INCLUDING OPTIONAL

KITS DOD MODEL MEP-029AHK HOUSING KIT (6115-01-070-7550) MEP-029ACM AUTOMATIC CONTROL MOD (6115-01-275-7912) MEP-029ARC REMOTE CONTROL MODULE (6110-01-070-7553) MEP-029ACC REMOTE CONTROL CABLE (6110-01-087 {NAVFAC P-8-631-24P; TO 35C2-3-463-4} 044703 TM 5-6115-545-12-HR HAND RECEIPT MANUAL COVERING COMPONENTS OF END ITEM (COEI), BAS ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL) FOR GENERA DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 60 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODELS MEP-006A) UTILITY CLASS, 50/6 (NSN 6115-00-118-1243), (MODEL MEP-105A) PRECISE CLASS, 50/60 H (6115-00-118-1252) AND (MODEL MEP-115A) PRECISE CLASS, 400 HZ (6115-00-118-1253) 050998 TM 5-6115-600-12 8 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 100 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 V (DOD MODEL MEP-007B) CLASS UTILITY, 50/60 (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP00 WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT ELECTRIC 051007 TM 5-6115-600-24P 4 GENERATOR SET, DIESEL ENGINE DRIVEN, 100 KW, 3 PHASE, 4 WIRE, 120/208 AND VOLTS (DOD MODEL MEP-007B), UTILITY CLASS, 50/60 HZ (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP007BWF, WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT, ELECTRIC {TO 35C2-3-442-14; NAVFAC P-8-628-24P; SL-4-07464B} 057268 LO 5-6115-600-12 GENERATOR SET, DIESEL ENGINE DRIVEN; TACTICAL, SKID MTD, 100 KW PHASE, 4 WIRE; 120/208 AND 240/416 V (DOD MODEL MEP007B), CLASS UTILITY, 50/60 HZ (NSN 6115-01-036-6374) 057513 LO 5-6115-604-12 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE; SKID MT 750 KW, 3 PHASE, 4 WIRE; 2400/4160 AND 2200/3800 VOLTS (DOD MOD MEP208A) CLASS PRIME UTILITY, HZ 50/60 (NSN 6115-00-450-5881) {LI 6115-12/9} 060183 TM 5-6115-612-24P 6 GENERATOR SET, AVIATION, GAS TURBINE ENGINE DRIVEN, INTEGRA TRAILER MOUNTED, 10KW, 28 VOLTS MODEL MEP-362A, PRECISE, DC (NSN 6115-01-161-3992) {TM 6115-24P/1; AG-320B0-IPE-000; TO 35C2-3-471-4} 060188 TM 5-6115-612-34 4 GENERATOR SET, AVIATION, GAS TURBINE ENG DRIVEN, INTEGRAL TRAILER MOUNTED 10KW 28 VOLTS DOD MODEL MEP 36 PRECISE, DC, (NSN 6115-01-161-3992) {AG-320BO-MME-000; TM 6115- TO 35C2-3-471-2} 060645 LO 5-6115-612-12 AVIATION GENERATOR SET, GAS TURBINE, ENGINE DRIVEN, INTEGRAL TR MOUNTED, 10KW, 28 VOLTS DC DOD MODEL MEP 362A CLASS PRECISE (NSN 6115-01-161-3992) 060921 TM 55-1730-229-34 5 POWER UNIT, AVIATION, MULTI-OUTPUT GTED, ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWA AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28VDC 700 AMPS, PNEUMATIC, 60 LBS/MIN. AT 40 PSIG, HYDRAULIC, 15 GPM AT 3300 PS DOD MODEL MEP-360A, CLASS PRECISE, 400 HERTZ, (NSN 1730-01-144- {AG 320A0-MME-000; TO 35C2-3-473-2; TM 1730-34/1} 060922 TM 55-1730-229-12 8 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWABLE, AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28 VDC 700 AMPS, PNEUMATIC 60 LBS/M AT 40 PSIG, HYDRAULIC 15 GPM AT 3300 PSIG, DOD MODEL MEP-360A, CLASS PRECISE, HERTZ 400, (NSN 1730-01-144-1897) {AG 320A0-OMM-000; TO 35C2-3-473-1; TM 1730-12/1} 061758 LO 5-6115-614-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD. 200 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS MODEL MEP009B, UTILI 50/60 HERTZ, (NSN 6115-01-021-4096) 061772 LO 5-6115-622-12 GENERATOR SET, DIESEL ENGINE-DRIVEN, WHEEL MOUNTED 750-KW, 3-PH 4-WIRE, 2200/3800 AND 2400/4160 VOLTS CUMMINS ENGINE COMPANY IN MODEL KTA-2300G-2 DOD MODEL MEP-012A; CLASS UTILITY; HERTZ 062762 LO 5-6115-615-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 3 K MODEL 016B; CLASS UTILITY MODE 50/60 HZ (NSN 6115-01-150-4140); DOD MODEL MEP-021B; CLASS UTILITY; MODE 400 HZ (6115-01-151-812 DOD MODEL MEP-026B; CLASS UTILITY; MODE 28 VDC (6115-01-150-036 {LI 05926B/06509B-12/5; P-8-646-LO} 064310 TM 5-6115-626-14&P 2 POWER UNIT PU-406B/M (NSN 6115-00-394-9576) MEP-005A 30 KW 60 HZ GENERATOR SET M200A1 2-WHEEL4-TIRE, MODIFIED TRAILER 064390 TM 5-6115-632-14&P 5 POWER UNIT PU-753/M (NSN 6115-00-033-1 MEP-003A 10 KW 60 HZ GENERATOR SET M116A2 2-WHEEL,

2-TIRE, MODI TRAILER 064392 TM 5-6115-629-14&P 3 POWER PLANT AN/AMJQ-12A (NSN 6115-00-257-1602) (2) MEP-006A 60HZ, GENERATOR SETS (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAIL 064443 TM 5-6115-625-14&P 2 POWER UNIT PU-405A/M (NSN 6115-00-394-9577) MEP-004A 15 KW 60 HZ GENERATOR SET M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER (THIS ITEM IS INCLUDED ON EM 0086 & EM 0087) 064445 TM 5-6115-633-14&P 4 POWER PLANT AN/MJQ-18 (NSN 6115-00-033-1398) (2) MEP-003A 1 60 HZ GENERATOR SETS M103A3 2-WHEEL 1 1/2 TON MODIFIED TRAILER 064446 TM 5-6115-628-14&P 4 POWER PLANT AN/MJQ-15 (NSN 6115-00-400-7591) (2) MEP-113A 1 400 HZ GENERATOR SETS, (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRA (THIS ITEM IS INCLUDED ON EM 0086) 064542 TM 5-6115-631-14&P 4 POWER PLANT AN/MJQ-16 (NSN 61 15-00-033-1395) (2) MEP-002A 5 KW 60 HZ GENERATOR SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAI 065071 TM 55-1730-229-24P 6 POWER AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDAULIC, PNEUMATIC (AG WHEEL MOUNTED, SELF-PROPELLED, TOWABLE AC 400 HZ, 3 PH, 0.8 PF, 115/200V, 30 KW DC 28 VDC 700 AMPS PNEUMATIC 60 LBS/MIN. AT 40 HYDRAULIC 15 GPM AT 3300 PSIG DOD MODEL MEP-360A, CLASS PRECISE 400 HERTZ (NSN 1730-01-144-1897) {TO 35C2-3-473-4; TM 1730-24P/ AG 320A0-IPB-000} 065603 TB 5-6115-593-24 WARRANTY PROGRAM FOR GENERATOR SET DOD MODEL MEP-029A HOUSING K DOD MODEL MEP-029AHK 066727 TM 5-6115-640-14&P 2 POWER AN/MJQ-32 (NSN 6115-01-280-2300) AN/MJQ-33 (6115-01-280-2301) (MEP-701A 3KW 60 HZ ACOUSTIC SUPPRESSION KIT GENERATOR SETS M116 2-WHEEL, 2-TIRE, 3/4-TON MODIFIED TRAILERS 066808 TM 5-6115-627-14&P 2 POWER PLANT AN/MJQ-10A (NSN 6115-00-394-9582); (2) MEP-005A 30 KW 60 HZ GEN SETS; (2) M200A1 2-WHEEL, 4 TIRE MODIFIED TRAILERS 066809 TM 5-6115-630-14&P 4 POWER UNIT, PU-751/M (NSN 6115-00-033-1373) MEP-002A, 5 KW, 60 HZ GENERATOR SET M116A1 2-WHEEL, 2-TIRE, MODIFIED TRAILER 066824 TM 5-6115-465-10-HR 1 HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS, (BII) AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 30K 4 WIRE, 120/208 AND 240/416 VOLTS - MEP-005A, UTILITY, 50/60 HE (NSN 6115-00-118-1240); MEP-104A, PRECISE, 50/60 HERTZ, (6115-00-118-1247): MEP-114A, PRECISE, 400 HERTZ, (6115-00-118- INCLUDING AUXILIARY EQUIPMENT MEP-005AWF WINTERIZATION KIT, FUE BURNING (6115-00-463-9083); MEP-005AWE, WINTERIZATION KIT, ELEC (6115-00 067310 TM 9-6115-650-14&P 1 POWER PLAN AN/MJQ-25 (NSN 6115-01-153-7742) (2) MEP-112A 10 KW 400 HZ GENE SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAILER 067311 TM 9-6115-653-14&P 2 POWER UNIT PU-732/M (NSN 6115-00-260-3082) MEP-113A 15 KW 400 HZ GENERATOR SET M200 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067544 TM 9-6115-652-14&P 1 POWER UNIT PU-760/M (NSN 6115-00-394-9581) MEP-114A 30 KW 400 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067632 TM 9-6115-648-14&P POWER UNIT PU-650B/G (NSN 6115-00-258-1622) MEP-006A 60 KW 60 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067744 TM 9-6115-646-14&P 1 POWER UNIT PU-495A/G, (NSN 6115-00-394-9575) AND PU-495B/G, (6115-01-134-0 MEP-007A 100 KW, 60 HZ OR MEP-007B, 100 KW, 60 HZ GENERATOR SET M353-2-WHEEL, 2-TIRE MODIFIED TRAILER 067746 TM 9-6115-651-14&P POWER UNIT 707A/M (NSN 6115-00-394-9573) MEP-115A, 60 KW, 400 HZ GENERATOR M200A1, 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067879 TM 9-6115-647-14&P 1 POWER UNIT PU-789/M (NSN 6115-01-208-9827) MEP-114A, 30 KW 400 HZ GENERATOR SET M353 2-WHEEL, 2-TIRE, MODIFIED TRAILER 069601 TM 9-6115-464-10-HR HAND RECEIPT MANUAL COVERING THE END ITEMS/COMPONENTS OF END IT (COEI), BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION L (AAL) FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MO 15 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL MEP UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP PRECISE CLASS, 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113 PRECISE CLASS, 400 HERTZ (6115-00-118-1244) 069602 LO 9-6115-464-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD, 15KW, 4 WIRE, 120/208 AND 240/416 VOLTS (DOD MODEL MEP 004A)

(NSN 6115-00-118-1241); (DOD MODEL MEP 104A) (6115-00-118-1245) (DOD MODEL MEP-113A) (6115-00-118-1244) 069954 TM 9-6115-465-24P 2 GENERATOR SET, DIESEL ENGINE DRIVE TACTICAL SKID MTD. 30KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V MODELS; MEP-005A, UTILITY, 50/60 HZ, (NSN 6115-00-118-1240), MEP-104A PRECISE, 50/60 HZ, (6115-00-118-1247), MEP-114A, PRECISE, 400 H (6115-00-118-1248), INCLUDING OPTIONAL KITS, DOD MODELS; MEP-00 WINTERIZATION KIT, FUEL BURNING, (6115-00-463-9083), MEP-005-AW WINTERIZATION KIT, ELECTRIC, (6115-00-463-9085), MEP-002-ALM, L BANK KIT, (6115-00-463-9088), MEP-005-AWM, WHEEL MOUNTING KIT, (6115-00-463-9094) {TO-35C2-3-070096 TM 9-6115-464-24P 1 GENERATOR S DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS (DOD MODEL MEP-004A) UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) (DOD MODEL MEP-103A) PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) (DOD MODEL MEP-113A) PRECI CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS (DOD MODEL MEP-005-AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (DOD MODEL MEP-005-AWE) WINTERIZATION KIT, ELECTRIC (6615-00-46 (DOD MODEL MEP-004-ALM) LOAD BANK KIT (6115-00-191-9201 071025 TM 9-6115-641-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-11} 071026 TM 9-6115-642-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIE 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-11; TM 09247A/09248A-10/1} 071028 TM 9-6115-643-10 3 GENERATOR SET, SKID MOUNTED, TACTICAL QUI 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-73 MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-21} 071029 TM 9-6115-644-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ), (NSN 6115-01-274-7389) MEP-815A (400 HZ), (6115-01-274-7394) {TO 35C2-3-446-11; TM 09249A/09246A-10/1} 071030 TM 9-6115-645-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ), (NSN 6115-01-274-7390) MEP-816A (400 HZ), (6115-01-274-7395) {TO 35C2-3-444-11; TM 09244A/09245A-10/1} 071031 LO 9-6115-641-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A TACTICAL QUIET 60 HZ (NSN 6115-01-274-7387) MEP-812A TACTICAL QUIET 400 HZ (6115-01-274-7391) 071032 LO 9-6115-642-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 H MEP-803A TACTICAL QUIET 60 HZ (NSN 6115-01-275-5061) MEP-813A TACTICAL QUIET 400 HZ (6115-01-274-7392) 071033 LO 9-6115-643-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60/400 HZ MEP-804A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7388) MEP-814 TACTICAL QUIET 400 HZ (6115-01-274-7393) 071034 LO 9-6115-644-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 40 MEP-805A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7389) MEP-815 TACTICAL QUIET 400 HZ (6115-01-274-7394) {LI 09249A/09246A-12} 071035 LO 9-6115-645-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 40 MEP-806A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7390) MEP-816 TACTICAL QUIET 400 HZ (6115-01-274-7395) {LI 09244A/09245A-12} 071036 TB 9-6115-641-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A AND MEP-812A 071037 TB 9-6115-642-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A AND MEP-813A {SI 09247A/09248A-24} 071038 TB 9-6115-643-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A AND MEP-814A 071039 TB 9-6115-644-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A AND MEP-815A {SI 09249A/09246A-24} 071040 TB 9-6115-645-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A AND MEP-816A {SI 09244A/09245A-24} 071541 TM 9-6115-464-12 2 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 15 KW, 3 PHASE, 4 WIRE, 120/2 AND 240/416 VOLTS DOD MODEL MED-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP-103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE

CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005-AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005-AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004-ALM LOAD BANK KIT (6115-00-291 071604 TM 9-6115-645-24P GENERATOR SET, TACTICAL QUIET 60KW, 50/60/400 HZ (NSN 6115-01-274-7390) (MEP-806A) (6115-01-274-7395) (MEP-816A) {TO 35C2-3-444-14; TM 09244A/09245A-24P/3} 071605 TM 9-6115-642-24P GENERATOR SET, TACTICAL QUIET 10 KW, 60/400 HZ (NSN 6115-01-275-5061) (MEP-803A) (6115-01-274-7392) (MEP-813A) {TO 35C2-3-455-14; TM 09247A/09248A-24P/3} 071610 TM 9-6115-643-24P GENERATOR SET, TACTICAL QUIET 15KW, 50/60 - 400 HZ (NSN 6115-01-274-7388) (MEP-804A) (6115-01-274-7393) (MEP-814A) {TO 35C2-3-445-24} 071611 TM 9-6115-644-24P GENERATOR SET, TACTICAL QUIET 30KW, 50/60-400 HZ (NSN 6115-01-274-7389) (MEP-805A) (6115-01-274-7394) (MEP-815A) {TO 35C2-3-446-14; TM 09249A/09246A-24P/3} 071613 TM 9-6115-641-24P GENERATOR SET, TACTICAL QUIET 5 KW, 60/400 HZ (NSN 6115-01-274-7387) (MEP-802A) (6115-01-274-7391) (MEP-812A) {TO 35C2-3-456-14} 071713 TM 9-6115-645-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ) (NSN 6115-01-274-7390) MEP-816A (400 HZ) (6115-01-274-7395) {TO 35C2-3-444-12; TM 09244A/09245A-24/2} 071748 TM 9-6115-644-24 1 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ) (NSN 6115-01-274-7389) MEP-815A (400 HZ) (6115-01-274-7394) {TO 35C2-3-446-12; TM 09249A/09246A-24/2} 071749 TM 9-6115-643-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-7388) MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-22} 071750 TM 9-6115-642-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-12; TM 09247A/09248A-24/2} 071751 TM 9-6115-641-24 3 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-12} 072239 TM 9-6115-464-34 1 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS DOD MODEL MEP-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP 103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005AWE WINTERIZAT KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004ALM LOAD BANK KIT (6115-00-291-920 073744 TM 9-6115-604-24P 1 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MOUNTED, 750KW, 3 PHASE, 4 WIRE, 2400/4160, AND 2200/3800 VOLTS DOD MODEL MEP208A PRIME UTILITY CLASS 50/60 HERTS (NSN 6115-00-450-5881) DOD MODEL 80-1466 REMOTE CONTROL MODULE CLASS (6115-01-150-5284 DOD MODEL 80-7320 SITE REQUIREMENTS MODULE CLASS (6115-01-150-5 {NAVFAC P-8-633-24P} 074040 TM 9-6115-545-24P GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, D MODELS MEP-006A, UTILITY CLASS, 50/60 H/Z, (NSN 6115-00-118-124 MEP-105A, PRECISE CLASS, 50/60 H/Z, (6115-00-118-1252), MEP-115 PRECISE CLASS, 400 H/Z (6115-00-118-1253); INCLUDING OPTIONAL K DOD MODELS MEP-006AWF, WINTERIZATION FUEL BURNING, (6115-00-407 MEP-006AWE, WINTERIZATION KIT, ELECTRIC, (6115-00-455-7693), ME LOAD BANK KIT, (6115-00-407-8322), AND MEP-006AWM, WHEEL MOUNTI (6115-00-463-9092) {TO 074212 TM 9-6115-604-12 GENERATOR SET, DIESEL DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 24 AND 2200/3800 V (DOD MODEL MEP 208A) CLASS PRIME UTILITY, HZ 50 (NSN 6115-00-450-5881) {NAVFAC P-8-633-12} 074896 TM 9-6115-604-34 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 2400/4160 AND 2200/3800 VOLTS DOD MODEL MEP 208A PRIME UTILITY CLASS 50/60 HERTZ (NSN 6115-00-450-5881) {NAVFAC P-8-633-34} 075027 TM 9-6115-584-24P 1 GENERATOR SET, DIESEL E DRIVEN, TACTICAL SKID MTD 5 KW, 1 PHASE -2 WIRE, 1 PHASE -3 WIR 3 PHASE -4

WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP- UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-24P TO 35C2-3-456-4} 077581 TM 9-6115-673-13&P 2KW MILITARY TACTICAL GENERATOR SET 120 VAC, 60 HZ (NSN 6115-01-435-1565) (MEP-531A) (EIC: LKA) (NSN 6115-21-912-0393) (MECHRON) 28 VDC (NSN 6115-01-435-1567) (MEP-501A) (EIC: LKD) (NSN 6115-21-912-0392) (MECHRON) 078167 TM 9-6115-672-14 GENERATOR SET SKID MOUNTED TACTICAL QUIET 60KW, 50/60 AND 400 HZ, MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) EIC: GGW, MEP-816B (400 HZ) (NSN 6115-01-462-0292) EIC: GGX 078443 TM 9-6115-639-13 1 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 078490 TM 9-6115-671-14 OPERATOR, UNIT, GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ, MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (6115-01-462-0290) (EIC: GGV) 078503 TM 9-6115-671-24P GENERATOR SET SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (NSN 6115-01-462-0290) (EIC: GGV) 078504 TM 9-6115-672-24P GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) (EIC: GGW) MEP-816B (400 HZ) (NSN 6115-01-462-0292) (EIC: GGX) 078505 TB 9-6115-671-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-805B AND MEP-815B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078506 TB 9-6115-672-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-806B AND MEP-816B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078523 TM 9-6115-664-13&P 5KW, 28VDC, AUXILIARY POWER UNIT (APU) MEP 952B NSN 6115-01-452-6513 (EIC: N/A) 078878 TM 9-6115-639-23P 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 079379 TB 9-6115-641-13 WINTERIZATION KIT (NSN 6115-01-476-8973) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 5KW, 60 AND 400 HZ MEP-802A (600HZ) (6115-01-274-7387) MEP-812A (400HZ) (6115-01-274-7391) 079460 TB 9-6115-642-13 WINTERIZATION KIT (NSN 6115-01-477-0564) (EIC: N/A) INSTALLED ON GENERATOR KIT, SKID MOUNTED, TACTICAL QUIET, 10KW, 60 AND 400 HZ MEP-803A (60HZ) (6115-01-275-0561) MEP-813A (400HZ) (6115-01-274-7392) 079461 TB 9-6115-643-13 WINTERIZATION KIT (NSN 6115-477-0566) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 15KW, 50/60 AND 400 HZ, MEP-804A (50/60HZ) (6115-01-274-7388) MEP-814A (400HZ) (6115-01-274-7393) 079462 TB 9-6115-644-13 WINTERIZATION KIT (NSN 6115-01-474-8354) (EIC:N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, 30KW, 50/60 AND 400 HZ MEP-805A (50/60HZ) (NSN 6115-01-274-7389) MEP-815A (400HZ) (NSN 611501-274-7394) 079463 TB 9-6115-645-13 WINTERIZATION KIT (NSN 6115-01-474-8344) (EIC: N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 60KW, 50/60 AND 400 HZ, MEP-806A (50/60HZ) (6115-01-274-7390) MEP-816A (400HZ) (6115-01-274-7395) 080214 TM 9-6115-670-14&P AUXILIARY POWER UNIT, 20KW, 120/240 VAC, 60 HZ, MODEL NO. MEP-903A(SICPS) NSN 6115-01-431-3062 MODEL NUMBER MEP-903B (JTACS) NSN 6115-01-431-3063 MODEL NO MEP-903C9WIN-T) NSN 6115-01-458-5329 (EIC: N/A)

120 240 single phase wiring diagram: Construction Electrician 1 and C, NAVPERS 10637-C Bureau of Naval Personnel, 2018-09-17 This book is intended to serve as an aid for men who are seeking to acquire the theoretical knowledge and operational skills required of candidates for advancement to the rates of Construction Electrician First Class and Chief Construction Electrician. Preparing for advancement in rating 1 Defensive tactics 10 Electrical sketching and planning 59 Protective devices and controllers 82 Testing equipment 115 Power generators 144 Power distribution system 172 Communication 193 Cold weather operations 231 Training 238 Foremanship 257 Maintenance programs 268 NBC warfare defense equipment 283

120 240 single phase wiring diagram: *Anchor Dam* United States. Bureau of Reclamation, 1962

120 240 single phase wiring diagram: REA Bulletin , 1952

120 240 single phase wiring diagram: Electrical Standards Reference Manual United States. Occupational Safety and Health Administration. Office of Training and Education, 1987

120 240 single phase wiring diagram: Standing Operating Procedures for Whiskeytown Dam and Reservoir United States. Bureau of Reclamation, 1970

120 240 single phase wiring diagram: Operator, Organizational, Direct Support, and General Support Maintenance Manual , 1992

120 240 single phase wiring diagram: Basic Industrial Electricity Kenneth G. Oliver, 1991

120 240 single phase wiring diagram: Renewable and Efficient Electric Power Systems Gilbert M. Masters, 2013-06-05 A solid, quantitative, practical introduction to a wide range of renewable energy systems in a completely updated, new edition The second edition of Renewable and Efficient Electric Power Systems provides a solid, quantitative, practical introduction to a wide range of renewable energy systems. For each topic, essential theoretical background is introduced, practical engineering considerations associated with designing systems and predicting their performance are provided, and methods for evaluating the economics of these systems are presented. While the book focuses on the fastest growing, most promising wind and solar technologies, new material on tidal and wave power, small-scale hydroelectric power, geothermal and biomass systems is introduced. Both supply-side and demand-side technologies are blended in the final chapter, which introduces the emerging smart grid. As the fraction of our power generated by renewable resources increases, the role of demand-side management in helping maintain grid balance is explored. Renewable energy systems have become mainstream technologies and are now, literally, big business. Throughout this edition, more depth has been provided on the financial analysis of large-scale conventional and renewable energy projects. While grid-connected systems dominate the market today, off-grid systems are beginning to have a significant impact on emerging economies where electricity is a scarce commodity. Considerable attention is paid to the economics of all of these systems. This edition has been completely rewritten, updated, and reorganized. New material has been presented both in the form of new topics as well as in greater depth in some areas. The section on the fundamentals of electric power has been enhanced, making this edition a much better bridge to the more advanced courses in power that are returning to many electrical engineering programs. This includes an introduction to phasor notation, more emphasis on reactive power as well as real power, more on power converter and inverter electronics, and more material on generator technologies. Realizing that many students, as well as professionals, in this increasingly important field may have modest electrical engineering backgrounds, early chapters develop the skills and knowledge necessary to understand these important topics without the need for supplementary materials. With numerous completely worked examples throughout, the book has been designed to encourage self-instruction. The book includes worked examples for virtually every topic that lends itself to quantitative analysis. Each chapter ends with a problem set that provides additional practice. This is an essential resource for a mixed audience of engineering and other technology-focused individuals.

120 240 single phase wiring diagram: Electrical Power Systems Technology Dale R. Patrick, Stephen W. Fardo, Brian W. Fardo, 2022-06-01 Electrical Power Systems Technology, Fourth Edition covers a wide range of technologies and systems used in the generation, distribution, control, conversion, and measurement of electrical power. This reference book provides a foundational overview presented in a basic, easy-to-understand manner. The content is organized in a logical pedagogical style using five basic power system components - Measurement, Generation, Distribution, Control, and Conversion. Each of these basic systems is broken down into sub-systems, equipment, and components that are explored in greater detail in each of the 18 chapters. Simplified mathematical concepts are described with practical applications to assist in fundamental understanding. Abundant illustrations (almost one per page) are used to add visual information to supplement technical knowledge development. The fourth edition has been edited to provide improved information and clarity, including many new illustrations. An additional chapter - Chapter

18 - Evolving Power System Technologies and Considerations - has been added to describe issues related to power system operation.

120 240 single phase wiring diagram: Handbook of Water and Wastewater Treatment Plant Operations, Third Edition Frank R. Spellman, 2013-10-21 Handbook of Water and Wastewater Treatment Plant Operations the first thorough resource manual developed exclusively for water and wastewater plant operators has been updated and expanded. An industry standard now in its third edition, this book addresses management issues and security needs, contains coverage on pharmaceuticals and personal care products (PPCPs), and includes regulatory changes. The author explains the material in layman's terms, providing real-world operating scenarios with problem-solving practice sets for each scenario. This provides readers with the ability to incorporate math with both theory and practical application. The book contains additional emphasis on operator safety, new chapters on energy conservation and sustainability, and basic science for operators. What's New in the Third Edition: Prepares operators for licensure exams Provides additional math problems and solutions to better prepare users for certification exams Updates all chapters to reflect the developments in the field Enables users to properly operate water and wastewater plants and suggests troubleshooting procedures for returning a plant to optimum operation levels A complete compilation of water science, treatment information, process control procedures, problem-solving techniques, safety and health information, and administrative and technological trends, this text serves as a resource for professionals working in water and wastewater operations and operators preparing for wastewater licensure exams. It can also be used as a supplemental textbook for undergraduate and graduate students studying environmental science, water science, and environmental engineering.

120 240 single phase wiring diagram: Blueprint Reading and Sketching United States. Bureau of Naval Personnel, 1968

120 240 single phase wiring diagram: Harvey's Electrical Code Field Guide Harvey N. Holzman, 2005

120 240 single phase wiring diagram: Electrical Design Corrosion Control United States. Department of the Army, 1962

120 240 single phase wiring diagram: *Specifications and Drawings for 14.4/24.9 Kv. Line Construction* United States. Rural Electrification Administration, 1963

120 240 single phase wiring diagram: Construction Electrician's Mate 1 & C United States. Bureau of Naval Personnel, 1951

120 240 single phase wiring diagram: Overhead Distribution Systems United States. War Department, 1946

120 240 single phase wiring diagram: Specifications and Drawings for 7.2/12.5 Kv. Line Construction United States. Rural Electrification Administration, 1962

120 240 single phase wiring diagram: Specifications for Rural Electric Distribution Pole Lines Tennessee Valley Authority, 1940

120 240 single phase wiring diagram: Selman's The Fundamentals of Imaging Physics and Radiobiology Victor White, 2020-10-16 This tenth edition of Selman's The Fundamentals of Imaging Physics and Radiobiology is the continuation of a seminal work in radiation physics and radiation biology first published by Joseph Selman, MD, in 1954 by Charles C Thomas, Publisher, Ltd., Springfield, IL. Many significant changes have been made in this tenth edition. Color photographs and new illustrations have been provided for several existing chapters and for the new chapters in this book. Revisions and updates have been completed for Chapters 1 through 28, whereas Chapters 29 to 33 are all new. The overall style of Doctor Selman is still present, but, with any revision, the style of the present author is also present. In essence, the author's *raison d'être* in revising this book was to better reflect current radiology practice and to honor the work of Doctor Selman. Topics discussed in this textbook deal with the physics of x-radiation, the biological interaction of radiation with matter, and all aspects of imaging equipment and technology commonly found in the modern radiology department. The chapter on computed tomography (CT) has been

heavily revised and updated. Protective measures regarding radiation safety and radiation hazards for workers and patients are thoroughly discussed and new chapters on dual energy x-ray absorptiometry (DXA), magnetic resonance imaging (MRI), ultrasound (US), fusion and molecular imaging have been added. This book will be very helpful to students about to take the ARRT (R) registry examination, but it is not a registry review book per se. This book also serves as a good overview of radiologic imaging physics for radiographers and other medical professionals.

120 240 single phase wiring diagram: Specifications and Drawings for 24.9/14.4 KV Line Construction , 1999

120 240 single phase wiring diagram: Specifications and drawings for 14.4/24.9 kV line construction , 1969

120 240 single phase wiring diagram: Anchor Dam, Constructed 1957-1961, Missouri River Basin Project, Wyoming United States. Bureau of Reclamation, 1962

120 240 single phase wiring diagram: Organizational, Intermediate (field), Direct Support and General Support, Maintenance Repair Parts and Special Tools List (including Depot Maintenance Repair Parts and Special Tools) , 1987

Additional Resources

Jefferson Electric - Single-Phase Encapsulated Transformers

NOTE: Electrostatic shields are optionally available and not shown in all wiring diagrams. * Insulate unused taps individually.

SECTION XV DRAWINGS AND TABLES - New York State ...

All 120 volt single phase utilization receptacle outlets must have approved ground fault circuit protection. Example: 15 or 20 amp. outlets. *See specification #1 for details of cable. 1. ...

Single-Phase Encapsulated 7 - jeffersonelectric.com

Single-Phase Encapsulated General Purpose Transformers .050 - 1 kVA, 95°C Temperature Rise, 1.5 - 25 kVA, 135°C Temperature Rise 120 x 240V – 120/240V
• Taps: None

OPTION A 208 - 240 VAC, Three-Phase, 4-Wire Delta ...

Above diagram depicts two different wiring configurations. One is 208-240 volt, singlephase, 3-wire. Note that lines R/L1 and S/L2 are connected through the circuit breaker to the ...

WIRING DIAGRAM- 120/208/240 VAC 1-PHASE - Manaras

single two white d red k wiring diagram- 120/208/240 vac 1-phase c gray sequence please consult manaras/ delay, connect back to adv. open for any other options like, timer to module or any ...

A FIELD WIRING DIAGRAM A 240 VAC SINGLE PHASE

240 vac single phase NOTE: The grounding method shown is one of multiple allowable methods. A GEC (grounding electrode conductor) is required only for M215-60-2LL.

120 240 Single Phase Wiring Diagram (Download Only)

A typical 120/240 single phase wiring diagram includes several essential components: Transformer: The heart of the system, transforming the higher

voltage from the utility into the ...

Buck boost dry type transformers operating and installation ...

Buck-Boost Connection Diagram Use the following information for single-phase autotransformer connections. Note: Inputs and outputs may be reversed; kVA capacity remains constant. All ...

REQUIREMENTS & STANDARDS METER SOCKET SINGLE ...

120/240 volt 120/208 volt, network (see note 1) n 2 3 1 notes: 1. a fifth terminal (stinger) is required for a 120/208v service. 2. wire size range: 2.1 - 100 amp socket: lugs suitable for #6 - ...

Control power and encapsulated transformers - ABB

120/240 V secondaries (series-multiple) may be connected for 120 V, 240 V or 240/120 V three-wire. Jumpers are provided. Overcurrent protection: Type IP transformers are low impedance ...

Appendix 15a - Jefferson Electric

Single Phase Transformer Wiring Diagrams. Appendix 15a-3 S208B Wiring Diagram & Connections Connections Primary Volts Interconnect Primary Lines Connect To ... Wiring ...

DTK-120/240CM+ - DITEK Surge Protection

Type 1 SPD for hardwired installation on 120/240 VAC split phase electrical service or disconnect switch. Caution: Measure all voltages to verify applied voltage does not exceed the voltage ...

Common 12-Lead Generator Wiring Diagrams - TractorByNet

Voltage L-L: 240V Voltage L-N: 120V Preferred Single-Phase Connection. Don't Use Zig-Zag if Possible. NOTE: Derate generator by 1/3 rated capacity when using this connection!

25 kVA Isolation Transformer - 208V Primary - 120/240V ...

208V-25KVA-120V.240-N3R transformer is a single phase unit with a primary voltage of 208V. It also provides a secondary voltage of 120/240V. Featuring robust construction, this unit's cores ...

Low-voltage dry-type mini-power centers - Eaton

Jan 1, 2016 · Mini-power centers are used wherever there is a 480 V or 600 V distribution system and loads requiring 208Y/120 V, three-phase or 120/240 V single-phase. Typical installations ...

Single-Phase Encapsulated 2 - Jefferson Electric

2 Single-Phase Encapsulated Wiring Diagram S240A Wiring Diagram & Connections* Primary: 120 x 240 Secondary: 120/240 Wiring Diagram S208A Wiring Diagram & Connections* ...

National Grid Specifications for One Line Diagrams (5)

Below is an example of a one line diagram and a list of metering guidelines. The one line diagram is for a 400 amp 120/208 three phase service and is for reference only. METERING ...

Dry-type distribution transformers— general purpose - Eaton

Jan 1, 2016 · Eaton's single-phase and three-phase general purpose dry-type ventilated transformers are of the two-winding type, self-cooled, and are available in a wide variety of ...

SP2 Surge Protective Device Instruction Manual IB158003EN

Choose a mounting location for the SPD that provides the shortest and straightest possible wiring (but not less than six inches lead length) from the SPD to the electrical system connections. ...

120 / 240 VAC SINGLE SPLIT PHASE & MULTI-WIRE BRA...

Fig. 1 below illustrates the residential 120 / 240 VAC, Single Split Phase, 3- Pole, 4 Wire Grounding System, which was inherited from Edison's early DC ...

Jefferson Electric - Single-Phase Encapsulated Transf...

NOTE: Electrostatic shields are optionally available and not shown in all wiring diagrams. * Insulate unused taps individually.

SECTION XV DRAWINGS AND TABLES - New York State E...

All 120 volt single phase utilization receptacle outlets must have approved ground fault circuit protection. Example: 15 or 20 amp. outlets. *See ...

Single-Phase Encapsulated 7 - jeffersonelectric.com

Single-Phase Encapsulated General Purpose Transformers .050 - 1 kVA, 95°C Temperature Rise, 1.5 - 25 kVA, 135°C Temperature Rise 120 x 240V ...

OPTION A 208 - 240 VAC, Three-Phase, 4-Wire Delta

Above diagram depicts two different wiring configurations. One is 208-240 volt, singlephase, 3-wire. Note that lines R/L1 and S/L2 are connected ...

[120 240 Single Phase Wiring Diagram](#)

120 240 Single Phase Wiring Diagram

Related Articles

- [10k training plan advanced](#)
- [120 volt baseboard heater wiring diagram](#)
- [120v relay wiring diagram](#)

[Back to Home](#)